



all lorry parts



**Quality
Spare
Parts**

**Replacement Spare Part
For
DAF, RENAULT, VOLVO, SCANIA
TRUCKS**



The company of ALP Automotive LTD was established in 1996 as an import and export constitution. The purpose is to create a worldwide vision and perspective providing qualified, reliable and affordable goods.

At first, ALP initiated to specialize in aftermarket spare parts for DAF trucks and rapidly expanded it's acknowledge, experience and quality day by day. After 23 years of experience, ALP offers it's customers under the registered trademark ALP for DAF, Renault, Scania, Mercedes, Volvo, MAN and Iveco.

In addition to ALP brand, our company is also the regional dealer of Kolbenschmidt (KS), which is known as a Dutch company for engine parts to supply all demands and requirements of our customer with perfection of quality.

The essential principle is to appreciate and care about our customers. We ensure all to keep the satisfaction of customers at the highest level without compromising from its superior quality.

Proud to operate within this specialist group, ALP is one of the Turkey's reputable independent distributors of replacement truck spares, supplying premium-quality replacement commercial vehicle spares.

	OEM NO	DESCRIPTION	NOTES	
	20453627 20534600	LAMP SHROUD, LH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20453628 20534601	LAMP SHROUD, RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	3090972 1062547 3980869 20398385	HOUSING HEAD LAMP L	FH12, FH16	
	3090971 1062548 3980870 20398386	HOUSING HEAD LAMP R	FH12, FH16	
	20360567 3980967	EMBLEM	FH12 / FH16	
	20392544	MUDGUARD LH - RH	FH12, FH16, FM12, FM16	
	8144482 1063509 1062624	GRILLE	FH12, FH16	
	8144455 20360507 20360073	GRILLE	FH12, FH16, FM12, FM16	
	8141312	COVER L	FH12, FH16, FM12, FM16	
	8141313	COVER R	FH12, FH16, FM12, FM16	

	OEM NO	DESCRIPTION	NOTES	
	20467053	FRAME, GRILLE	FH12 / FH16	
	20453600	EMBLEM	FH12 / FH16	
	1611754	EMBLEM	F12 CH.314000	
	1607898	EMBLEM INTERCOOLER	F12 CH.314000	
	21116881	ACCELATOR PEDAL	FH12 / FH16 FM9 / FM12	
	20893503	ACCELATOR PEDAL	FH12 / FH16 FM9 / FM12	
	20478734	AIR FILTER	FH 12 /16	
	1083666 (1621376)	UPPER GRILLE	F10 ch.314000-, F12 ch.314000-, F16	
	20456710	SUN VISOR UPPER	FH / FM	
	20360593	WATER TANK, WASHER SYSTEM	FH12 / FH16 FM9 / FM12	

	OEM NO	DESCRIPTION	NOTES	
	1621181 1608098	GRILLE	F10 ch.314000-, F12 ch.314000-, F16	
	1086219 (1080564)	DIRT DEFLECTOR L	FL7, FL10	
	1086220 (1080565)	DIRT DEFLECTOR R	FL7, FL10	
	1594334	DIRT DEFLECTOR L	FL7, FL10	
	1594335	DIRT DEFLECTOR R	FL7, FL10	
	1610782	DIRT DEFLECTOR L	F10 ch.314000- F12 ch.314000- F16	
	1610783	DIRT DEFLECTOR R	F10 ch.314000- F12 ch.314000- F16	
	1698144 (1521323)	DIRT DEFLECTOR L	F10 ch.314000- F12 ch.314000- F16	
	1698145 (1521324)	DIRT DEFLECTOR R	F10 ch.314000- F12 ch.314000- F16	
	1621182	SPACER L	F10 ch.314000- F12 ch.314000- F16	

	OEM NO	DESCRIPTION	NOTES	
	1621183	SPACER R	F10 ch.314000- F12 ch.314000- F16	
	1088870	CAP, HEADLAMP L	F10 ch.314000- F12 ch.314000- F16	
	1088871	CAP, HEADLAMP R	F10 ch.314000- F12 ch.314000- F16	
	1698146 (1621184)	HOUSING, LIGHT INDICATER L	F10 ch.314000- F12 ch.314000- F16	
	1698147 (1621185)	HOUSING, LIGHT INDICATER R	F10 ch.314000- F12 ch.314000- F16	
	20360266	FRONT PANEL UPPER	FH 12 / 16 NEW	
	20453716	FRONT PANEL LOWER	FH 12 / 16 NEW FM 9 / 10 / 12	
	20409818 20529704	STEP, FRONT PANEL	FH 12 / 16 NEW FM 9 / 10 / 12	
	20379175	CORNER PANEL , LH	FH 12 / FH16 vers.2	
	20379176	CORNER PANEL , RH	FH 12 / FH16 vers.2	

	OEM NO	DESCRIPTION	NOTES	
	20442252	OUTER RING, SPRING SADDLE	FH/FM/NH 9/10/12/13/16	
	20524754	PULLEY, WATER PUMP	FH16	
	20711223	PULLEY, WATER PUMP	FH/FM SERIES	
	8086970	TENSION ROLLER, FAN	FM9/ B9	
	20747516 20503093	TENSION ROLLER, FAN	FH16	
	1676687	BELLOW, AIR FILTER	FH12 / FH16 FM7 / FM9 / FM10	
	70301773	MOUNTING ENGINE REAR	B7 / B9 / B123	
	20503552 1626870	MOUNTING ENGINE FRONT	FH12 / FH16 / FM10 FM12 / NH12	
	20503551 1622825	MOUNTING ENGINE FRONT	FH12 / FH16 / FM10 FM12 / NH12	
	20399992 20399980	MOUNTING ENGINE REAR	FH12 / FH16 / FM10 FM12 / NH12	

	OEM NO	DESCRIPTION	NOTES	
	21228153 20723224	MOUNTING ENGINE REAR	FH / FM SERIES	
	20499469	MOUNTING ENGINE REAR	FH12 / FH16 / FM12 NH12	
	20499470	MOUNTING ENGINE REAR	FH / FM SERIES	
	20819267	SPRING, CLUTCH PEDAL	FL / FE SERIES	
	276830 276318 273851	REPAIR KIT, GEAR SHIFT	ALL MODELS	
	276831 276319 273852	REPAIR KIT, GEAR SHIFT	ALL MODELS	
	1076701	LOCK WASHER, AXLE	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16 ø69/62,5xø110x8	
	20424593	LOCK WASHER, AXLE	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16 ø58.5/52,5xø79x6	
	20424594	LOCK WASHER, AXLE	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16 ø68.5/62,5xø96x6	
	20456099	AXLE NUT	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16 M52x222,5SW70	


	OEM NO	DESCRIPTION	NOTES	
	20424598	AXLE NUT M60x200xSW80	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16	
	1699357	KING PIN KIT, AXLE STEERING KNUCKLE	FL10 / FM7 / FM10 FM12 / NL10 / NL12	
	3092467	KING PIN KIT, AXLE STEERING	FH12 / FM7 / FM 10 FM12 /	
	1078564	COVER, STEERING AXLE	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16	
	3038061	HUB CAP	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16	
	1088812	BUSHING , BRAKE ADJUSTER	FL10 / FM7 / FM10 FM12 / NL10 / NL12	
	271259	SPRING KIT ,BRAKE	FL 608 FL 615 B6	
	3173294 1628433	V STAY	NEW MODELS	
	1606200 1080690	V STAY	F88, F89, F10, F12 N10, N12, F 16, FL10 FL12	
	1076639	V STAY	VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	1606552	V STAY	VOLVO	
	3172829	V STAY	Volvo F/FL 6, F/FE/FL/F M 7 Volvo FH/FM/NH 9/10/ 12/13/16	
	3173295	V STAY	Volvo F/FL 6, F/FE/FL/F M 7	
	3173292 20556491	V STAY	Volvo F/FL 6, F/FE/FL/F M 7 Volvo FH/FM/NH 9/10/ 12/13/16	
	3173293 20556492	V STAY	Volvo F/FL 6, F/FE/FL/F M 7 Volvo FH/FM/NH 9/10/ 12/13/16	
	3173291 20556490	V STAY	Volvo F/FL 6, F/FE/FL/F M 7 Volvo FH/FM/NH 9/10/ 12/13/16	
	20502944 20382314	V STAY	Volvo F/FL 6, F/FE/FL/F M 7 Volvo FH/FM/NH 9/10/ 12/13/16	
	20741695 20741703	V STAY	Volvo F/FL 6, F/FE/FL/F M 7 Volvo FH/FM/NH 9/10/ 12/13/16	
	1590068	V STAY	Volvo F/FL 6, F/FE/FL/F M 7 Volvo FH/FM/NH 9/10/ 12/13/16	
	1082104 1605035	TIE ROD	NEW MODELS	

	OEM NO	DESCRIPTION	NOTES	
	8147151	TORQUE ARM 620mm	FH12 / FH16 / FH13 FM10 / FM12	
	8365399	TORQUE ARM	FH12 / FH16 / FH13 FM10 / FM12	
	1589817	TORQUE ARM	FH12 / FH16 / FH13 FM10 / FM12	
	1135429	TORQUE ARM	FH12 / FH16 / FH13 FM10 / FM12	
	1135427	TORQUE ARM	FH12 / FH16 / FH13 FM10 / FM12	
	1626958	TORQUE ARM	FH12 / FH16 / FH13 FM10 / FM12	
	20517494	TORQUE ARM	FH12 / FH16 / FH13 FM10 / FM12	
	1620497	TORQUE ARM	FH12 / FH16 / FH13 FM10 / FM12	
	8172031	RELEASE FORK (CLUTCH)	FH12 / FH16 / FH13 FM10 / FM12	
	3191966	RELEASE FORK (CLUTCH)	FH12 / FH16 / FH13 FM10 / FM12	

	OEM NO	DESCRIPTION	NOTES	
	1077574	OIL PRESSURE SENSOR	Bus F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16	
	20484678 20428456 20886108	PRESSURE SENSOR 0-7 BAR / 3PIN	FH/FM/NH 9/10/12/13/16	
	20508011	ENGINE SPEED SENSOR	FM / FH / N H / B SERIES	
	20382529 8155724	SWITCH CABIN LOCK	FH/FM/NH 9/10/12/13/16	
	1676594	OIL FILLER CONNECTOR (WITHOUT CAP)	FH/FM/NH 9/10/12/13/ FH16	
	1675839 20807510	OIL FILLER CAP	FH/FM/NH 9/10/12/13/ FH16	
	3171490 1077500 3962959	KM SENSOR	Bus F/FL 6, F/FE/FL/FM 7 F/FL/N/NL 10/12/16 FH/FM/NH 9/10/12/13/ FH16	
	8140024	EXPANSION TANK LEVEL SENSOR	FH 12 / 16 FM 12	
	3962893	OIL PRESSURE SENSOR	FH/FM/NH 9/10/12/13/16	
	3944084	SWITCHES, POWER WINDOW	FH12 / FH16	


	OEM NO	DESCRIPTION	NOTES	
	3944085	SWITCHES, POWER WINDOW	FH12 / FH16	
	8157759	SWITCH	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16	
	8157753	SWITCH	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16	
	-	POTENTIOMETER FOR 21116877 NEW MODEL	FH12 / FH16 6 WIRES	
	-	POTENTIOMETER FOR 21116880 NEW MODEL	FH12 / FH16 5 WIRES	
	20504685 3985226	POTENTIOMETER FOR 20893503 OLD MODEL	FH12 / FH16 6 WIRES	
	-	POTENTIOMETER FOR 1063332 OLD MODEL	FH12 / FH16 5 WIRES	
	20583477 20498094 20720686	IMPULSE SENSOR	FH/FM/NH 9/10/12/13/ FH16	
	1624361	TEMPERATURE SENSOR	FH/FM/NH 9/10/12/13/ FH16	
	20796744 20898038	PRESSURE SENSOR	FH/FM/NH 9/10/12/13/ FH16	

	OEM NO	DESCRIPTION	NOTES	
	8144007 20375011	FUEL LEVEL SENSOR 640mm	FH/FM/NH 9/10/12/13/ FH16	
	8157761	SWITCH	FH/FM/NH 9/10/12/13/ FH16	
	3090483	LOCK CYLINDER KIT 1 CYL. / 2 KEY	FH12, FH16 FM10, FM12	
	3090484	LOCK CYLINDER KIT 2 CYL. / 2 KEY	FH12, FH16 FM10, FM12	
	20442878	WIPER MOTOR, For. windscreen wipers	FH/FM/NH 9/10/12/13/ FH16	
	8143408	WIPER MOTOR, For. windscreen wipers	FH/FM/NH 9/10/12/13/ FH16	
	1674918 3979764	EXPANSION TANK	FH Series FM Series	
	1674444	FAN SHROUD RUBBER	FH12 / FH16	
	1620067	CAB MOUNTING VALVE	F10 / F12 / F16 NL10 / NL12 / FL7 FL10 / FL12	
	-	EMBLEM F12	F12 CH.314000	

	OEM NO	DESCRIPTION	NOTES	
	1653070 1652760	COVER, RANGE CYLINDER	F10 / F12 / F12 FL6 / FL7 / FL10 NL10 / NL12 R/SR 1400/1700	
	1521247 1669419	RELAY VALVE, RANGE CYLINDER	FH12 / FH16 F10 / F12 / F16 FL7 / FL10	
	1521248	RELAY VALVE, RANGE CYLINDER	FM12,FH12,FH16,B12	
	1521249	COVER,SPLIT CYLINDER	FL7 / FL10	
	20590252 20366720 20514657 3192385	SOLENOID VALVE	FH / FM SERIES	
	20775173	RELAY VALVE FOR GEARBOX	FH / FM SERIES	
	3192384	COVER, RANGE CYLINDER	F/FL 6, F/FE/FL/FM 7 FH/FM/NH 9/10/12/13/ FH16	
	20411199 3165147	AIR VALVE EXHAUST BRAKE	FH12 / FH16 / NH12 FM12 / B12 D12C	
	20752914	SWITCH PANEL	FH SERIES	
	20752918	SWITCH PANEL	FH SERIES	

	OEM NO	DESCRIPTION	NOTES	
	20360898	HEADLAMP INSERT LHD / L	FH SERIES FM SERIES	
	20360899	HEADLAMP INSERT LHD / R	FH SERIES FM SERIES	
	20398660 20398481 20425468 20789440	SIDE MARKING LAMP	NH12,FM9,FM12,FH12, FH16	
	8141013	LAMP SUN VISOR	FM9,FM12,FH12,FH16	
	8144063	POSITION LAMP ORANGE	FH12 / FH16 FM7 / FM10 / FM12	
	8144064	POSITION LAMP WHITE	FH12 / FH16 FM7 / FM10 / FM12	
	20429696	SIDE MARKER LAMP	FH12 / FH16 FM7 / FM10 / FM12	
	20745225	SIDE MARKER LAMP	FL7 / FL10 / FL12	
	20398824	POSITION LAMP	FH12 / FH16 FM7 / FM10 / FM12	
	20425484	POSITION LAMP	FH12 / FH16 FM7 / FM10 / FM12	
	3093481	CONTROL VALVE	FH/FM/NH 9/10/12/13/ FH16	
	3093482	CONTROL VALVE	FH/FM/NH 9/10/12/13/ FH16	
	1677527	HOUSING,FUEL FILTER	FH12	

	OEM NO	DESCRIPTION	NOTES	
	20440371 20752310 20411997 3092460	FUEL PUMP, ENGINE Long shaft	FH12 / NH12 / FM12 FL12 / B12	
	20440372 20769469 3092459	FUEL PUMP, ENGINE Short shaft	FH12 / NH12 / FM12 FL12 / B12	
	20997341	FUEL PUMP, ENGINE	FH12 / FH16 / FM9 / FM10/ FM12	
	20517745	FAN	FH12	
	20397619K 85000022	VISCOUS FAN CLUTCH WITH BLOWER	FH12 / NH12	
	20397618K	VISCOUS FAN CLUTCH WITH BLOWER	FM9 / FM12	
	8149394	VISCOUS FAN CLUTCH WITH BLOWER	FH12 / FL7 / FL10	
	20805992	VISCOUS FAN CLUTCH	FM9 / FM12	
	8149921	VISCOUS FAN CLUTCH	FH16	
	20744939 20538845	WATER PUMP	FH12 440 / FH16 / FM / VN / VT	

	OEM NO	DESCRIPTION	NOTES	
	20707160	PULLEY, WATER PUMP	FM9, FM12, FM16, FH16	
	3161436	WATER PUMP (WITH PULLEY)	FM9, FM12, FM16, FH16	
	8131097	SEALING RING, WATER PUMP	FM9, FM12, FM16, FH16	
	20489341 8170473	COVER RUBBER	D12 C	
	20714247 20526706 8170452	COVER RUBBER	D12 C	
	20382506	BRAKE SWITCH	FH12-16	
	20360542	DOOR, Left	FH12 / FH16	
	20360543	DOOR, Right	FH12 / FH16	
	3176909	WIRE KIT	FH/FM/NH 9/10/12/13/ FH16	
	3176505	PEDAL	FH/FM/NH 9/10/12/13/ FH16	

	OEM NO	DESCRIPTION	NOTES	
	3176136	CONTROL CABLE STEERING	FH / FM / NH 9/10/12/13/16	
	1075357	SPRING, CABIN SHOCK ABSORBER	FH / FM SERIES	
	1075358	SPRING, CABIN SHOCK ABSORBER	FH / FM SERIES	
	1075355	SPRING, CABIN SHOCK ABSORBER	FH / FM SERIES	
	8158197	SPRING, CABIN SHOCK ABSORBER	FH / FM SERIES	
	20534645	AIR SPRING, BOGIE LIFT (LIFT-AXLE SHORT VERSION)	F10 / F12 FL10 / FL12 FM10 / FM12 FH12 / FH16	
	20534646	AIR SPRING, BOGIE LIFT (LIFT-AXLE LONG VERSION)	F10 / F12 FL10 / FL12 FM10 / FM12 FH12 / FH16	
	1081785 20494458 20455245	AIR SPRING, BOGIE LIFT (LIFT-AXLE)	F10 / F12 FL10 / FL12 FM10 / FM12 FH12 / FH16	
	3183210 1547209	VALVE SPRING	D12 A/B/C	
	3183211 1547210	VALVE SPRING	D12 A/B/C	


	OEM NO	DESCRIPTION	NOTES	
	1543870	VALVE SPRING	D16	
	1543871	VALVE SPRING	D16	
	1543872	VALVE SPRING	D16	
	20530916 276615	MAIN BERAING, STD	FH12 / D12 A/B	
	276616	MAIN BERAING, 0.25	FH12 / D12 A/B	
	276134	CONNECTING ROD BEARING, STD	FH12 / D12 A/B	
	276135	CONNECTING ROD BEARING, 0.25	FH12 / D12 A/B	
	3093651	THRUST WASHER SET STD.	FH12 / D12 A/B	
	20503200 276630	BEARING SET, CAMSHAFT	FH12 / D12 A/B	
	275699	PISTON AND LINER SET Ø 131 MM	FH12	

	OEM NO	DESCRIPTION	NOTES	
	20515059	PISTON AND LINER SET	FH12 / D12 C/D	
	276642	PISTON AND LINER SET 144,01 MM	F16 / TD163 ES	
	276906	PISTON AND LINER SET	FH16 / D16 A/B	
	3183227 1547810	VALVE SEAT IN STD.	FH12 / D12 A/B/C	
	3165369 1547583	VALVE SEAT EX STD	FH12 / D12 A/B/C	
	3183228 1547907	VALVE SEAT IN 0,20	FH12 / D12 A/B/C	
	3165397 1547913	VALVE SEAT EX 0,20	FH12 / D12 A/B/C	
	20904074	VALVA GUIDE IN-EX	D13A 400 / 440 / 480 520	
	20514654 20998367 20998346 20541383 20480593	PRIMARY FILTER	FH12 / FH16 / FM10 FM12	
	20879812 20788794 20745605	FUEL FILTER	FH12 / FH16 / FM10 FM12	
	20551483 1677516	RUBBER GASKET OIL COOLER	FH12 / FL12 / FM12 / B12 D12 ENGINE	

	OEM NO	DESCRIPTION	NOTES	
	1664689	BELT TENSIONER	F10 / F12	
	1664690	BELT TENSIONER	NL10 / NL12 / N10 / N12	
	1665312	RUBBER CUSHION (Radiator mounting)	D12 A/B FH12 / FH16	
	1665322	RUBBER CUSHION (Radiator mounting)	D12 A/B FH12 / FH16	
	1546718 276811	INJECTOR SLEEVE KIT	D12A / D12B FH12	
	85104134 3183368	INJECTOR SLEEVE KIT	D12 C / FH12	
	21098621	INJECTOR SLEEVE KIT	D12C / FH12	
	3092575	REPAIR KIT, SPLIT CYLINDER GEAR BOX	FH/FM/NH 9/10/12/13/ FH16	
	8148973	TURBOCHARGER	D12A / D12C / D12D	
	8148997 8148329	HAND PUMP	FH12 / NH12 / FM7 FM12	

	OEM NO	DESCRIPTION	NOTES	
	20366711	COVER, GEARBOX	FH 12 – FH 16	
	267813	LOCKING CYLINDER	FL/F12/F16/FL10	
	1653185	INHIBITOR CYLINDER	N10,F10,F12,FH12, FM10,FM7,FL7,FL10, FM12,FL12	
	1656239	GEARBOX CONTROL CYLINDER	F12/F16/ R1400	
	20365902	GEARBOX ROD	FH/FM/NH 9/10/12/13/ FH16	
	3191961	REPAIR KIT,COVER GEARBOX	VT2014,2214,2514	
	1652547	COVER	R1400,1700,SR1400, SR1700	
	20399362	ANCHORAGE, FRONT SPRING	FH12 / FH16 FM9 / FM10 / FM12	
	3095043	OIL SEAL, REAR WHEEL HUB	FH SERIES FM SERIES	
	3192069	OIL SEAL, DIFF.	90X151X10/15	


	OEM NO	DESCRIPTION	NOTES	
	3199066	OIL SEAL REAR WHELL HUB 141 x 153 x 5,5	Bus FH/FM/NH 9/10/12/13/ FH16	
	20399560	OIL SEAL REAR WHELL HUB 125*148,30*9,70	Bus FH/FM/NH 9/10/12/13/ FH16	
	8172031	RELEASE FORK (CLUTCH)	FH12 / FH16	
	3191966	RELEASE FORK (CLUTCH)	FH12 / FH16	
	20399428	CAP		
	-	PISTON,AIR BELLOWS	(FOR: 20456150 / 6605 N P01 S)	
	-	PISTON,AIR BELLOWS	(FOR: 20456152 / 6608 N P01 S)	
	-	PISTON,AIR BELLOWS	(FOR: 20456154 / 6606 N P01 S)	
	-	PISTON,AIR BELLOWS	(FOR: 20456156 / 6607 N P01 S)	
	3950209 8157021	PISTON, AIR BELLOWS	FL6, FL7, FL10, FL12 FH12, FH16	
	1599326	PLATE, AIR BELLOWS	F10, F12, FH12, FH16	



	OEM NO	DESCRIPTION	NOTES	
	465741 465728	CYLINDER HEAD	TD60	
	8194450	CYLINDER HEAD	TD101G	
	425559	CYLINDER HEAD	TD122	
	20712545	SEAL	D12 / A-C	
	8170116	VALVE COVER GASKET (PLASTIC)	D12 C / D FH12	
	20710235 85112559 21123014	VALVE COVER GASKET SET	D12 C / D FH12	
	20430678	GASKET, WATER PUMP	FH/FM/NH 9/10/12/13	
	3944186 8143448 1088588	SOLENOID VALVE	ALL MODELS VOLVO	
	3944716	SOLENOID VALVE	ALL MODELS VOLVO	
	3944717	SOLENOID VALVE	ALL MODELS VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	8159904	IGNITION SWITCH	FH12/FH13/FH16	
	1082209 1664812	COOLANT PIPE	Volvo F/FL/N/NL 10/12/16	
	8152116	COOLING PIPE	Volvo F/FL/N/NL 10/12/16	
	1665278	COOLING PIPE	Volvo F/FL/N/NL 10/12/16	
	20542213 3979793	RADIATOR HOSE	FM10 / FM12	
	20968686	HOSE	FH/ FM/ NH 9/10/12/13/16	
	20456429	COMPRESSOR HOSE	FH/ FM/ NH 9/10/12/13/16	
	20367063	COMPRESSOR HOSE	FH/ FM/ NH 9/10/12/13/16	
	8142555	COMPRESSOR AIR CONDITIONING Repl. Sanden: SD7834	FH/ FM/ NH 9/10/12/13/16	
	20538307	COMPRESSOR AIR CONDITIONING Repl. Sanden: SD8044	FH/ FM/ NH 9/10/12/13/16	

	OEM NO	DESCRIPTION	NOTES	
	3092710	BRAKE DISC 20.92710	FH12/FH16	
	20545966 21002866	CONTROL CABLE, GEAR SHIFT 2750mm	FH/FM/NH 9/10/12/13/ FH16	
	20545965 21343565	CONTROL CABLE, GEAR SHIFT 2650mm	FH/FM/NH 9/10/12/13/ FH16	
	20545955 21343555	CONTROL CABLE, GEAR SHIFT 2915mm	FH/FM/NH 9/10/12/13/ FH16	
	979973 1076178	HOSE ASSEMBLY 230mm	FH/FM/NH 9/10/12/13/ FH16	
	979927 1076189	HOSE 1200mm	FH/FM/NH 9/10/12/13/ FH16	
	978884 1076199	HOSE 1500mm	FH/FM/NH 9/10/12/13/ FH16	
	979928 1076205	HOSE 3200mm	FH/FM/NH 9/10/12/13/ FH16	
	20994420	STAY, CHASSIS HEIGHT 810mm 350mm	FH/FM/NH 9/10/12/13/ FH16	
	3987354	STAY, 435mm	FH/FM/NH 9/10/12/13/ FH16	

	OEM NO	DESCRIPTION	NOTES	
	1624093	BALL JOINT M 22x1,5; M 24x1,5; L = 85 mm; R	F/FL 6, F/FE/FL/FM 7 F/FL/N/NL 10/12/16	
	3091750	MIRROR BRACKET, L	FH/FM/NH 9/10/12/13/ FH16	
	3091751	MIRROR BRACKET, R	FH/FM/NH 9/10/12/13/ FH16	
	3979593 1676319	FILLER CAP EXPANSION TANK	FH/FM/NH 9/10/12/13/ FH16	
	20850557	LEVEL SENSOR	FH / FM	
	3097369 20546795 20773824 20424148	AIR DRYER CARTRIDGE (78964) HALDEX TYPE	FH SERIES FM SERIES	
	8172628 1672230	INHIBITOR VALVE	FH12 / FH16	
	20524936	CHARGE PRESSURE SENSOR	FH/ FM/ NH 9/10/12/13/16	
	1626372	CONTACT	F10 / F12 / F16 N10 / N12	
	1578121	CONTACT	F10 / F12 / F16 N10 / N12	

	OEM NO	DESCRIPTION	NOTES	
	3095840	GASKET SET, COMPRESSOR	FH12 / FM12 / NH12 B12	
	-	CYLINDER HEAD, COMPRESSOR	(PLAIN WITHOUT PLATE) LP4934/4949/4967/ LP4921	
	-	CYLINDER HEAD, COMPRESSOR	(PLAIN WITHOUT PLATE) LP4813	
	-	COVER, COMPRESSOR	(WITH BUSHING)	
	-	CRANKSHAFT, COMPRESSOR LP4949	B10	
	-	CRANKSHAFT, COMPRESSOR LP4918/ LP4934/4967/LK4921	B10M,B12BR,B10B, B10L	
	20701801	COMPRESSOR, TYPE: WABCO 412 704 008 0	FH12 / FH16 / FM12	
	-	GASKET SET, COMPRESSOR		
		VALVE SET, COMPRESSOR		
	-	GASKET SET, COMPRESSOR		


	OEM NO	DESCRIPTION	NOTES	
	85102273	REPAIR KIT, COMPRESSOR		
	-	REPAIR KIT, COMPRESSOR		
	-	VALVE SET, COMPRESSOR		
	-	CRANKSHAFT, COMPRESSOR		
	-	REPAIR KIT, COMPRESSOR	LK3802/3813	
	85104246	CYLINDER HEAD,COMPRESSOR	(WITH PLATE) ASSEMBLY	
	-	PLATE, COMPRESSOR ASSEMBLY		
	85104326	REPAIR KIT, COMPRESSOR	WABCO TYPE (FOR : 20568592)	
	-	CRANKSHAFT, COMPRESSOR		
	-	PLATE, COMPRESSOR ASSEMBLY		

	OEM NO	DESCRIPTION	NOTES	
	-	VALVE SET, COMPRESSOR		
	8113633	COMPRESSOR TYPE:LP4918	B10M	
	8113634	COMPRESSOR TYPE:LK4921		
	8113815	COMPRESSOR, TYPE:LP4919		
	3118286	COMPRESSOR TYPE:LP4949	B10	
	9521897	COMPRESSOR TYPE:LP4968		
	8129779	COMPRESSOR TYPE: LP4850	B10,FL6,FL7,FL10, FM10	
	20845313	COMPRESSOR	TYPE: WABCO 412 704 015 0	
	20382348	COMPRESSOR	TYPE: WABCO 412 352 005 0	
	-	REPAIR KIT, COMPRESSOR		

	OEM NO	DESCRIPTION	NOTES	
	20569226	CYLINDER HEAD, COMPRESSOR	(WITH PLATE) ASSEMBLY	
	20569930	CYLINDER HEAD, COMPRESSOR	(WITH PLATE) ASSEMBLY	
	8170446	GEAR, COMPRESSOR	FH12,NH12,FM12	
	-	BRACKET SET, SUN VISOR	FH12,FH16,FM12,FM16	
	8152497	BRACKET,FRONT	FL10/12	
	8152498	BRACKET L	FL10/12	
	8152498	BRACKET, R	FL10/12	
	20453676	SPACER L	FH12,FH16,FM12,FM16	
	20453677	SPACER R	FH12,FH16,FM12,FM16	
	20456480	AIR INLET,UPPER	FH12 / FH16	

	OEM NO	DESCRIPTION	NOTES	
	1063291	WINDOW REGULATOR L	FH12 / FH16	
	1063292	WINDOW REGULATOR R	FH12 / FH16	
	20467387	PROTECTING PLATE LAMP BAKALITE L	FM9,FM12,FH12,FH16	
	20467388	PROTECTING PLATE LAMP BAKALITE R	FM9,FM12,FH12,FH16	
	1072473	LOCK CYLINDER, L		
	1072475	LOCK CYLINDER, R		
	1075469	PLUG	FH/FM SERIES	
	3175545	CAP	FH12,FM9,FM12	
	3175546	CAP	FH12,FM9,FM12	
	3175547	CAP	FH12,FM9,FM12	

	OEM NO	DESCRIPTION	NOTES	
	3175548	CAP	FH12,FM9,FM12	
	1076745	MOUTING,FRONT CAB L	FH / FM SERIES	
	1076746	MOUTING,FRONT CAB R	FH / FM SERIES	
	8141064	EMBLEM	FH12 / FH16	
	20360285	EMBLEM	FH Series	
	20360284	EMBLEM	FH Series	
	20360283	EMBLEM	FH Series	
	20360282	EMBLEM	FH Series	
	8144101	EMBLEM	FH Series	
	8144325	EMBLEM	FH Series	

	OEM NO	DESCRIPTION	NOTES	
	3981596	ADJUSTING HOUSING	FH/FM/NH 9/10/12/13/ FH16	
	8140141	LAMP INSERT BRACKET	FH/FM/NH 9/10/12/13/ FH16 FL6/7/10/12	
	8156886 8156887	SAFETY NET FOR HEADLAMP L&R	FH12 / FH16	
	20455981	MAIN MIRROR, LH	FH SERIES 2.Version 2005-	
	20455982	MAIN MIRROR, RH	FH SERIES 2.Version 2005-	
	20379428 20710524	GLASS, HEADLAMP L	FH 12 / 16 NEW FM 9 / 12 NEW MODEL	
	20379429 20710525	GLASS, HEADLAMP R	FH 12 / 16 NEW FM 9 / 12 NEW MODEL	
	20398387	HOUSING HEAD LAMP L	FM7 / FM10 / FM12	
	20398388	HOUSING HEAD LAMP R	FM7 / FM10 / FM12	
	1062133	FOOT STEP L	FM7 / FM10 / FM12 / FM16	

	OEM NO	DESCRIPTION	NOTES	
	1062134	FOOT STEP R	FM7 / FM10 / FM12 / FM16	
	3175158	FOOT STEP MUDGUARD L	FM7 / FM10 / FM12 / FM16	
	3175159	FOOT STEP MUDGUARD R	FM7 / FM10 / FM12 / FM16	
	8191409	CORNER PANEL L	FM7 / FM10 / FM12 / FM16	
	8191412	CORNER PANEL R	FM7 / FM10 / FM12 / FM16	
	8191406	GRILLE	FM7 / FM10 / FM12 / FM16	
	8191421	UPPER GRILLE STEEL	FM7 / FM10 / FM12 / FM16	
	20398707	CORNER BUMPER STEEL / LH	FH 12 / FH16 2.VERSION	
	20398708	CORNER BUMPER STEEL / RH	FH 12 / FH16 2.VERSION	
	20398709	CENTRE BUMPER STEEL	FH 12 / FH16 2.VERSION	

	OEM NO	DESCRIPTION	NOTES	
	3175376	UPPER GRILLE	FM SERIES 2.VERSION	
	20379171	CORNER PANEL L	FM SERIES 2.VERSION	
	20379172	CORNER PANEL R	FM SERIES 2.VERSION	
	20529478	FOOT STEP MUDGUARD L	FM SERIES 2.VERSION	
	20529483	FOOT STEP MUDGUARD R	FM SERIES 2.VERSION	
	20529765	COVER FOOTSTEP	FM SERIES 2.VERSION	
	20900679	MIRROR COMPLETE LOW CABIN	FH / FM SERIES	
	20900682	MIRROR COMPLETE HIGH CABIN	FH / FM SERIES	
	-	MIRROR COMPLETE FRONT VISION	FH12 / FH16	
	3173291 20556490	V-STAY	FH12 / FH16 / FH13 FM10 / FM12	

	OEM NO	DESCRIPTION	NOTES	
	1628154	REACTION ROD	FH12 / FH16 / FH13 FM10 / FM12	
	8147151	REACTION ROD 620mm	FH12 / FH16 / FH13 FM10 / FM12	
	20399146	REDUCING VALVE	VOLVO BUS	
	8112337 1082030	AIR DRYER	FH12 / FH16 / FH13 FM10 / FM12	
	8148327	VALVE, FUEL PUMP	FH12	
	3192533	GEAR POSITION DETENT	FH12 / FH16 / FH13 FM10 / FM12	
	20806212 3191967	BEARING	VT / 2014 – 2214 VT / 2412 – 2514 VT – VTO / 2814 B	
	20513343	SENSOR	FH12 / FH16 / FH13 FM10 / FM12	
	1547049 3095060	STARTER MOTOR	F/FL/N/NL 10/12/16 FH/FM/NH 9/10/12/13/ FH16	
	3986429 8156817	ALTERNATOR 24V / 80A	F/FL/N/NL 10/12/16 FH/FM/NH 9/10/12/13/ FH16	

	OEM NO	DESCRIPTION	NOTES	
	1089862	ALTERNATOR 24V / 80A	Bus F/FL 6, F/FE/FL/FM 7 F/FL/N/NL 10/12/16	
	20409228	ALTERNATOR 24V / 110A	FH/FM/NH 9/10/12/13/ FH16	
	1594228	TEMPERATURE SENSOR	F/FL 6, F/FE/FL/FM 7 F/FL/N/NL 10/12/16 FH/FM/NH 9/10/12/13/ FH16	
	3987417	DOOR SWITCH	F/FL 6, F/FE/FL/FM 7 F/FL/N/NL 10/12/16 FH/FM/NH 9/10/12/13/ FH16	
	3944080	RETURN SWITCH	F/FL 6, F/FE/FL/FM 7 F/FL/N/NL 10/12/16 FH/FM/NH 9/10/12/13/ FH16	
	20565103 21063887 20892367	STOP / TAIL LAMP L	FL6, FM9, FM12, NH12 FH12, FH16 NEW MODELS	
	20565104 21063895 20892368	STOP / TAIL LAMP R	FL6, FM9, FM12, NH12 FH12, FH16 NEW MODELS	
	20565107	LENS, STOP/TAIL LAMP L - R	FL6, FM9, FM12, NH12 FH12, FH16 NEW MODELS	
	3154315 8149798 1664973	BELT TENSIONER	FH 12 / FH 16 FM12	
	3154314 1675318	PULLEY, BELT TENSIONER	FH 12 / FH 16 FM12	

	OEM NO	DESCRIPTION	NOTES	
	3979980 8149879	BELT TENSIONER	FH12 / FM10 / FM12 NH12	
	8149855	BELT TENSIONER	FH12 / FH16 FM9 / FM10	
	20491753	BELT TENSIONER	FH / FH16 VHD / VN / VT	
	20503093	DEFLECTION PULLEY	FH / FH16 VHD / VN / VT	
	20487079	BELT TENSIONER	FH / FM	
	3183644	PULLEY, BELT TENSIONER	B6 / B7 / B12 FL7 / FL10 / NL10	
	8150556 1080442	EXPANSION TANK	F10 / F12 Ch. 314000	
	1660219 8152259	EXPANSION TANK	FL10 / FL12	
	1622085 1599459	SHOCK ABSORBER, CAB / FRONT-REAR	F10,F12, F10,F12 ch.314000	
	1622086 (1585586)	SHOCK ABSORBER, CAB / FRONT	F10,F12, F10,F12 ch.314000	

	OEM NO	DESCRIPTION	NOTES	
	1580389	SHOCK ABSORBER, CAB / REAR	F10,F12, F10,F12 ch.314000	
	1505185 1608888 1590167 1591736	SHOCK ABSORBER, FRONT	F10,F12, F10,F12 ch.314000	
	1591501 (1598510) (1610919) (1505190)	SHOCK ABSORBER, REAR / FRONT	F10,F12, F10,F12 ch.314000	
	1591735 (1505184) (1590161)	SHOCK ABSORBER, REAR / FRONT	F10,F12, F10,F12 ch.314000	
	1629721 3172986 1076860	SHOCK ABSORBER CAB / REAR	FH12 , FH16	
	1629722	SHOCK ABSORBER CAB / FRONT	FH12 , FH16	
	3986315 1622227 3198849	SHOCK ABSORBER CAB / REAR	FH12 , FH16	
	3172984 1629724 1629719	SHOCK ABSORBER, CAB / FRONT	FH 12 / FH 16	
	3172985 20427897 20721169 1076855	SHOCK ABSORBER, CAB / REAR	FH 12 / FH 16 FM12	
	1075076 1075077	SHOCK ABSORBER, CAB / REAR	FH 12 / FH 16	

	OEM NO	DESCRIPTION	NOTES	
	3198836 3092136 21111925	SHOCK ABSORBER, CAB / FRONT	FH12 / FH16 2.Version	
	20721166 3198859 21137458 20960913 1075445	SHOCK ABSORBER, CAB / REAR	FH12 / FH16 2.Version	
	1089008	SHOCK ABSORBER, CAB / FRONT	FL7 / FL10 / FL12	
	1075478	SHOCK ABSORBER, CAB / FRONT	FM7 / FM10 / FM12	
	1081785 20494458 20455245	AIR SPRING, BOGIE LIFT	F10 / F12 FL10 / FL12 FM10 / FM12 FH12 / FH16	
	20374545 1629478 3987957 1076717	SHOCK ABSORBER FRONT WHEEL	FH 12 / 16 FM 7 / 9 FM 10 / 12 NH 12	
	1629482	SHOCK ABSORBER REAR WHEEL	FH 12 / 16 FM 7 / 9 FM 10 / 12 NH 12	
	1629405	SHOCK ABSORBER REAR WHEEL (6 X 4)	FH12 / FH16 2.Version	
	20367750	SHOCK ABSORBER REAR WHEEL (4 X 2)	FH12 / FH16 2.Version	
	1655853	HANDLE	SR 1400 / 1700 FH12, FH16, NH12 FL10, F10, F12 NL10, NL12	

	OEM NO	DESCRIPTION	NOTES	
	1655854	HANDLE	F10 / F12 FL 7 / FL10 NL10 / NL12	
	20488052 1521394 1655855 3192255	HANDLE	FH12/FH16/NH12 FL7/FL10/FL12 NL10/NL12/F10/F12 FM7/FM10/FM12	
	20488063 20493844 3192261 1673299	HANDLE	FH12/NH12/F10/ F12/FL7/FL10/ N10/N12	
	20488061 3192943	HANDLE	NEW MODELS	
	1655981	HANDLE	N10/N12/NL10/12 ZF GEARBOX	
	1526965 1526469	HANDLE	F10 / F12	
	382422	HANDLE GEAR LEVER BODY COVER LEVER 382422+1130383	N86, N88, F86, F87, F88, G88, F89, G89, F6S, F7, F10 ch.-25000, F12 ch.- 34000, N7 ch.-12000, N10 ch.-12000, N10 ch.- 49000, N10 USA, N12 ch.- 12000	
	- 382422 1130383 267345	HANDLE GEAR LEVER BODY COVER LEVER COMPLETE	N86, N88, F86, F87, F88, G88, F89, G89, F6S, F7, F10 ch.-25000, F12 ch.- 34000, N7 ch.-12000, N10 ch.-12000, N10 ch.- 49000, N10 USA, N12 ch.- 12000	
	267345	LEVER, HANDLE	For: 27.2422	
	273851 276829	REPAIR KIT, HANDLE	NEW MODELS	


	OEM NO	DESCRIPTION	NOTES	
	1572197	SPRING, ACCELERATOR LINKAGE	F7, FE7, FS7, F10, FS10, F12, F16, N7 ch.-12000, N10 ch.- 49000, N10 ch.306000-, N10 USA, NL10 AUS, N12 ch.306000-, N12 USA, NL12 AUS, B6, B7 ch.20000-, B7 ch.30000-	
	1620462 1669488 1581209 1614351	CLUTCH MASTER CYLINDER	FL7, F10, FL10, F12, N7, N10 N12, B58, B10R	
	273660	REPAIR KIT,CLUTCH MASTER CYLINDER	FL7, F10, FL10, F12, N7, N10 N12, B58, B10R	
	271106 276834	REPAIR KIT,CLUTCH MASTER CYLINDER	FL7, F10, FL10, F12, F16, N7, N10, NL10 NL10S, N12, NL12 AUS, NL12BR, NL12S	
	3094523 3094730 276833 276635	REPAIR KIT, CLUTCH MASTER CYLINDER	FH 12 / FH 16 NEW MODEL	
	276546	REPAIR KIT, CLUTCH MASTER CYLINDER	F88, FB88, G88, F89, G89, N7 ch.-6567, N7 AUS ch.-530095, N10 ch.-21719, N12 ch.- 3232	
	1628218	CLUTCH MASTER CYLINDER	FH 12 / FH 16 NEW MODEL	
	8172824 20553587 20835246	CLUTCH MASTER CYLINDER	FM9, FM12, FH12,16	
	1655639 1673067 1526523 267321	CLUTCH SERVO	F86, FB86, F87, F89, G89, F6S, FE6, FL608-615, FL616-619, F7, FE7, FL7, FS7, F10, FL10, F12*, N7, N10, N10BR, NL10 AUS, NL10BR, NL10S, N12, N12BR, N12 AUS, NL12BR, NL12S, B57, BB57, B58, B6, B7 ch.- 29999, B7F, B7FA, B9M**, B10M**, B10R, C10M * not for single disc	
	1655435 1668501 1521371	CLUTCH SERVO	FH12 / FH16	

	OEM NO	DESCRIPTION	NOTES	
	1671953	CLUTCH SERVO	FH12 / FH16	
	8171720	CLUTCH SERVO	FH SERIES FM SERIES NH SERIES	
	8171721	CLUTCH SERVO	FH SERIES FM SERIES NH SERIES	
	8171700	CLUTCH SERVO	FH SERIES FM SERIES NH SERIES	
	20524584 1672129	CLUTCH SERVO	FH SERIES FM SERIES NH SERIES	
	20524585	CLUTCH SERVO	FH SERIES FM SERIES NH SERIES	
	1527474 267143	CLUTCH GF2/350	F7, F10, F86, FB86, F88, G88, N7, N10, B9M, B10M, C10M; Gearbox:R61, SR61, R62, SR62, ZF	
	364239	CLUTCH G380	F10, F12, F86, FB86, F88, G88, F89, FB89, G89, N10, N12; Gearbox:R/SR61, MR61, MR61B, MR62, R/SR62, R/SR70, SR71	
	267181	CLUTCH Ø 380mm	F7, F10, F86, FB86, F88, G88, N7, N10, B9M, B10M, C10M; Gearbox:R61, SR61, R62, SR62, ZF	
	267171	CLUTCH GMF420K	F10, N10 Gearbox:R62, SR62	

	OEM NO	DESCRIPTION	NOTES	
	1655741	CLUTCH Ø 350mm	FL10 / FL12	
	1655899	CLUTCH Ø 380mm	NL10 / NL12 F12ch.314000	
	1669144	CLUTCH Ø 380mm	NL10 / NL12 FH12	
	1669137	CLUTCH Ø 400mm	F16 / FH16	
	1668616	CLUTCH MFZ430	FL7, FE7, F10, FL10, N10, NL10S, B6-12; Gearbox:R/SR1400/ 1700	
	1668919	CLUTCH MFZ430	F12, FH12, FL12 Gearbox:R/SR1400 1700 / 1900	
	346319	CLUTCH G420	F88, F89	
	1655648 (1526046) 1668372 8112108 1527523 267236	CLUTCH PLATE 350GSZ	F7, N7, F10, N10, FL10, N12, F12; Gearbox:R62, SR62, R70, SR70, SR71, MR62, R1400, R1700, SR1400, SR1700	
	1655649 (267237) 1668373 8112109 1527524	CLUTCH PLATE 350GSZ	F7, N7, F10, N10, FL10, N12, F12; Gearbox:R62, SR62, R70, SR70, SR71, MR62, R1400, R1700, SR1400, SR1700	
	-	EMBLEM TURBO	F12 CH.314000	






	OEM NO	DESCRIPTION	NOTES	
	1524768 1668618	CLUTCH PLATE 430WGTZ	F10, FL10, N10, NL10S, B6-12 Gearbox:R/SR1400/ 1700 FH12 / FH16 / FM10	
	1668983	CLUTCH PLATE 430WGTZ	F12, FH12, FL12 Gearbox:R/SR1400/ 1700/1900 FH12 / FH16 / FM10	
	1669138	CLUTCH PLATE 400mm	F16 / FH16	
	1669139	CLUTCH PLATE 400mm	F16 / FH16	
	1521717 8171496	CLUTCH PLATE 400mm	FH / FM SERIES	
	1521726 8171497	CLUTCH PLATE 400mm	FH / FM SERIES	
	20366591	CLUTCH PLATE 400mm	FH / FM SERIES	
	20366592	CLUTCH PLATE 400mm	FH / FM SERIES	
	1655678	CLUTCH PLATE 430mm	F10 / N10 / FL10	
	1521716 8172402	CLUTCH PLATE 430mm	FH / FM SERIES	
	8172802 3191766	CLUTCH PLATE 430mm	FH / FM SERIES	
	8172803 3191767	CLUTCH PLATE 430mm	FH / FM SERIES	


	OEM NO	DESCRIPTION	NOTES	
	1668369 1655334	CLUTCH PLATE 380GSZ	F12, N12 ch.306000- NL12S; Gearbox:R1400/1700, SR1400/1700	
	1668370 1655335	CLUTCH PLATE 380GSZ	F7, N7, F10, N10, FL10, N12, F12 SR62, SR70, R1400, R1700, SR1400, SR1700	
	1655686	CLUTCH PLATE 380GSZ	F12 ch.51894-,N12 ch.306000-; Gearbox:R70, SR70, SR71	
	1655687 (1526199)	CLUTCH PLATE 380GSZ	F12 ch.-57893, N12 ch.12001-, F12 ch.51894- N12 ch.306000-; Gearbox:R70, SR70, SR71	
	3018128 (1526214) (267161)	CLUTCH PLATE 420GSZ	F88, FB88, G88, N88, NB88, F89, FB89, G89, B10M, B58, N10; Gearbox:R61, SR61, ZF, S-6	
	1667931 (267221)	CLUTCH PLATE 420GSZ	F10, N10 Gearbox:R62, SR62	
	1669141	CLUTCH PLATE 380mm	NL 10 / 12 FM 10 / 12	
	1669142	CLUTCH PLATE 380mm	NL 10 / 12 FM 10 / 12	
	1653156	VALVE, CLUTCH CONTROL	FH12 / FH16 / NH12	
	1594138 8150500	KM SENSOR	SR1400/1700/1900	


	OEM NO	DESCRIPTION	NOTES	
	3171490 1077500 3962959	KM SENSOR	NEW MODELS	
	8143017 3962640	SOLENOID VALVE	F10, FL10, FS10, F12, FH12, FL12, F16, FH16, N10, N12,NL12,B10	
	1078316	SOLENOID VALVE	VOLVO	
	1610566	SOLENOID VALVE	VOLVO	
	1610568	SOLENOID VALVE	VOLVO	
	1610570	SOLENOID VALVE	VOLVO	
	8158342	SOLENOID VALVE	VOLVO	
	4774354	TURBOCHARGER	TD 60	
	4880539	TURBOCHARGER	TD 70	
	468962	TURBOCHARGER (12 X 12)	F10 / F12 TD120G	

	OEM NO	DESCRIPTION	NOTES	
	468931 468932	TURBOCHARGER (12 X 16)	F12 TD120 C/D/F	
	422856 422934	TURBOCHARGER	FL10	
	8148873 3165219	TURBOCHARGER	FH12 / FH16 / FM12 NH12	
	1695978 1698199	TURBINE HOUSING, TURBOCHARGER	FL10	
	-	TURBINE HOUSING, TURBOCHARGER	FH12	
	1080437 (1612335) (1590264) (1570994)	COMPRESSOR TYPE: BENDIX KZ 433/1/5 15,5	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	1695153 (3090472) (1518374)	CYLINDER HEAD, COMPRESSOR	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	1518372	PLATE, COMPRESSOR OLD VERSION (10HOLES)	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3090473	PLATE, COMPRESSOR NEW VERSION (11HOLES)	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3090239 (1696200)	COVER, COMPRESSOR WITH BUSHING	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	




	OEM NO	DESCRIPTION	NOTES	
	1518350	BUSHING, COVER	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	1518353	CRANKSHAFT, COMPRESSOR	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3090257 (1518356)	CONNECTING ROD, COMPRESSOR	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3094155 (272896)	PISTON RING SET 75MM STD.	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3094156 (270613)	PISTON RING SET 75MM 0,10	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3094157 (270614)	PISTON RING SET 75MM 0,20	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3094151 (1697706) (1518358)	PISTON 75MM STD. (WITHOUT RINGS)	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3094152 (1697707) (1518359)	PISTON 75MM 0,10 (WITHOUT RINGS)	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3094153 (1697708) (1518360)	PISTON 75MM 0,20 (WITHOUT RINGS)	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	-	GASKET SET, COMPRESSOR	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	

	OEM NO	DESCRIPTION	NOTES	
	270698	REPAIR KIT, COMPRESSOR (2 VALVES)OLD VERSION	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	3090471	REPAIR KIT, COMPRESSOR (4 VALVES)NEW VERSION	FL7, F10, FL10, F12, F16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B58, B59, B9M, B10M, C10M	
	328752 272560	PISTON RING SET 63,5MM STD.	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	328753 272561	PISTON RING SET 63,5MM 0,10	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	328754 272562	PISTON RING SET 63,5MM 0,20	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	1697477 352499	PISTON 63,5MM STD. (WITHOUT RINGS)	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	1697478 352500	PISTON 63,5MM 0,10 (WITHOUT RINGS)	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	1697479 352501	PISTON 63,5MM 0,20 (WITHOUT RINGS)	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	272813	REPAIR KIT, COMPRESSOR COMPR. TYPE: BENDIX TUFLO 500,TUFLO 700	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	272878	REPAIR KIT, COMPRESSOR COMPR. TYPE: BENDIX TUFLO 501	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	

	OEM NO	DESCRIPTION	NOTES	
	-	GASKET SET, COMPRESSOR FOR: TUFLO500,700	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	-	GASKET SET, COMPRESSOR FOR: TUFLO501	F86, FB86, F87, F88, FB88, G88, F89, G89, F6, F6S, F7, FL7, F10, FL10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B6, B7F	
	1626060	COMPRESSOR Type : WABCO 704	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	- 1698680 1699412	CYLINDER HEAD, COMPRESSOR ASSEMBLY For : 91.26060	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	1698674	COVER, COMPRESSOR WITH BUSHING	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	-	BUSHING, COVER	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	1698678	CONNECTING ROD, COMPRESSOR	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	1698670	CRANKSHAFT, COMPRESSOR	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	3094621	PISTON RING SET 85MM STD. (2X1698687+1X1698688)	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	-	PISTON RING SET 85MM 0,10	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	

	OEM NO	DESCRIPTION	NOTES	
	-	PISTON RING SET 85MM 0,20	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	1698686	PISTON 85MM STD. (WITHOUT RINGS)	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	-	PISTON 85MM 0,10 (WITHOUT RINGS)	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	-	PISTON 85MM 0,20 (WITHOUT RINGS)	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	- 1698683 1698681	VALVE SET, COMPRESSOR 2XDELIVERY VALVE 2XINLET VALVE	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	276183	GASKET SET, COMPRESSOR	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	-	REPAIR KIT, COMPRESSOR 1X91.6183 1X91.00120	F7, FL7, F10, Ch.314000- FL10, F12, Ch.314000- F16, N10, N12 Type: Wabco West 704	
	1599999	COMPRESSOR	Type : LP 4812	
	1613632	COMPRESSOR	Type : LP 4813	
	8150407	COMPRESSOR	Type : LP 4825 FL 7 / FL10 / FL 12 F10 / Ch.314000 F12 / Ch.314000 F16 / N10 / N12	



	OEM NO	DESCRIPTION	NOTES	
	1697771	CYLINDER HEAD, COMPRESSOR	F10, F12, FL6, FL7, FL10 For : LP4812	
	1698156	CYLINDER HEAD, COMPRESSOR	F16, FL6, B10, B6, B7 FL10, FL7,B12 For : LP4813	
	3090378	CYLINDER HEAD, COMPRESSOR	F10, F12 ch.314000- FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	
	1697770	PLATE, COMPRESSOR ASSEMBLE	LP4812 LP4813 LP4814 LP4815	
	3090380	VALVE PLATE, COMPRESSOR	F10, F12 ch.314000- FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	
	3090385 1697769	COVER, COMPRESSOR WITH BUSHING	LP4812 LP4813 LP4825	
	1697278 (1697286)	COVER BUSHING, COMPRESSOR	LP4812 LP4813 LP4825	
	1697285	CRANKSHAFT, COMPRESSOR Type : LP 4825	LP4812 LP4813 LP4825	
	3090386 1697281 1698528	CONNECTING ROD, COMPRESSOR Type : LP 4825	LP4812 LP4813 LP4825	
	-	VALVE SET, COMPRESSOR 1697290 INLET VALVE X 2 1698203 SPRING X 2 - VALVE X 1	LP4812 LP4813 LP4814 LP4815	

	OEM NO	DESCRIPTION	NOTES	
	-	GASKET SET, COMPRESSOR 1697288 GASKET X 1 1658528 GASKET X 1 1697277 GASKET X 2 1697093 ORING X 1	LP4812 LP4813 LP4814 LP4815	
	270879	REPAIR KIT, COMPRESSOR	LP4812 LP4813 LP4814 LP4815	
	3090388	PISTON RING SET 75MM STD. 2X1697284 1X1697283	LP4825 - LP4812 LP4813 LP4814 LP4815	
	-	PISTON RING SET 75MM 0,10 2X1698152 1X1698154	LP4825 - LP4812 LP4813 LP4814 LP4815	
	-	PISTON RING SET 75MM 0,20 2X1698153 1X1698155	LP4825 - LP4812 LP4813 LP4814 LP4815	
	1697282	PISTON 75MM STD.	LP4825 - LP4812 LP4813 LP4814 LP4815	
	-	PISTON 75MM 0,10	LP4825 - LP4812 LP4813 LP4814 LP4815	
	1698150	PISTON 75MM 0,20	LP4825 - LP4812 LP4813 LP4814 LP4815	
	3091740	INLET VALVE, COMPRESSOR	F10, F12 ch.314000- FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	
	3091591	INLET VALVE, COMPRESSOR	F10, F12 ch.314000- FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	

	OEM NO	DESCRIPTION	NOTES	
	3097147	REPAIR KIT, WITH PISTONS COMPRESSOR	F10, F12 ch.314000-FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	
	3090379	REPAIR KIT, INLET VALVE COMPRESSOR (3090379+3097147)	F10, F12 ch.314000-FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	
	-	REPAIR KIT, COMPRESSOR	F10, F12 ch.314000-FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	
	3090377	GASKET SET, COMPRESSOR	F10, F12 ch.314000-FL10, F16, NL10, NL12 Type: Knor LP4825 (II159993)	
	3987602 1628593 20429339	COMPRESSOR Type : LP 4974/ 4930	FH 12/ FH16 FM10/ FM12 NH12	
	8113023 9521675	COMPRESSOR Type : LP 4967	FH 12/ FH16 B10 / B12	
	3037346	COMPRESSOR Type : LP 4934	B10, B12	
	3173001	COMPRESSOR Type : LP 4985	NH12, FH12, FM12 FH16, FL12, FM7	
	1699820	CYLINDER HEAD, COMPRESSOR	FH12, FH16, NH12, B12 For: LP4930/4974	
	3097144	CYLINDER HEAD, COMPRESSOR	B10, B12 For: LP4934/4949/4967	

	OEM NO	DESCRIPTION	NOTES	
	3095847	CYLINDER HEAD, COMPRESSOR	FH12, FH16, FM12, B12, FM7, FL12, NH12 For: LP4985	
	3097146	PLATE, COMPRESSOR ASSEMBLY	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	-	CRANKSHAFT, COMPRESSOR Type : LP4930/4974/4985	FH 12 / FH16 FM7 / FM10/ FM12 NH12 / B12	
	-	CRANKSHAFT, COMPRESSOR Type : LP4934/4967	B10 / B12	
	3097151	CONNECTING ROD, COMPRESSOR Type : LP 49..	FH 12 / FH16 FM7 / FM10/ FM12 NH12 / B12	
	3097149	COVER, COMPRESSOR Type : LP 49..	FH 12 / FH16 FM7 / FM10/ FM12 NH12 / B12	
	3097148	BUSHING COVER, COMPRESSOR	LP4930 LP4934 LP4967	
	3097153	PISTON RING SET, COMPRESSOR 88mm STD	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	-	PISTON RING SET, COMPRESSOR 88mm 0,10	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	-	PISTON RING SET, COMPRESSOR 88mm 0,20	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	


	OEM NO	DESCRIPTION	NOTES	
	1698848	PISTON 88MM STD.	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	-	PISTON 88MM 0,10	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	-	PISTON 88MM 0,20	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	3097145	REPAIR KIT, INLET VALVE COMPRESSOR	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	3091739	VALVE KIT, COMRESSOR For: 49..	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	3091718	VALVE KIT, COMRESSOR For: 49..	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	3097147	REPAIR KIT, WITH COMPRESSOR	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	-	REPAIR KIT, COMPRESSOR	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	3097143	GASKET SET, COMPRESSOR	Compr. Type: Knorr LP4930 / FH12, FH16, B12 ch.5000- Compr. Type: Knorr LP4934 / B10, B12	
	85100626	PISTON RING SET, COMPRESSOR 88mmSTD	Compr. Type: Knorr LK39	

	OEM NO	DESCRIPTION	NOTES	
	276117 276119	REPAIR KIT, COMPRESSOR (276117+276119)	Compr. Orig. Ref. 6795600 / Compr. Type: Knorr LK3802, LK3813 / (one cylinder type) FL6, FS7	
	20569224	REPAIR KIT, COMPRESSOR (85mm Twin)	FH12 / FH16	
	-	REPAIR KIT, COMPRESSOR (Single Cylinder)	FH12 / FH16 / FM9 FM12 / NH12	
	-	VALVE SET, COMPRESSOR (Single Cylinder)	FH12 / FH16 / FM9 FM12 / NH12	
	8113829	REPAIR KIT, COMPRESSOR (Single Cylinder)	FL6	
	-	REPAIR KIT, COMPRESSOR	LP49 (Single Cylinder)	
	3131133	REPAIR KIT, COMPRESSOR	LP3970 (Single Cylinder)	
	-	REPAIR KIT, COMPRESSOR	FH SERIES (Single Cylinder)	
	364642	STEERING PUMP Type: ZF No: 7673 955 139 100 bar	F10,N10,N12	
	1587787	STEERING PUMP Type: ZF No: 7673 955 213 120 bar	F10,N10,N12 ch.306000	

	OEM NO	DESCRIPTION	NOTES	
	1587788 1591098	STEERING PUMP Type: ZF No: 7673 955 219 120 bar	F10,N10, N12 ch.306000-	
	1589231 1610367	STEERING PUMP Type: ZF No: 7673 955 225 135 bar	F10, F12, F16, FL10	
	1585013	STEERING PUMP Type: ZF No: 7673 955 211 135 bar	F10 , N10, N12 ch.306000	
	1589925	STEERING PUMP	ZF No: 7673 955 202	
	3172499	STEERING PUMP TYPE : LUK	FL6 / FL7 / FS7	
	1082959 3172199	STEERING PUMP TYPE : LUK	FL10	
	3172490 8113282	STEERING PUMP TYPE : LUK	FH12 / B12	
	1628208 3172193 8112593 8113268	STEERING PUMP TYPE : LUK	FH12 / B12	
	3172197 8159831	STEERING PUMP TYPE : LUK	FH12 / FL12 / NH12	
	367847 (366126)	UNIVERSAL JOINT	F89, G89, F10 ch.- 313999, F12 ch.- 313999, N7, N10, N12 ch.-305999, B9M, B10M, B10R, B58	

	OEM NO	DESCRIPTION	NOTES	
	1606502 (8189503) 1606501	UNIVERSAL JOINT	FL7, FL10, F10, F12, N10 ch.49001-, N12, B9M, B10M	
	3090267 (271141) (270911) (276015) (276024) (276030) (276032)	KING PIN SET	F86, F87, F88, F89, G89, N86, N7, N10, N12, B57, B58, B59, F6S, F7, FL7, F10, FL10, FS10, F12, FL12, F16, NL10 AUS, NL12 AUS, B9M, B10M	
	3090266 (271142) (270912) (276023) (276031)	KING PIN SET	FL618-619, F7, FL7, FS7, F10, FL10, F12, FH12, FL12, F16, FH16, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B9M, B10M, C10M, B12	
	276029 276014	KING PIN KIT	N7 / N10 / N12 / B57/ B58 / B59 / F88 / F89	
	276193	KING PIN KIT	FL6 / FE6 / FE7USA B6 / B7	
	85108338	KING PIN KIT	FL6 / FH12 / FH16 FM12 / FM16	
	3093731	KING PIN KIT	FM7 / FM9 / FM10 FM12 / FH12 / FH16 NH12 / B7 / B9 / B12	
	20751021	KING PIN KIT	FL6 / FH SERIES FM SERIES B7 / B9 / B12	
	270549	REPAIR KIT, TILT CYLINDER	F10, F12, F16, FL10	
	273656	REPAIR KIT, HYDRAULIC PUMP	F10, F12, F16, FL10	






	OEM NO	DESCRIPTION	NOTES	
	274103	REPAIR KIT, HAND PUMP CAB	FOR : 33.11186	
	3092052	REPAIR KIT, HAND PUMP CAB	FOR : 33.11186	
	274105	REPAIR KIT, TILT CYLINDER	F10 / F12 / F16	
	274106	REPAIR KIT, TILT CYLINDER	F10 / F12 / F16	
	1611186 3943330	HAND PUMP CAB TILT	ALL MODELS	
	-	HAND PUMP CAB TILT	FL 10	
	1609246 1082068 1082091 1084045	TILT CYLINDER, CABIN	F10 / F12 / F16	
	1605935 1611872	TILT CYLINDER, CABIN	FL7 / FL10 / FL12	
	1075296	HAND PUMP CAB TILT	FH SERIES FM SERIES	
	20455262 20917279	HAND PUMP CAB TILT	FH SERIES FM SERIES	
	20452326	TILT CYLINDER, CAB	FH 12 / FH 16	


	OEM NO	DESCRIPTION	NOTES	
	465854	OIL COOLER	TD60A / TD60B	
	468035 1544501	OIL COOLER	F10 / TD100, TD120A	
	468612	OIL COOLER	F12 / TD120, TD121, TD122	
	421067 471037	VALVE TAPPET	D50A, D50B, TD50A, TD50B, D60A, TD60A, TD60B, TD60C, TD61, TD63E TD63ES, D70, TD70, TD71, TD73E, TD73ES	
	479031 (422318) (1545539) 1545540	VALVE TAPPET	D100, TD100, THD100 TD101*, THD101*, TD102*, THD102*, TD120, TD121*, TD122* (*early production)	
	1674043 1661905	PRESSURE CAP, RADIATOR	F10 ch.314000-, F12 ch.314000-, F16	
	1544429 364826	PRESSURE CAP, RADIATOR	N10 ch.-305999, N12 ch.-305999	
	476551	PRESSURE CAP, RADIATOR	F10 ch-313999 F12 ch-313999	
	1542591	PRESSURE CAP, EXPANSION TANK COOLING SYSTEM	F10 / F12 / F16 N10 / N12 NL10 / NL12 FL7 / FL10	
	1674083	PRESSURE CAP, RADIATOR	FH12, FH16	


	OEM NO	DESCRIPTION	NOTES	
	475918 (1660617)	EXPANSION TANK	F10, F12	
	1676400	EXPANSION TANK	FH12 / FH16	
	1676306 1661993	THERMOSTAT 75C	TD61,TD63, TD70F,TD73, TD101,TD102,TD103, TD121, TD122, TD123, D6A,D7B,D10A	
	1544683 8149182	THERMOSTAT 82C	TD61,TD63, TD70F,TD73, TD101,TD102,TD103, TD121, TD122, TD123, D6A,D7B,D10A	
	1665694 8149186	THERMOSTAT 86C	TD61,TD63, TD70F,TD73, TD101,TD102,TD103, TD121, TD122, TD123, D6A,D7B,D10A	
	273951	THERMOSTAT 76C	TD60A,TD60B, TD70F,TD70G, D100A,TD100A, TD100B,TD100G, TD120A,TD120C, TD120G	
	273952	THERMOSTAT 81C	TD60A,TD60B, TD70F,TD70G, D100A,TD100A, TD100B,TD100G, TD120A,TD120C, TD120G	
	- 467495 422238 422239 467671 467496 422292	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	N10 / TD100A, TD100B	
	- 1545091 1545092 1545093 1545094 1545095 1545096	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	TD100G, TD101G, TD101F	


	OEM NO	DESCRIPTION	NOTES	
	- 422963 422964 422965 422966 422967 422968	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	TD102F	
	- 479881 479882 479883 479994 479995 479996	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	TD103	
	- 423512 423513 423514 423515 423516 423517	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	TD120A	
	- 468600 468601 468602 468603 468604 468605	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	TD120G, TD120F (eng.no.-60640)	
	- 468981 468982 468983 468984 468985 468986	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	TD120G, TD120F (eng.no.60641-), TD121, TD122	
	- 479801 479802 479803 479804 479805 479806	INJECTION PIPING SET X 1 X 1 X 1 X 1 X 1 X 1	N12	
	3825417	INJECTION PIPING SET	TD162	
	6886192	CONTROL CYLINDER EXHAUST BRAKE	F88 / F89 / N10 N12 / NL10 / NL12	
	1556363	CONTROL CYLINDER EXHAUST BRAKE	N10 / N12 / F10 / F12 FL10 / NL10 / NL12 FM10 / B10 / B12	
	471172 1676832 471175 8194541	HOUSING , FUEL FILTER	ALL MODELLS	

	OEM NO	DESCRIPTION	NOTES	
	20440372 20769469 3092459	FUEL PUMP, ENGINE Short shaft	FH12 / NH12 / FM12 FL12 / B12	
	244391 1699140	FEED PUMP BOSCH REF : 0 440 008 007	F10 (ch. No. -313999) N10, FL10, N12 F12 (ch. No-313999)	
	244825	FEED PUMP BOSCH REF : 0 440 008 068	F10, F12, X110, N12 (ch. No. 314000-)	
	-	EXHAUST MANIFOLT, COMPLETE 468925 X 1 468924 X 1	TD120, TD121	
	479317 (1545824)	OIL PUMP	TD102, TD103; F10, FL10, N10	
	468387 468351	OIL PUMP OLD MODEL	TD120A, TD120E, TD120G, TD120GA	
	478649	OIL PUMP NEW MODEL	TD121G, TD121GD, TD121F, TD121FD, TD122FS, TD122FK, TD122FH, TD122FA, TD123E, TD123ES	
	270575 8192085	INJECTOR SLEEVE KITS	TD60B, TD60C, TD61F, TD61FB, TD61FBQ, TD61FHQ, TD61G, TD61GA, TD61GB, TD61GC, TD61DE, TD61GS, TD63E, TD63ES	
	273821 (276130) 477928	INJECTOR SLEEVE KITS	TD70F, TD70G, TD70H, TD71F, TD71G, TD73	
	270946 479163	INJECTOR SLEEVE KITS	TD100G, TD101, TD102, TD103, THD101, THD102, THD103, THD104	

	OEM NO	DESCRIPTION	NOTES	
	273822 468784	INJECTOR SLEEVE KITS	TD120F, TD120G (eng.no.-63804)	
	273983 470247	INJECTOR SLEEVE KITS	TD120F, TD120G (eng.no.6385-), TD121, TD122, TD123	
	275740	CYLINDER HEAD GASKET SET	D50A, D50B, TD50A, TD50B D60A, TD60A, TD60B, TD60C	
	276821 (275774)	CYLINDER HEAD GASKET SET	TD61F, TD61FB, TD61FBQ, TD61FHQ, TD61G, TD61GA, TD61GB, TD61GC, TD61GE, TD61GS,TD63E, TD63ES, D6A	
	275525	CYLINDER HEAD GASKET SET	D70A, D70B, TD70A, TD70B, TD70C, TD70D, TD70E, TD70F, TD70FC, TD70FS, TD70G, TD70H, TD70HA	
	276816 (275779)	CYLINDER HEAD GASKET SET	TD71F, TD71FA, TD71FAQ, TD71FC, TD71FCQ, TD71FD, TD71FQ, TD71FS, TD71FSQ, TD71G, TD73E, TD73ES, D7A, D7B	
	275551	CYLINDER HEAD GASKET SET	D100A*, TD100A* (*eng.no.18536-) D100B, TD100B, TD100C HD100A*, HD100D* THD100A*, THD100D* (*eng.no.2499-) THD100DA, THD100DB, THD100DC, THD100DD	
	270789 275742	CYLINDER HEAD GASKET SET	TD100BG, TD100G, TD100GA THD100EA, THD100EB, THD100EC, THD100ED THD100EE, THD100EK TD101, THD101, TD102, THD102, TD103, THD103, THD104KB, THD104KF, D10A, DH10A	
	275548	CYLINDER HEAD GASKET SET	TD120, TD121F, TD121FA, TD121FB, TD121FC, TD121FD, TD121FE, TD121FF TD121FK, TD121G*, TD121GD* (*eng.no.-131995)	
	270949	CYLINDER HEAD GASKET SET	TD121G*, TD121GD* (*eng.no.131996-) TD122, TD123E, TD123ES	

	OEM NO	DESCRIPTION	NOTES	
	271085 276924 3095198	CYLINDER HEAD GASKET SET	TD162F, TD162FL, TD162FS, TD163ES, D16A	
	3093503 3099100 276916 276887	CYLINDER HEAD, GASKET SET	D12 A / FH12	
	276875	DECARBONIZING GASKET SET	D12 A / FH12	
	276876	DECARBONIZING GASKET SET	D12A / B12	
	- 275740 270762 270768 270778	GASKET SET, COMPLETE 20.00060	TD60B, TD60C	
	- 275774 275776 270764 270774	GASKET SET, COMPLETE	TD61F, TD61G, TD61GA, TD61GB, TD61GC, TD61GS, TD63E, TD63ES	
	- 275525 270761 270771 270957	GASKET SET, COMPLETE 20.00070	D70A, D70B, TD70A, TD70B, TD70C, TD70D, TD70E, TD70F, TD70FC, TD70FS, TD70G, TD70H, TD70HA	
	- 275779 275781 270765 270775	GASKET SET, COMPLETE	TD71F; TD71FAQ, TD71FC, TD71FCQ, TD71FD, TD71FQ, TD71FS, TD71FSQ, TD71G	
	- 275551 276034 276122 270958	GASKET SET, COMPLETE	D100A, D100B TD100A, TD100B, TD100C (eng.no.18536-) F88, FB88, G88, N10, N88, NB88	
	- 270789 276035 276122 276052	GASKET SET, COMPLETE	TD100F, TD100G, TD100GA, TD101F, TD101FA, TD101G, TD101GA, TD102F, TD102FD, TD102FH, TD102FM, TD102FL, TD102FQ, TD103E, TD103S, F10, FL10, N10	

	OEM NO	DESCRIPTION	NOTES	
	- 275548 275554 276124 270772	GASKET SET, COMPLETE	TD120A, TD120C, TD120D, TD120E, TD120F, TD120FA, TD120FB, TD120FC, TD120G, TD120GA (eng.no.-55607)(engine no 55608-) TD121FG, TD121G, TD121FC, TD121FA (* engine no: -131995)	
	- 275548 275554 276124 270772	GASKET SET, COMPLETE	TD121G, TD121GD	
	- 270949 275554 276125 270772	GASKET SET, COMPLETE	TD122F, TD122G	
	- 270949 275554 276125 270772	GASKET SET, COMPLETE	TD123E, TD123ES	
	275785	CONVERSION GASKET SET, ENGINE OVERHAUL	THD101GB, THD101GC, THD101GD, THD101GK, B10R	
	276122 270780 275531	CONVERSION GASKET SET, ENGINE OVERHAUL	D100A, D100B TD100A, TD100B, TD100C, HD100A	
	276123 270776	CONVERSION GASKET SET, ENGINE OVERHAUL	TD100BG, TD100G, TD100GA, THD100EK TD101, THD101, TD102, TD103, D10A, DH10A	
	276124 270781 275555	CONVERSION GASKET SET, ENGINE OVERHAUL	TD120, TD121F, TD121FA	
	276125 271130	CONVERSION GASKET SET, ENGINE OVERHAUL	TD121G, TD121GD TD122, TD123E, TD123ES	
	424600	GASKET, OIL PAN	D50, TD50, TD60, TD61	

	OEM NO	DESCRIPTION	NOTES	
	424601 421025	GASKET, OIL PAN	D70, TD70, TD71	
	424604 422025	GASKET, OIL PAN	D100A, D100B, TD100A, TD100B, TD100BG, TD100C	
	424602	GASKET, OIL PAN	TD100G, TD100GA, TD101F, TD101FA, TD101FC, TD101FD, TD101GA, TD101GB, TD102F, TD102FD, TD102FDQ, TD102FF, TD102FH, TD102FQ, TD102FS	
	424605 423365	GASKET, OIL PAN	TD120A, TD120C, TD120D, TD120E, TD120F, TD120FA, TD120FB, TD120FC (eng.no.- 55607)	
	424603 470133	GASKET, OIL PAN	TD120A, TD120C, TD120D, TD120E, TD120F, TD120FA, TD120FB, TD120FC (eng.no.-55608) TD120G, TD120GA, TD121F, TD121FA, TD121FB, TD121FC, TD121FD, TD121FE, TD121FF, TD121FK, TD121G, TD121GD, TD122*	
	479486	GASKET, OIL PAN RUBBER GASKET	TD102, TD103, D10A	
	479484	GASKET, OIL PAN RUBBER GASKET	TD122, TD123	
	1547562	GASKET, OIL PAN RUBBER GASKET	D12 A,B,C / FH12	
	425622	GASKET, OIL PAN RUBBER GASKET	D12A / FH12 / B12	
	1545283	SEALING RING COOLANT PUMP	FOR.89.5615, 89.5618-89.5609 89.5607	

	OEM NO	DESCRIPTION	NOTES	
	1676432	SEALING RING COOLANT PUMP	F10 Interco., F12 Interco.; TD102F, TD122FK, TD122FS	
	1676561	SEALING RING COOLANT PUMP	F6, FL6,F7, FL7 F10, FL10,F12, FL12, FH12,F16, FH16, N10,NL10,N12, NL12S,B10M,B58	
	1578133	TEMPERATURE SENSOR	F10 ch.-25000, F12 ch.-313999, F12 ch.314000- with retarder, N10 TD100B/TD100G, N12 TD120 eng.no.31532-	
	1612230	TEMPERATURE SENSOR	TD100 / TD101 TD121 / TD122	
	1082030 8112337	AIR DRYER WABCO REF : 432 431 191 0 96.432191	FH12 / FH16 FM10 / FM12	
	-	AIR DRYER	WABCO REF: 432 410 104 0	
	-	AIR DRYER	ALL MODELS	
	3090288	AIR DRYER CARTRIDGE	ALL MODELS	
	20557234 20972915	AIR DRYER CARTRIDGE	FH 12 / FH 16 FH / FM SERIES	
	3028745 3181131	AIR SILENCER	WABCO REF : 432 407 070 0 10 BAR	

	OEM NO	DESCRIPTION	NOTES	
	1573255 (1613652)	FOUR CIRCUIT PROTECTION VALVE		
	1618635 8152899	PROTECTING VALVE		
	1589620 6886123	FOOT BRAKE VALVE WABCO REF . 461 315 042 0	FM7, FL4, FL6, FL7 FL10, FL12	
	1607836	LOAD SENSING VALVE	WABCO REF: 475 710 000 0	
	1607728	LEVELLING VALVE	WABCO REF. 464 006 000 0	
	8030222	LEVELLING VALVE	TYPE NO : SV 1294	
	-	LEVELLING VALVE	TYPE NO : SV 1310	
	-	LEVELLING VALVE		
	280375 281672	EMERGENCY, RELAY VALVE	ALL MODELS	
	354451	EMERGENCY, RELAY VALVE	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	1585346 6888589	TRAILER CONTROL VALVE	WABCO REF: 973 002 000 0	
	1607887	TRAILER CONTROL VALVE	WABCO REF : 973 002 520 0	
	1576736 (348909) (3090254) (1082666)	RELAY VALVE M22 X 1,5	WABCO REF: 973.001.010.0	
	367838	LEVELLING VALVE R	BOSCH REF : 0 500 005 006	
	367839	LEVELLING VALVE L	BOSCH REF : 0 500 005 007	
	-	HAND BRAKE VALVE	ALL MODELS	
	1509055	HAND BRAKE VALVE	WABCO REF : 961 702 001 0	
	1588103 1598586	HAND BRAKE VALVE	WABCO REF. 961 722 302 0	
	6876972	HAND BRAKE VALVE	OEM REF: HB1142	
	-	UNLOADER VALVE	WABCO REF: 975 303 473 0	

	OEM NO	DESCRIPTION	NOTES	
	-	LOAD SENSING VALVE	WABCO REF: 475 714 500 0	
	-	LOAD SENSING VALVE	WABCO REF: 475 711 108 0	
	-	LOAD SENSING RELAY EMERGENCY VALVE	WABCO REF: 475 712 000 0	
	-	MANUAL LOAD PROPORTIONING VALVE	WABCO REF : 475 604 010 0	
	8141934 3198233 20531967	LEVELING VALVE	WABCO REF: 464 007 002 0	
	267859	INHIBITOR VALVE	WABCO REF: 463 022 020 0	
	1606720 3987429	PRESSURE LIMITING VALVE	F10,F12,N10,N12, NL10,NL12,FH12,FH16 B10, B12, NH12	
	1629727 1585876	NON-RETURN VALVE	ALL MODELS	
	1626982 1505049	NON-RETURN VALVE	ALL MODELS	
	1581425 1081328	DRAIN VALVE	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	-	PRESSURE VALVE	WABCO REF: 475 010 025 0	
	6213539 350471	QUICK COUPLING	WABCO REF: 452 802 009 0	
	1079666	ABS MODULATOR VALVE	WABCO REF: 472 195 018 0	
	3173151	TRAILER CONTROL VALVE	WABCO REF: 973 009 002 0	
	1669324 3092123	INHIBITOR VALVE	R1400,R1700 SR1400,SR1700	
	1068951 1669297 8172627	INHIBITOR VALVE	SR1400,SR1700 SR1900	
	1068952	INHIBITOR VALVE	SR1400,SR1700 SR1900	
	1662413 1526797	VALVE, SELECTOR UNIT	N10 / N12 NL10 / NL12	
	1662551	VALVE, GEAR SELECTOR	N10 / N12 NL10 / NL12	
	267859	INHIBITOR VALVE	WABCO REF: 463 022 020 0	

	OEM NO	DESCRIPTION	NOTES	
	1527046	REPAIR KIT, SERVO CYLINDER	SR62	
	8191146	SIGNAL LAMP L + R YELLOW	FH12 / FH16	
	3981668	SIGNAL LAMP L + R WHITE	FH12 / FH16 NEW MODELS	
	20429874 20409874 20826211	SIGNAL LAMP, L FH vers.2	FH 12 / FH 16 FM 9 / FM 10 FM 12	
	20429875 20409875 20826212	SIGNAL LAMP, R FH vers.2	FH 12 / FH 16 FM 9 / FM 10 FM 12	
	1082755 8121102	SIGNAL LAMP , L	NL10 / NL12	
	1082756 8121103	SIGNAL LAMP , R	NL10 / NL12	
	1062189 8144693	FOG LAMP, WHITE	ALL MODELS	
	1589502	CONTACT, EXHAUST BRAKE	F10, F12, N10, N12 NL10, NL12	
	8155750 1594958 1578073 1587086	FLASHER SWITCH	N10 ch.53770, N12 ch.6564-, F10 ch.25001-, F12 ch.34001-, F16	

	OEM NO	DESCRIPTION	NOTES	
	1594959	WIPER WASHER SWITCH	N10 ch.53770, N12 ch.6564-, F10 ch.25001-, F12 ch.34001-, F16	
	1580618	FLASHER SWITCH	N10 ch.21720-3769, N12 ch.3233-6563, F10 ch.-25000, F12 ch.-34000	
	1578198	WIPER WASHER SWITCH	N10 ch.21720-3769, N12 ch.3233-6563, F10 ch.-25000, F12 ch.-34000	
	8154792 1594542	FLASHER SWITCH	FL4, FL7, FL10, FL12	
	1594543	WIPER WASHER SWITCH	FL4, FL7, FL10, FL12	
	3172170 1624135	DIRECTION INDICATOR SWITCH	FH 12 , FH 16	
	1624133 20704091	WIPER WASHER SWITCH	FH 12 , FH 16	
	3172171 1096413	DIRECTION INDICATOR SWITCH	FH 12 , FH 16	
	3944672 20701028	WIPER WASHER SWITCH	FH 12 , FH 16	
	3944672	DIRECTION INDICATOR SWITCH	VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	8158723	DIRECTION INDICATOR SWITCH	FL7, FL10	
	8158724	WIPER WASHER SWITCH	FL7, FL10	
	3944084	SWITCHES, POWER WINDOW	FH12 / FH16	
	3944085	SWITCHES, POWER WINDOW	FH12 / FH16	
	1578700	SWITCHES, HAZARD WARNING LIGHT	F7,F10,F12,F16 N10,N12	
	1578702	SWITCHES, HEAD LAMPS	F7,F10,F12,F16 N10,N12	
	1578704	SWITCHES, INTERMITTENS WIPER	F7,F10,F12,F16 N10,N12	
	1578706	SWITCHES, STOP LAMPS	F7,F10,F12,F16 N10,N12	
	1080660	SWITCHES, INTERMITTENS WIPER	F7,F10,F12,F16 N10,N12	
	1578710	SWITCHES, FOG LAMP REAR	F7,F10,F12,F16 N10,N12	

	OEM NO	DESCRIPTION	NOTES	
	8152142	SWITCHES, POWER WINDOW	F7,F10,F12,F16 N10,N12	
	1578756	SWITCHES, BOGIE LIFT	F7,F10,F12,F16 N10,N12	
	1611818	SWITCHES, DIFF. WHEEL	F7,F10,F12,F16 N10,N12	
	8157753	SWITCH	FH Series	
	8157754 20559983	SWITCH	FH Series	
	8157759	SWITCH	FH Series	
	1607651	FUEL LEVEL SENSOR	F/FL 6, F/FE/FL/FM 7 F/FL/N/NL 10/12/16	
	3944186 8143448 1088588	SOLENOID VALVE	ALL MODELS	
	-	SOLENOID VALVE 24v	ALL MODELS	
	1598575	TACHOMETER (25) X 100	F10,F12 FL7,FL10	

	OEM NO	DESCRIPTION	NOTES	
	1502170	TACHOMETER (35) X 100	N10,N12 NL10,NL12	
	1606877 1266085 1218684 1218690	OIL PRESSURE SWITCH ENGINE	F10, F12, N10, N12 TD100, TD120, TD121	
	1609395	OIL PRESSURE SWITCH ENGINE	F10, F12, F16, N10, N12, TD101, TD102, TD103, TD122, TD123 TD162	
	1594229	OIL PRESSURE SENSOR	F10 / F12 / N10 / N12	
	8125161	OIL PRESSURE SENSOR	FH12, FH16 F12 CH314000 F10 CH314000	
	1594236	OIL PRESSURE SENSOR	F10, F12	
	3987034	OIL PRESSURE SENSOR	F10, F12	
	1585878	WASHER PUMP	ALL MODELS	
	1606929	WASHER PUMP	ALL MODELS	
	8189171 8144143	WASHER PUMP (2 PIN)	FL10, FH12, FH16 FM10, FM12,	

	OEM NO	DESCRIPTION	NOTES	
	20409793 3980681 8189170	WASHER PUMP (3 PIN)	FL10, FH12, FH16 FM10, FM12,	
	1613336	HAND THROTTLE CONTROL	F88,F89,F10,F12, F16,N10,N12, NL10,NL12,B58, B59,B10,B12,	
	20589122	INTERCOOLER AIR HOSE Ø 76 X 148 mm	FH12 / FM12	
	1676216 1660277	INTERCOOLER AIR HOSE Ø 76 150X165X125mm	FL7 / FL10 / B7	
	1676218	INTERCOOLER AIR HOSE Ø 76 150X145X150mm	F10 / F12 / FL7 FL10 / NL10 / NL12	
	1675098 1660264	INTERCOOLER AIR HOSE Ø 76 X 305 mm	FL7 / FL10 / B12	
	20589123	INTERCOOLER AIR HOSE Ø 80 X 390 mm	FH12 / FM12 / VN	
	8154602	RUBBER HOSE, GEARBOX Ø 19 X 40 mm Ø 380 X 90 mm	FH12 / FH16 / FM9 FM12	
	8155665	RUBBER HOSE, GEARBOX Ø 19 X 40 mm Ø 375 X 95 mm	FH12 / FH16 / FM9 FM12	

	OEM NO	DESCRIPTION	NOTES	
	1332476	CABLE		
	1622577 1612165	CONTROL CABLE, CAB DOOR LOCK		
	1674174	BELLOWS, AIR INLET	FH12 / FH16	
	1080152 (1587240)	RUBBER BELLOWS	F10, F12	
	20383596	RUBBER BELLOWS UPPER	FH12 / FH16	
	20383598 1623569	RUBBER BELLOWS LOWER	FH12 / FH16	
	8149800	INTERCOOLER AIR HOSE Ø 80X360-350mm	FH12 / FH16 / FM9 FM10 / FM12	
	1676481 20463924 8149634	INTERCOOLER AIR HOSE Ø 83X155mm	FH12 / NH12 / FM7 FM 9 / FM10 / FM12 B12	
	1676491	INTERCOOLER AIR HOSE Ø 85X82X235mm	FH12	
	007006	INTERCOOLER AIR HOSE Ø 83X170mm	FH12	

	OEM NO	DESCRIPTION	NOTES	
	1676199	INTERCOOLER AIR HOSE	FH16	
	1676744 20441625	INTERCOOLER AIR HOSE Ø 70X230mm	F10 / F12 / F16 / F6 NL10 / NL12 / B12	
	70312021	INTERCOOLER AIR HOSE Ø 68X165mm	B7 BUS	
	3988838	BRAKE DISC, FRONT WHEEL 67.88838	FH 12 / FH16 FM7 / FM9 / FM10 FM12 / B10 / B12	
	3095396 20768092 20918891	BRAKE PADS SET 67.95396	FH 12 / FH16 FM7 / FM9 / FM10 FM12 / B10 / B12	
	3038061 (1575522)	HUB CAP	OLD VERSION	
	3032845 (1586796) (1606125)	HUB CAP	OLD VERSION	
	1625712 (3985590) (3963419)	HUB CAP NEW VERSION	FL616-619, FL7, FS7, F10, F12, FH12, FL12, F16, FH16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S	
	1573173	CLUTCH SERVO	F86, F87, F88, G88, F89, G89, N88, N7, N10 ch.-21719, N12 ch.-3232	
	271194 273447	REPAIR KIT, CLUTCH SERVO		

	OEM NO	DESCRIPTION	NOTES	
	273632	REPAIR KIT, CLUTCH SERVO	F86, F87, F88, G88, F89, G89, N88, N7, N10 ch.-21719, N12 ch.-3232	
	270586	REPAIR KIT, CLUTCH SERVO OLD VERSION	FH12 / FH16	
	85102140 3095041	REPAIR KIT, CLUTCH SERVO NEW VERSION	FH12 / FH16 / FM10 FM12 / NH12	
	9309309	REPAIR KIT, CLUTCH SERVO NEW VERSION	FH12 / FH16 / FM10 FM12 / NH12	
	3093100 3094550 276624	REPAIR KIT, CLUTCH SERVO NEW VERSION	FH12 / FH16 / FM10 FM12 / NH12	
	85102142	REPAIR KIT, CLUTCH SERVO NEW VERSION	FH12 / FH16 / FM10 FM12 / NH12	
	353059	LUBRICATING HOSE	For 86.27693 For 86.27695	
	353060	LUBRICATING HOSE	For 86.55825 For 86.55843	
	230191 1503691	HOSE, CLUTCH SERVO	F87, F88, F89, G88, G89, F7, FL7, F10, FL10, F12, FL12, N7, N10, NL10 AUS, N1210S, N12, NL12 AUS, NL12S, B57	
	1619885	HOSE, CLUTCH SERVO	F10, F12 CH.314000	

	OEM NO	DESCRIPTION	NOTES	
	949964 (191813) 964858	FORK AND PIN, CLUTCH SERVO FORK . PIN For 86.55639 For 86.68501	F86, FB86, F87, F89, G89, F6S, FE6, FL6, F7, FE7, FL7, FS7, F10, FL10, FS10, F12, FH12, FL12, F16, FH16, N7, N10, NL10 AUS, NL10BR, NL10S, N12, NL12 AUS, NL 127, BB57, B58, B58BR, B6 ch-4999, B7, B7F, B7FA, B9M, B10M, B10B, B10MBR, B10R, C10M, B12	
	967347	HOSE, EXHAUST PRESSURE REGULATOR	F10, F12 NEW	
	948529	HOSE, EXHAUST PRESSURE REGULATOR	F10, F12 OLD	
	1075221	CAP, CAB MOUNTING FRONT L	FH12 / FH16 NEW	
	1075223	CAP, CAB MOUNTING FRONT R	FH12 / FH16 NEW	
	1500981	SIGHTING ROD	N10, N12, NL10, NL12	
	475820	FAN SHROUD	F10, F12	
	423087	GEAR, COMPRESSOR	For 91.80437 For 91.11815 Tuflo 501	
	478777	GEAR, COMPRESSOR	For 91.26060 For 91.99999 For 91.13632 For 91.50407	
	1677848	GEAR, COMPRESSOR	For Compr. Orig. Ref. 1628592, 1628593 FH12	

	OEM NO	DESCRIPTION	NOTES	
	8152010 (1082368)	AIR FILTER, COMPRESSOR		
	8152009 (1082111) (1586882)	AIR FILTER, COMPRESSOR		
	3944252 (1505047)	REGULATOR	7,9 BAR	
	3944255 (3126287)	REGULATOR	8,1 BAR	
	3944251 (1607889)	REGULATOR	12,1 BAR	
	6645225 (272864)	REPAIR KIT, REGULATOR	For 91.44252 For 91.44255 For 91.44251	
	1507501	HOSE, COMPRESSOR L=300MM	F84, F85, F86, F87, F6S, F7, F10, F12, N10, N12, B6	
	968116	HOSE, COMPRESSOR L=300MM	FL4, F7, FL7, F10, F12, N10, NL10 AUS, N12, NL12 AUS, FL10, F12, FL12 Tuflo: 500, 501, 700, LP48	
	977649	HOSE, COMPRESSOR L=365MM	FL7, F10, FL10, F12, N7, N10, NL10 AUS, NL10S, N12, NL12S Tuflo: 500, 501	
	966600	HOSE, COMPRESSOR L=250MM	F610-611-613-614, F6S, F7, F10, F12, N7, N10, NL10 AUS, N12, NL12 AUS, B6FA Tuflo: 400, 500, 501, 700	

	OEM NO	DESCRIPTION	NOTES	
	966601	HOSE, COMPRESSOR L=350MM	F6 USA, F7 USA, N10 USA, N12 USA, FL7 , FL10, NL10S, NL12S Tuflo: 500	
	967736	HOSE, COMPRESSOR L=400MM	FL616-619, FS7, F10, F12, F16, NL10S, NL12S	
	967737	HOSE, COMPRESSOR L=300MM	FL7, FL10 Tuflo: 500, LP48ESS, F10, F12 Tuflo: 700 NL10 AUS, NL10S, NL12 AUS, NL12S Tuflo: 700	
	977237	HOSE, COMPRESSOR		
	977651	HOSE, COMPRESSOR For: WABCO704		
	1215281 241646	HEADLAMP INSERT OUTER SIDE	F10 / F12 N10 / N12	
	1215282	HEADLAMP INSERT OUTER SIDE	F10 / F12 N10 / N12	
	1215283	HEADLAMP INSERT OUTER SIDE YELLOW	F10 / F12 N10 / N12	
	1695926	HEADLAMP LENS	F10 / F12 N10 / N12	
	1570496 244429	HEADLAMP INSERT INNER SIDE	F10 / F12 N10 / N12	

	OEM NO	DESCRIPTION	NOTES	
	1578058	HOUSING, SIGNAL LAMP L	F10 F12 N10, N12	
	1578059	HOUSING, SIGNAL LAMP R	F10 F12 N10, N12	
	1578053	LENS, SIGNAL LAMP L	F10 F12 N10, N12	
	1578054	LENS, SIGNAL LAMP R	F10 F12 N10, N12	
	1081604	HEADLAMP INSERT, L	F10 ch.314000- F12 ch.314000- FL10, F16, N10 ch.306000- N12 ch.306000-	
	1081606	HEADLAMP INSERT, R	F10 ch.314000- F12 ch.314000- FL10, F16, N10 ch.306000- N12 ch.306000-	
	-	GLASS, HEADLAMP L + R	F10 ch.314000- F12 ch.314000- FL10, F16, N10 ch.306000- N12 ch.306000-	
	8144285 3981593	HEADLAMP INSERT, L	FH12 , FH16	
	8144286 3981594	HEADLAMP INSERT, R	FH12 , FH16	
	-	GLASS, HEADLAMP L + R	FH12 , FH16	

	OEM NO	DESCRIPTION	NOTES	
	20360884	HEADLAMP INSERT, L	FH12 / FH16 2. ver. FM9/FM10/FM12	
	20360885	HEADLAMP INSERT, R	FH12 / FH16 2. ver. FM9/FM10/FM12	
	20379428 20710524	GLASS, HEADLAMP L	FH 12 / 16 NEW FM 9 / 12 NEW MODEL	
	20379429 20710525	GLASS, HEADLAMP R	FH 12 / 16 NEW FM 9 / 12 NEW MODEL	
	3175031 1081608	HEADLAMP INSERT, L	FL 7 / FL10 / FL12	
	3175032 1081607	HEADLAMP INSERT, R	FL 7 / FL10 / FL12	
	-	GLASS, HEADLAMP L + R	FL 7 / FL10 / FL12	
	1082751	HEADLAMP INSERT, L 76.00102	NL 10 / NL 12	
	1082752	HEADLAMP INSERT, R 76.00103	NL 10 / NL 12	

	OEM NO	DESCRIPTION	NOTES	
	964763	BULB, HALOGEN	H4 24 V 70/75 W 43T	
	943903	BULB	H3 24 V /70 W	
	1593923	SIGNAL LAMP , L	F10 ch.314000-F12 ch.314000-FL10,FL12 F16	
	1593924	SIGNAL LAMP , R	F10 ch.314000-F12 ch.314000-FL10,FL12 F16	
	20360273 3980334	LAMP, LH	FH12 / FH16	
	20360274 3980335	LAMP, RH	FH12 / FH16	
	3981666	PARKING LAMP, LH-RH	FH12 / FH16	
	1062190	FOG LAMP,YELLOW	ALL MODELS	
	1587993	FLASHER RELAY	F10 ch.-25000, F10 ch.314000-, F12 ch.- 34000, F12 ch.314000-, F16, NL10S, NL10 AUS, NL12S, NL12 AUS, N12BR MARK2, B6	
	1623180	FLASHER RELAY	F10 ch.-25000, F10 ch.314000-, F12 ch.- 34000, F12 ch.314000-, F16, NL10S, NL10 AUS, NL12S, NL12 AUS, N12BR MARK2, B6	

	OEM NO	DESCRIPTION	NOTES	
	1188625 (1082905)	INDICATING LAMP, WHITE	F10, F12, N10, N12	
	1608040	INDICATING LAMP, YELLOW	F10, F12, N10, N12	
	-	INDICATING LAMP, BLUE	F10, F12, N10, N12	
	-	INDICATING LAMP, RED	F10, F12, N10, N12	
	-	INDICATING LAMP, GREEN	F10, F12, N10, N12	
	1623726	INDICATING LAMP, WHITE	FH12 / FH16 / FM9 / FM10 / FM12 / NH12	
	1623727	INDICATING LAMP, RED	FH12 / FH16 / FM9 / FM10 / FM12 / NH12	
	-	INDICATING LAMP, YELLOW	FH12 / FH16 / FM9 / FM10 / FM12 / NH12	
	-	INDICATING LAMP, BLUE	FH12 / FH16 / FM9 / FM10 / FM12 / NH12	
	1620476	STOP / TAIL LAMP L	FL4, FL6, FL7, FL10, FS10, F10 ch.314000-, F12 ch.314000-, F16, N10 ch.306000-, NL10BR, NL10S, N12 ch.306000-, NL12BR, NL12S	
	1620477	STOP / TAIL LAMP R	FL4, FL6, FL7, FL10, FS10, F10 ch.314000-, F12 ch.314000-, F16, N10 ch.306000-, NL10BR, NL10S, N12 ch.306000-, NL12BR, NL12S	
	1620480 (6778319)	LENS, STOP/TAIL LAMP L - R	FL4, FL6, FL7, FL10, FS10, F10 ch.314000-, F12 ch.314000-, F16, N10 ch.306000-, NL10BR, NL10S, N12 ch.306000-, NL12BR, NL12S	

	OEM NO	DESCRIPTION	NOTES	
	8191745	STOP / TAIL LAMP L	FH12 / FH16	
	8191746	STOP / TAIL LAMP R	FH12 / FH16	
	8142919	LENS, STOP/TAIL LAMP L - R	FH12 / FH16	
	3981455	STOP / TAIL LAMP L	FH12 / FH16 NEW MODEL	
	3981456	STOP / TAIL LAMP R	FH12 / FH16 NEW MODEL	
	3981782	LENS, STOP/TAIL LAMP L - R	FH12 / FH16 NEW MODEL	
	20507623 20425728	STOP / TAIL LAMP L	FL6, FM9, FM12, NH12 FH12, FH16	
	20507624 20425729	STOP / TAIL LAMP R	FL6, FM9, FM12, NH12 FH12, FH16	
	20425732	LENS, STOP/TAIL LAMP L - R	FL6, FM9, FM12, NH12 FH12, FH16	
	-	ACCESSORY LAMP, TRAILER	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	8153600 (1504951)	RELAY 24V		
	-	HORN 24 v	ALL MODELS	
	20383071 8154771	HORN 24 v	ALL MODELS	
	1081869 1590396	PRESSURE GAUGE 0-10 BAR Ø 63mm	F10, F12, N10, N12	
	1088427 1575289 20537762	WINDSCREEN WIPER BLADE L= 600 mm	F6,F7,F10,F12, F16,FL6,FL7,FL10	
	1503895	WINDSCREEN WIPER BLADE L= 500 mm	F88,F89	
	1372029 1599025	WINDSCREEN WIPER BLADE L= 400 mm	N7,N10,N12 NL10,NL,12	
	1606291 3944817	WINDSCREEN WIPER BLADE L= 700 mm	FL7, FL10, FL12	
	8143709 20537740 20826591	WINDSCREEN WIPER BLADE L= 650 mm	FH 12	
	8189631	WINDSCREEN WIPER BLADE L= 650 mm	FH16	

	OEM NO	DESCRIPTION	NOTES	
	1593933	WINDSCREEN WIPER RUBBER	For 33-88427	
	1575288	WINDSCREEN WIPER ARM	F7, F10, F12, F16	
	352390	LEVEL INDICATOR	F88, F89, N10, N12	
	1581232	LEVEL INDICATOR	F10, F12	
	1614753	FAN MOTOR, HEATING SYSTEM	F10 / F12	
	8154260	RELAY 24 volt	F10, F12, F88, F89 FH12, FH16, FL10, FL12, N10, N12, NL10, NL12	
	1623942 (1573732)	WATER RESERVOIR	F10, F12, F16	
	1605835	WATER RESERVOIR	FL10	
	1089851	WATER RESERVOIR	FL7, FL10, F10 ch.314000-, F12 ch.314000-	
	-	AIR HOSE,YELLOW M 16 X 1,5	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	-	AIR HOSE,RED M 16 X 1,5	ALL MODELS	
	-	AIR HOSE,YELLOW M 22 X 1,5	ALL MODELS	
	-	AIR HOSE,RED M 22 X 1,5	ALL MODELS	
	-	COUPLING HEAD, YELLOW M 16 X 1,5	ALL MODELS	
	-	COUPLING HEAD, RED M 16 X 1,5	ALL MODELS	
	-	COUPLING HEAD, YELLOW (AUTOMATIC) M 16 X 1,5	ALL MODELS	
	-	COUPLING HEAD, RED (AUTOMATIC) M 16 X 1,5	ALL MODELS	
	1584598	COUPLING HEAD, YELLOW M 22 X 1,5	ALL MODELS	
	1584599	COUPLING HEAD, RED M 22 X 1,5	ALL MODELS	
	1505064	COUPLING HEAD, YELLOW (AUTOMATIC) M 22 X 1,5	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	1505065	COUPLING HEAD, RED (AUTOMATIC) M 22 X 1,5	ALL MODELS	
	3944912 1507695	CONNECTING CABLE, ELECTRIC	ALL MODELS	
	1581329	SOCKET, CONNECTING CABLE	ALL MODELS	
	1581328	SOCKET, CONNECTING CABLE	ALL MODELS	
	8151943 240315 1587698	MAIN SWITCH, HAND OPERATED	ALL MODELS	
	1593140	SPEED SENSOR 3 SOCKET 760.0100	ALL	
	273788	STOP CONTROL CABLE	F84, F85, F86, FB86, F88, FB88, G88, F89, G89, F7 excl. AUS, FL7 ch.-313628, -560378, F10 ch.-40144, FL10 ch.-313697, -560378, F12 ch.- 65416, N88, NB88, N7, N10 ch.- 313552, N12 ch.-313593, B57, BB57, B610, B6F, B6FA ch.-573	
	1505363	SHAFT, STEERING PUMP	For 92.4642	
	1695592	SHAFT, STEERING PUMP	For 92.85013 For:92.87787 For:92.87788 For:92.89231	
	1695412	PLATE, STEERING PUMP	For 92.4642	

	OEM NO	DESCRIPTION	NOTES	
	1695594	PLATE, STEERING PUMP	For 92.85013 For:92.87787 For:92.87788 For:92.89231	
	1505359 3091873	ROTOR KIT, STEERING PUMP	For 92.4642	
	1695595 3090417	ROTOR KIT, STEERING PUMP	For 92.85013 For:92.87787 For:92.87788 For:92.89231	
	1695413	PLATE, STEERING PUMP	For 92.4642	
	1695596	PLATE, STEERING PUMP	For 92.85013 For:92.87787 For:92.87788 For:92.89231	
	1547488	IDLER GEAR , OIL PUMP	FH12 / OLD	
	8170264	IDLER GEAR , OIL PUMP	FH12 / NEW	
	8170265	IDLER GEAR , OIL PUMP	FH12 / NEW	
	1677295	HUB , IDLER GEAR OIL PUMP	FH12 / OLD	
	8170454	HUB , IDLER GEAR OIL PUMP	FH12 / NEW	

	OEM NO	DESCRIPTION	NOTES	
	1543452	DRIVE GEAR, OIL PUMP	FH16	
	1543450	IDLER GEAR, OIL PUMP	FH16	
	1527500	CENTRE PLATE, CLUTCH FOR : 350 mm	F10, F12, N10, N12	
	1655731 382857	CENTRE PLATE, CLUTCH FOR : 380 mm	F10, F12, N10, N12	
	- 267149 382873	LEVER AND FORK KIT LEVER FORK FOR CLUTCH	350mm	
	- 356888 347211	LEVER AND FORK KIT LEVER FORK FOR CLUTCH	380mm, 420mm	
	267144	THRUST WASHER FOR CLUTCH	350mm	
	356878	THRUST WASHER FOR CLUTCH	380mm, 420mm	
	1527693 (267156) (352221) (8112167)	RELEASE BEARING	F86, FB86, G88, G89, F88, F89, F7, FL7, F10, FL10, F12, N7, N10, N12, B9, B10	
	1527695 (267158) (348842) (8112138)	RELEASE BEARING	F86, FB86, G88, G89, F88, F89, F7, FL7, F10, FL10, F12, N7, N10, N12, B9, B10	

	OEM NO	DESCRIPTION	NOTES	
	1527696	BALL BEARING	For 86.27693 For 86.27695	
	1655135	SPRING BRACE, RELEASE BEARING	For 86.55825 For 86.55843 For 86.72847	
	1655829 20571946	MOUNTING KIT, RELEASE BEARING	For 86.55825 For 86.55843	
	1655825 (1672946) (1668923) (1669833) (8112159) 20571928	RELEASE BEARING WITH ASSEMBLING KIT	FE7, FS7, FL7, F10, FL10, N10, NL10S, F12, FL12, FH12, B10, B12	
	1672847 1655732 3192223	RELEASE BEARING WITHOUT ASSEMBLING KIT	FE7, FS7, FL7, F10, FL10, N10, NL10S, F12, FL12, FH12, B10, B12	
	1655843 (1669832) (1668921) 3192222 20569157	RELEASE BEARING WITH ASSEMBLING KIT	FL7, F10, FL10, N10, F12, FL12, N12, NL12S, F16, FH12, FH16, B10	
	1672944 (1672945) 3192217	RELEASE BEARING WITHOUT ASSEMBLING KIT	FL7, F10, FL10, N10, F12, FL12, N12, NL12S, F16, FH12, FH16, B10	
	3192224 1672948 20571941	RELEASE BEARING WITH ASSEMBLING KIT	B7	
	3192218 20569151 1521723	RELEASE BEARING WITH ASSEMBLING KIT	VT2214 / 2412 / VT2515	
	3192216 20569153 1521722	RELEASE BEARING WITH ASSEMBLING KIT	SR1700 / SR1900	

	OEM NO	DESCRIPTION	NOTES	
	3192220 20569155 1571767	RELEASE BEARING WITH ASSEMBLING KIT	VT2014 / VT2214 VT2514	
	-	MOUNTING KIT, RELEASE BEARING REF.NO: 3180002103	SR1700, SR1900 VT2014, VT2214, VT2412, VT2514	
	1667058	RELEASE FORK	B7, FL10, FL7, FM12 FH12, FH16	
	3192250	RELEASE FORK	B7, FL10, FL7, FM12 FH12, FH16	
	964481	LEVER, CLUTCH SERVO		
	3150188	ROLLER, RELEASE FORK	FM9, FM10, FM12 FH12, FH16	
	1655134	ROLLER RELEASE FORK	FL7, FS7, FE7, F10, FL10, F12, FL12, FH12, F16, FH16, N10 ch.306000-, NL10 AUS, NL10BR, NL10S, N12 ch.306000-, N12 AUS, NL12BR, NL12S, B10B, B10BR, B10M ch.20001-, B10M ch.40000-, B12	
	1655704 (267257)	CUBE RELEASE FORK	F6, F6S, FL6, F7, F10 ch.- 25000, F10 ch.25001-, F12 ch.- 34000, F12 ch.34001-, N7, N10, N10BR, N12, B10M ch.- 11499, B10M ch.11500-, C10M, B7 ch.20000-, B6, B58, B57 ch.-7980	
	470327	TURBO OUTLET HOSE Ø 76 x 80 mm	F10 ch.no.-25000, F12 ch.no.-34000, N10 USA, N10BR MARK2, N12, N12 AUS, N12BR, N12BR MARK2, NL12S, B10M ch.no.-11499, B58BR	
	466328	TURBO OUTLET HOSE Ø 22 x 80 mm	F84, F85, F86/F87 TD70E, F4 TD40A, F6, F6S, F7, F10 ch.no.314000-, F12 ch.no.34000-, F16, FH16, N84, N7 TD70E/TD70G, NL10 AUS, NL10BR,	

	OEM NO	DESCRIPTION	NOTES	
	3028329	INTERCOOLER AIR HOSE Ø 50X60X245mm	B10 / B12 / B58 BUS	
	475900	HOSE, RADIATOR UPPER	F10 ch.no.-25000, F10 ch.no.25001-40460 F10 ch.no.-19625, F10 ch.no.19626-40640 F10 ch.no.25001-46640 F10 ch.no.314000- F12 ch.no.-34000 F12 ch.no. 34001- F12-35078 F12 35079-325762 F12-900118 F12-352763-900119	
	1544427	HOSE, RADIATOR UPPER	F12 ch.no.-34000, F12 ch.no.34001-, F12 ch.no.-35078, F12 ch.no.35079-352762, F12 ch.no.-900118, F12 ch.no.352763-900119	
	76116	HOSE, RADIATOR LOWER	F12 ch.no.-34000, F12 ch.no.34001-, F12 ch.no.-35078, F12 ch.no.35079-352762, F12 ch.no.-900118, F12 ch.no.352763-900119	
	343849	HOSE, RADIATOR	F88, F89	
	475440 475596	HOSE, RADIATOR	N10, NL10 AUS, NL10BR, NL10S, N12, NL12 AUS, NL12BR, NL12S	
	470464 468216	HOSE, RADIATOR	F10 ch.314000-, F12, N12	
	1665082	HOSE, RADIATOR	F12 / Ch.314000 F10 / Ch.314000 NL12 AUS, NL12BR, NL12S	
	476503 1588420	HOSE, RADIATOR	F10, F12	
	476768 354684	RUBBER HOSE, HEATING SYSTEM	F88/FB88 ch.no.3799-, FB88T ch.no.3119-, F89, G89, F12 ch.no. 230 Switzerland	

	OEM NO	DESCRIPTION	NOTES	
	1544203 1580064	RUBBER HOSE, COOLING SYSTEM, HEATING SYSTEM	F10 ch.no.314000- F12 ch.no.314000-	
	1544831	RUBBER HOSE, COOLING SYSTEM, HEATING SYSTEM	F10 CH.40640 F12 CH.65820	
	476117	RUBBER HOSE, WATER PUMP	F10, F12	
	1661620	SUCTION HOSE	N10, N12	
	351574 943369	RUBBER HOSE, OIL COOLER	F10, F12, FL10, N10, NL10S	
	468706	RUBBER HOSE, OIL COOLER	F12, N12, B12, NL12 B12	
	467538	RUBBER HOSE, OIL COOLER	F88, FL6, F10, FL10 N88, N10, N12, NL10	
	467739	RUBBER HOSE	F10, F12	
	475186	RADIATOR HOSE	N10 / N12	
	422769 1545502	RADIATOR HOSE	FL10	


	OEM NO	DESCRIPTION	NOTES	
	1664079	RADIATOR HOSE	F12 / Ch.314000 F10 / Ch.314000	
	20542202 3979986	RADIATOR HOSE	FH12	
	20542199	RADIATOR HOSE	FH12, NH12, FM9, FM12	
	1665951	RADIATOR HOSE	FH12	
	3154395 20542204 3175035 1674305 1674306	RADIATOR HOSE	FH12	
	3154396 3979894	RADIATOR HOSE	FH12	
	1665940	RADIATOR HOSE LOWER	D12A / FH12	
	1676378	RADIATOR HOSE (EXPANSION TANK)	D12A / FH12	
	1664112	RADIATOR HOSE	F12 / Ch.314000 F10 / Ch.314000	
	1664045	RADIATOR HOSE	F12 / Ch.314000 F10 / Ch.314000	

	OEM NO	DESCRIPTION	NOTES	
	1629909	RADIATOR HOSE	F12 / Ch.314000 F10 / Ch.314000	
	1664386	RADIATOR HOSE	F12 / Ch.314000 F10 / Ch.314000	
	475861	RADIATOR HOSE	F10 / F12	
	-	V-BELT	12,5X1350	
	-	V-BELT	12,5X1375	
	-	V-BELT	12,5X1450	
	-	V-BELT	12,5X1475	
	-	V-BELT	12,5X1700	
	-	V-BELT	13X1400	
	-	V-BELT	17X2350	

	OEM NO	DESCRIPTION	NOTES	
	-	V-BELT	9,5X1175	
	958308	V-BELT	Ø 9,5 X 950	
	958312	V-BELT	Ø 9,5 X 1050	
	958313	V-BELT	Ø 9,5 X 1075	
	958315	V-BELT	Ø 9,5 X 1125	
	958316	V-BELT	Ø 9,5 X 1150	
	952137	V-BELT	Ø 9,5 X 1175	
	950819	V-BELT	Ø 9,5 X 1200	
	958494	V-BELT	Ø 12,5 X 1100	
	958496	V-BELT	Ø 12,5 X 1150	
	950852	V-BELT	Ø 12,5 X 1175	
	958498	V-BELT	Ø 12,5 X 1200	
	947961	V-BELT	Ø 12,5 X 1225	
	958503	V-BELT	Ø 12,5 X 1325	
	950859	V-BELT	Ø 12,5 X 1350	

	OEM NO	DESCRIPTION	NOTES	
	950860	V-BELT	Ø 12,5 X 1375	
	958506	V-BELT	Ø 12,5 X 1400	
	958508	V-BELT	Ø 12,5 X 1450	
	958509	V-BELT	Ø 12,5 X 1475	
	958518	V-BELT	Ø 12,5 X 1700	
	-	V-BELT	Ø 17 X 2350	
	342355	RUBBER CUSHION FRONT ENGINE MOUNT	F88, F89	
	1623745 (1502144) 1502352 1618777	RUBBER CUSHION FRONT ENGINE MOUNT -UPPER-	F7, F10, F12, F16 ch.no.-362893, N7, N10 ch.no.-49000, N12 ch.no.-12000	
	1503490 1503489	RUBBER CUSHION FRONT ENGINE MOUNT -LOWER-	F7, F10, F12, F16 ch.no.-362893, N7, N10 ch.no.-49000, N12 ch.no.-12000	
	1607468	RUBBER CUSHION FRONT ENGINE MOUNT	FL7, FS7, FL10	
	1611420 1593669	RUBBER CUSHION FRONT ENGINE MOUNT	N10 ch.no.49001-, N10 USA TD101GB, NL10 AUS, NL10S, N12 ch.no.12001-, NL12 AUS, NL12BR, NL12S	

	OEM NO	DESCRIPTION	NOTES	
	1622825 20503551	RUBBER CUSHION FRONT ENGINE MOUNT	FH12, FH16	
	352424	RUBBER CUSHION REAR ENGINE MOUNT	F88, F89	
	1573891 1503282	RUBBER CUSHION REAR ENGINE MOUNT	F10, F12, N10 ch.no.31104-, NL10 AUS, NL10BR, NL10S, N12 ch.no.5551-, NL12 AUS, NL12BR, NL12S	
	1613624 1591598	RUBBER CUSHION REAR ENGINE MOUNT	FE7 TD71FAQ with gearbox R1000, FL7, FS7, FL10, F10 ch.no.25001- F12 ch.no.314000-, B6 ch.no.5000-	
	1629614 20399980	RUBBER CUSHION REAR ENGINE MOUNT	FH12, FH16	
	3198122	RUBBER CUSHION REAR ENGINE MOUNT	FM10, FM12	
	1580440	RUBBER CUSHION, EXHAUST SYSTEM	ALL MODELS	
	476343	SUSPENSION RUBBER, RADIATOR	F10 ch.no.-19625, F12 ch.no.-34000, F12 ch.no.34001- TD121G/GD	
	1660079	SUSPENSION RUBBER, RADIATOR	F10; TD101F, TD101FA, TD102F, TD102FD, TD102FF, TD102FL, TD102FM, TD103ES, F12; TD120F ch.no.24820-, TD121F, TD121FD, TD122FA, TD123E, TD123ES	
	8153756	SUSPENSION RUBBER, RADIATOR	N10, N12	

	OEM NO	DESCRIPTION	NOTES	
	420991	RUBBER CUSHION, OIL PAN SCREW	TD63E, TD63ES, TD71FS, TD71FSQ, TD73E, TD73ES, TD102, TD103, TD122, TD123,D6A, D7A, D7B, D7C, D10A, B12 ch.5000- with engine/med motor D12.	
	943353	PLASTIC RIVET, OIL PAN GASKET	TD63E, TD63ES, TD71FS, TD71FSQ, TD73E, TD73ES, TD102, TD103, TD122, TD123,D6A, D7A, D7B, D7C, D10A, B12 ch.5000- with engine/med motor D12.	
	940096 1275379	RUBBER SEAL, OIL FILLER CAP	TD100, TD120	
	1542781	SEALING RING	TD100, TD101, TD102 TD120, TD121, TD122	
	20471422	SUPPORT BEARING KIT PROPELLER SHAFT	FH12 / FH16 FM7 / FM9 / FM10 FM12 / NH12	
	20471428 1068222	SUPPORT BEARING KIT PROPELLER SHAFT	FH12 / FH16 FM7 / FM9 / FM10 FM12 / NH12	
	20362601	SUPPORT BEARING KIT PROPELLER SHAFT Ø45x19	FH12 / FH16 FM7 / FM9 / FM10 FM12 / NH12	
	337321	BEARING CAGE PROPELLER SHAFT	F86, FB86, F87, F88, G88, F89, G89, F7, F10, F12, N86, NB86, N88, NB88, N7, N10, N12, B57, B58	
	-	SUPPORT BEARING PROPELLER SHAFT FOR. 67.96389	F6, F6S, F7, FE7, FL7, F10, FL10, F12N7, N10, NL10S, N12, B58BR, B7, B7F, B9M, B10M	
	-	SUPPORT BEARING PROPELLER SHAFT FOR. 67.3567	FL7, FL10, F10, F12, FH12, F16, FH16, N10, NL10, NL10S, N12, NL12 AUS, NL12S	

	OEM NO	DESCRIPTION	NOTES	
	263006 1651230	CLAMP, SUPPORT BEARING PROPELLER SHAFT	FOR 67.96389 FOR 67.3567	
	1696389	SUPPORT BEARING PROPELLER SHAFT KIT BEARING INNER DIAM Ø 60mm	F6, F6S, F7, FE7, FL7, F10, FL10, F12N7, N10, NL10S, N12, B58BR, B7, B7F, B9M, B10M	
	263567 8171366	SUPPORT BEARING PROPELLER SHAFT KIT BEARING INNER DIAM Ø 70mm	FL7, FL10, F10, F12, FH12, F16, FH16, N10, NL10, NL10S, N12, NL12 AUS, NL12S	
	1591023	BEARING, CROSS MEMBER	N10, N12, F10, F12 NL10, NL12, FL10 FH12, FH16	
	1606200 1080690	V STAY	F88, F89, F10, F12 N10, N12, F16, FL10 FL12	
	8154018 1581527 1607079 8158206	REACTION ROD	F88, F89, F10, F12 N10, N12, F16, FL10 FL12	
	1082104 1605035	TIE ROD	NEW MODELS	
	3173294 1628433	V STAY	NEW MODELS	
	1134566	RUBBER MOUNTING	F10 / F12	
	20390840	RUBBER CUSHION, CAB MOUNTING	FM7 / FM10 / FM12	

	OEM NO	DESCRIPTION	NOTES	
	1576051	PAD, CLUTCH PEDAL	ALL MODELS	
	1272021 666176	PAD, CLUTCH PEDAL	ALL MODELS	
	351111	RUBBER MOUNTING Ø10X1,5X60,5X100,5X 40	ALL MODELS	
	1570777	RUBBER MOUNTING Ø75X75X39	ALL MODELS	
	1079256	STABILIZER BEARING Ø65X120X95	FH12/ FH16 / FM7	
	9516524	STABILIZER BEARING Ø 55X93X95	B9 / B10 / B12	
	9519245	STABILIZER BEARING Ø 58,5X100,5X95	FL7 (6X2) / FM7	
	9959304	STABILIZER BEARING Ø 50X92X95	B9 / B10 / B12 / B58 FL608	
	1135086	NUT M16X2X25XSW-30	F10 / F12 / F16 / FL10 / N10 / N12 / FH12 / FH16	
	1135085	NUT M16X28X25	F10 / F12 / F16 / FL10 / N10 / N12 / FH12 / FH16	

	OEM NO	DESCRIPTION	NOTES	
	1628112	STABILIZER BEARING	F10 / F12 / F16 / FL10 / N10 / N12 / FH12 / FH16	
	3091587 3090936	RUBBER BUSHING Ø16,2X45,5X100	FH12 / FH16 / FM12	
	3090935	RUBBER BUSHING	FH12 / FH16	
	3090934	RUBBER BUSHING Ø20X46X50	FH12 / FH16 / FM12	
	273375	REPAIR KIT, V-STAY AXLE ROD (ARM OUTER) 90 MM	F7, FL7, F10, FL10, N10, N10BR, F12, N12, N12BR	
	273706 276191	REPAIR KIT, V-STAY AXLE ROD 45 MM		
	273374	REPAIR KIT, V-STAY A-ARM CENTER 43 MM	F10, N10, N12	
	271188	REPAIR KIT, V-STAY AXLE ROD (INNER) 37 MM	FL7, FL10, FL12, F10, F12, F16, N10	
	3090712	REPAIR KIT, V-STAY M14x1,5X90X60	FH12 / FH16 / NH12 FM9 / FM10 / FM12	
	3090015	REPAIR KIT, AXLE ROD Ø 20X46X60	B6 / FL6 / FL608	

	OEM NO	DESCRIPTION	NOTES	
	274070	REPAIR KIT, REACTION ROD Ø 75X21X130	F10 / F12 / FL10 / FL12 / NH12 / NL10 NL12	
	275988	REPAIR KIT, REACTION ROD Ø 67X17X100	F10 / F12 / FL10 / FL12 / NH12 / NL10 NL12	
	274019 273373	REPAIR KIT, REACTION ROD Ø 85 X 130 X 21	F7, FL7, F10, FL10, F12, N10, N10BR, N12, FH12	
	274068	REPAIR KIT, REACTION ROD (OUTER) Ø 85 X 152 X 21	F7, FL7, F10, FL10, N10, F12, N12	
	271187	REPAIR KIT, REACTION AXLE ROD (OUTER) Ø 75 X 115 X 17	FL7, FL10, FL12, F10, F12, F16, N10	
	274056 (276192)	REPAIR KIT, REACTION AXLE ROD (OUTER) Ø 95 X 152 X 23	FL10, F7, F10, F12, N10, N12, NL10, NL12	
	1075255 (1591689) 3173759 20554908	BUSHING, V-STAY	Rear Suspension: F7, FL7, FL10, F10 ch.25001-, F12 ch.34001-, FH12, FL12, F16, FH16, NL10BR 6x2, NL12BR 6x2 ch.635001-, B9M, B10M Front Suspension: B10B, B9M, B10M ch.20001-, B12	
	1598588	BUSHING, V STAY /REACTION ROD/CROSS STAY	FL608-619, F7, FL7, F10, FL10, F12, FH12, F16, FH16, NL10BR, NL12BR, B58BR, B9M, B10B, B10M, C10M, B12	
	1614355	BUSHING, V STAY /REACTION ROD/CROSS STAY	FL608-619, F7, FL7, FS7, F10, FL10, F12, FH12, FL12, F16, FH16, B9M, B10B, B10M, C10M, B12	
	1628107	BUSHING, V-STAY	FH12, FH16	

	OEM NO	DESCRIPTION	NOTES	
	1135080	BUSHING, V STAY/REACTION ROD	FL608-615, B9M, B10M, FL612-619, FL7, FS7, F10, FL10, F12, FH12, FL12, F16, FH16, B10B, B9M, B10M, B12	
	1136891	BUSHING, V STAY/REACTION ROD	B10M, B10MBR, B10B, B10DD, B12, B12BR	
	1581543	BUSHING BEARING BOGIE	F88, G88, F7, FL7, F10, FL10, F12, FH12, F16, FH16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S	
	1620443	BUSHING BEARING BOGIE	FH12, FH16	
	1580214	RUBBER CUSHION	FL7, FL10, F7, F10, F12, F16, N10, N12, NL10, NL12	
	1605182	PLASTIC BUSHING, UPPER REAR ANTI- ROLL BAR INNER DIAM. 55 MM 4X2, 6X2, 6X4, 8X4	FL7, F10 ch.25001- FL10, F12 ch.34001- FL12, FH12, FH16, F16	
	1605047	PLASTIC BUSHING, LOWER REAR ANTI- ROLL BAR INNER DIAM. 60 MM 4X2, 6X2, 6X4, 8X4	FL7, F10 ch.25001- FL10, F12 ch.34001- FL12, FH12, FH16, F16	
	1607561	PLASTIC BUSHING, LOWER REAR ANTI- ROLL BAR INNER DIAM. 65 MM 4X2, 6X2, 6X4, 8X4	FL7, F10 ch.25001- FL10, F12 ch.34001- FL12, FH12, FH16, F16	
	3028447 9518272	PLASTIC BUSHING, ANTI-ROLL BAR INNER DIAM. 45 MM	B9, B10, B12	
	3028448 9516523	PLASTIC BUSHING, ANTI-ROLL BAR INNER DIAM. 50 MM	B9, B10, B12	

	OEM NO	DESCRIPTION	NOTES	
	3028449 9516524	PLASTIC BUSHING, ANTI-ROLL BAR INNER DIAM. 55 MM	B9, B10, B12	
	9516579	PLASTIC BUSHING, FRONT AND REAR ANTI-ROLL BAR INNER DIAM. 60 MM	B9M, B10M; ch.20001- 43953, B12, B12BR	
	1575339	RUBBER BUSHING, REAR ANTI-ROLL BAR 6X2/8X2/6X4/8X4	F86, FB86, F87, F7, FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N7, N10, NL10S, N12, NL12S	
	1573032	RUBBER BUSHING, REAR ANTI-ROLL BAR	F7,F10,F12	
	1609768	RUBBER BUSHING, REAR ANTI-ROLL BAR	FL7, F10, FL10, F12, FL12, FL16, NL10S, N12S	
	363864	RUBBER BUSHING	F7, F10, F12, N7, N10, N12, B58	
	1629169	RUBBER BUSHING, REAR ANTI-ROLL BAR	FH12, FH16	
	6772312 (6856049)	RUBBER BUSHING	FL4, FL608-614, F610, F611, F612, F613, F614, F615, F616	
	1580009	RUBBER BUSHING, REAR ANTI-ROLL BAR UPPER	F86, FB86, F87, F89, G89, F7, FL7, F10, FL10, F12, FL12, F16, N7, N10, NL10 AUS, NL10S, N12, N12 AUS, NL12S	
	1580010	RUBBER BUSHING, REAR ANTI-ROLL BAR LOWER	F86, FB86, F87, F89, G89, F7, FL7, F10, FL10, F12, FL12, F16, N7, N10, NL10 AUS, NL10S, N12, N12 AUS, NL12S	


	OEM NO	DESCRIPTION	NOTES	
	1587261	RUBBER BUSHING, REAR ANTI-ROLL BAR L=26 mm	FL7, F10, FL10, F12, FL12, F16, NL10S, NL12S	
	1624611	PLASTIC BUSHING FRONT ANTI-ROLL BAR	FH12, FH16	
	1611551	PLASTIC BUSHING, FRONT ANTI-ROLL BAR	FL616-619, F7, FL7, FS7, F10, FL10, F12, F16, N7, N10, NL10 AUS, NL10S, N12, N12 AUS, NL12S	
	1589807	PLASTIC BUSHING, FRONT ANTI-ROLL BAR	FL616-619, F7, FL7, FS7, F10, FL10, F12, F16, N7, N10, NL10 AUS, NL10S, N12, N12 AUS, NL12S	
	1077594	BUSHING ANTI-ROLL BAR FRONT AIR SUSPENSION INNER DIAM: 75mm	FH12, FH16, FM7, FM12	
	6875470	RUBBER BEARING, ANTI-ROLL BAR 43X61/68X69	FL6, FL7	
	6771515	RUBBER BEARING, ANTI-ROLL BAR 45X60/70X70	FL6, FL7	
	1570910 8152645	PLASTIC BUSHING CABIN	F10,F12,F16	
	1134962	RUBBER BUSHING, ANTI-ROLL BAR/SHOCK ABSORBER	F84, F85, F86, FB86, F87, FB88, G88, F89, G89, FL4, F6, FE6, F6, FL7, FS7, F10, FL10, F12, FL12, F16, N88, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B57/58	
	1628318	BUSHING, FRONT ANTI-ROLL BAR	FL616-619, FS7, FH12, FH16	

	OEM NO	DESCRIPTION	NOTES	
	1075179	RUBBER BUSHING, ANTI-ROLL BAR	FH12, FH16	
	1075180	RUBBER BUSHING, ANTI-ROLL BAR	FH12, FH16	
	1075188	RUBBER BUSHING, ANTI-ROLL BAR	FH12, FH16	
	1622838	RUBBER BUSHING, REAR ANTI-ROLL BAR	FL7, FL10, F10, F16, FH12, FH16	
	1588445	SLEEVE, ANTI-ROLL BAR	FL7, F10, FL10, F12, FL12, F16, NL10S, NL12S	
	1625954	SLEEVE, ANTI-ROLL BAR	FL606-615, F7, FL7, FS7, F10, FL10, F12, F16, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S	
	1134955	BUSHING, ANTI-ROLL BAR	FL6, FS7, FL7, F10, FL10, F12, FL12, FH12, F16, FH16, N10, NL10S, N12, NL12S, B58, B7, B10M, C10M, B12	
	1620750	RUBBER BUSHING, REAR ANTI-ROLL BAR	FL7, FL10, F10 ch.314000-, F16, FH12, FH16	
	1624605	RUBBER BUSHING, ANTI-ROLL BAR		
	8152450	PIN REAR ANTI-ROLL BAR REAR AIR SUSPENSION	F12 ch.314000-, F16, FH12, FH16	

	OEM NO	DESCRIPTION	NOTES	
	1620753	PIN REAR ANTI-ROLL BAR REAR AIR SUSPENSION	FL7, FL10, F10 ch.314000-, F12 ch.314000-, F16, FH12, FH16	
	1586089 (1587103)	HOLLOW SPRING 125 MM	F7 ch.-31002, F10 ch.-30788, F12 ch.-42887, N10 ch.-53226, N12 ch.-16009	
	1609657 8151413 1577873 20390836	HOLLOW SPRING 145 MM	F7 ch.31003-, FL7, F10 ch.30789-, FL10, F12 ch.42888-, F16, N10 ch.53227- , N12 ch.16010-, NL10, NL12	
	1629553	HOLLOW SPRING 132 MM	F7 ch.31003-, FL7, FL10, F10 ch.30789-, F12 ch.42888-, FH12, FL12, F16, FH16, N10 ch.53227-, N12 ch.16010-, NL10 AUS, NL10S, NL12 AUS, NL12S	
	1089501	HOLLOW SPRING	FL7, FL10, F10 ch.314000, F12 ch.314000, F16, FH12, FH16	
	1506399	HOLLOW SPRING, REAR AND FRONT SUSPENSION 95X120	F84, F85, F86, FB86, F87, F88, FB88, G88, F89, G89, F7, FL7, F10, FL10, F12, FL12, F16, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B57/58, B9M, B10M	
	1628449	HOLLOW SPRING, REAR AND FRONT SUSPENSION	FH12 / FH16	
	1628397 (1591299)	RUBBER SPACER	FL616-FL619, FE6, FE7, FL7, F7, FL10, B7, F10 ch.25001-, F12 ch.34001-, N10 ch.49001-, N12 ch.12001-, NL10, NL12, F16	
	1614229	SHACKLE PIN FRONT SPRING	F88, G88, F89, G89, F7, FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N88, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S	
	1614230	SHACKLE PIN FRONT SPRING	F7, FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N7, N10, NL10 AUS, NL10S, N12, N12 AUS, NL12S	

	OEM NO	DESCRIPTION	NOTES	
	1075723	SHACKLE PIN FRONT SPRING	FH12, FH16, FM12, NH12 AUS	
	1076334	SHACKLE PIN FRONT SPRING	FH12, FH16, FM12, NH12 AUS	
	1609960	SHACKLE PIN REAR SPRING	F86, F87, F88, G88, F89, G89, F7, FL7, F10, F12, FH12, FL12, F16, FH16, N7, N10, NL10S, N12, NL12S	
	1598764	SHACKLE PIN REAR SPRING	F7, FL7, F10, FL10, F12, FL12, F16	
	1598765	SHACKLE PIN REAR SPRING	F10, F12, F16, FL7, FL10, FL12	
	1598766	SHACKLE PIN REAR SPRING	F10, F12, F16, FL7, FL10, FL12	
	310948	SHACKLE PIN, FRONT AND REAR SPRING	B57, B58	
	1587940	SHACKLE BUSHING REAR SPRING	F7, F10, F12	
	364571	RUBBER BUSHING, CAB	F10, F12	
	1608018	SHACKLE BUSHING REAR SPRING	FL7, F10, F12, FL10, FL12, F16	

	OEM NO	DESCRIPTION	NOTES	
	310947	SHACKLE BUSHING FRONT AND REAR SPRING	F88, G88, F89, G89, B7F, B57, B58	
	1504550	SHACKLE BUSHING FRONT AND REAR SPRING	F86, F87, F88, G88, F89, G89, F7, FL7, F10, F10, F12, FH12, FL12, F16, FH16, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S	
	1075726	SHACKLE BUSHING FRONT AND REAR SPRING	FH12, FH16, FM12, NH12 AUS	
	1598721	SHACKLE BUSHING REAR SPRING	FL7, F10, FL10, F12, FL12, F16	
	1586973	BOLT M20 X 2,5 X 126,5	F7, F10, F12, F16 FL7, FL16, N7, N10, N12, NL10, NL12	
	1584893	BOLT M20 X 2,5 X 146	F7, F10, F12, F16 FL7, FL16, N7, N10, N12, NL10, NL12	
	1608019	SHACKLE BUSHING REAR SPRING	FL7, F10, F12, FL10, FL12, F16	
	1096625	BUMP STOP	FH12	
	8142168	SLEEVE, BUSHING	FH12	
	980547	SCREW	FH12	


	OEM NO	DESCRIPTION	NOTES	
	1075341	WASHER	FH12	
	1075399	SLEEVE, BUSHING	FH12	
	8142699	SCREW	FH12, FH16	
	1075266	RUBBER BUSHING, CAB	FH12, FH16	
	8143461	RUBBER BUSHING, CAB	FH12, FH16	
	6793185 1080637	CAB ANCHORAGE, FRONT	NL10, NL12	
	1590946	U-BOLT M24X3X434	F7, F10, F16, FL7, FL10, FL12, FH16, N10, N10BR, NL10, N12, NL12	
	1585096	U-BOLT M24X3X395	F7, F10, F12, F16, FH16, FL7, FL10, FL12, N10, N12, M10, BR, N12BR, NL10, NL12, NL10BR, NL12BR	
	1590942	U-BOLT M20X3X305	F7, F10, F12, F16, FH16, FL7, FL10, FL12, N7, FL10, FL12, N7, N10, N12, NL10, NL12	
	947506	U-BOLT M20X3X540	F7, F10, F12, F16, FH16, FL7, FL10, FL12, N7, FL10, FL12, N7, N10, N12, NL10, NL12	
	6853940	U-BOLT M 18X180	FL608 / FL615	
	20442787	U-BOLT M 20X210	F10 / F12 / F16 FH12 / FH16 / NH12	
	20400378	U-BOLT M 20X460	FL608 / FL615	
	20375242	U-BOLT M 24X285	F10 / F12 / F16 FH12 / FH16 / NH12	



	OEM NO	DESCRIPTION	NOTES	
	1134445 1199873 1590136 1622111	AIR BELLOW FOR AIR SPRING FRONT AND REAR 644 N	FL608-615, FL7, F10, F12, B9M, B10M, B10R, B12, C10M, FH12, FH16	
	1137888	AIR BELLOW FOR AIR SPRING FRONT 661 N	F12, B9M, B10M, B10MBR	
	1075290	AIR BELLOW, FOR AIR SPRING	CONTI NO: 1421N	
	159842	AIR BELLOW, FOR AIR SPRING	CONTI NO: 916N1	
	1593842	AIR BELLOW, FOR AIR SPRING	CONTI NO: 716N	
	1611776 6135049	AIR BELLOW, FOR AIR SPRING	CONTI NO: 673N	
	1612455	AIR BELLOW, FOR AIR SPRING	CONTI NO: 768N	
	1622116 6797169	AIR BELLOW, FOR AIR SPRING	CONTI NO: 713N	
	1629193	AIR BELLOW, FOR AIR SPRING	CONTI NO: 720N	
	3027271	AIR BELLOW, FOR AIR SPRING	CONTI NO: RZ415-25	

	OEM NO	DESCRIPTION	NOTES	
	3027272	AIR BELLOW, FOR AIR SPRING	CONTI NO: RZ415-28	
	8147475	AIR BELLOW, FOR AIR SPRING	CONTI NO: 1924N1	
	20554755 1076594	AIR BELLOW, FOR AIR SPRING	CONTI NO: 4713 NP 012	
	1082085	AIR BELLOW, FOR AIR SPRING	CONTI NO: 883N1	
	1134446	AIR BELLOW, FOR AIR SPRING	CONTI NO: 727N	
	20554756 1076595	AIR BELLOW, FOR AIR SPRING	CONTI NO: METALLI	
	20456152 20582215	AIR BELLOW, FOR AIR SPRING	CONTI NO: 6608 NP 01	
	1080707	AIR BELLOW, FOR AIR SPRING	CONTI NO: 810MB	
	1575798	AIR BELLOW, FOR AIR SPRING	CONTI NO: 813MB	
	1089014	BUFFER, CAB	FL7, FL10, FL12	

	OEM NO	DESCRIPTION	NOTES	
	4737160	PAD	BM 5350	
	4940758	DRIVER CABIN'S CEAT	BM 5350	
	4821431	PAD	BM 5350	
	47371110	PAD	BM 5350	
	11054102	SPRING BLOCK	BM 5350	
	11056369	SPRING BLOCK	BM5350 A25-B / A25	
	11055842	SPRING BLOCK	A35	
	-	PAD	BM5350 / A35	
	11052112	RUBBER BEARING	A-25C / A-30C	
	4940758	DRIVER CABIN'S CEAT	BM5350	

	OEM NO	DESCRIPTION	NOTES	
	11055899	FRONT-BACK DIFFERENTIAL BUSHING	A35	
	11052293	RUBBER BEARING	A35 - C	
	383972	DIAPHRAGM, REAR AXLE	N10, N12, F10, F12 NL10, NL12, FL10	
	424692	VALVE COVER GASKET		
	1543581	VALVE COVER GASKET		
	8148490 1677556	COVER RUBBER		
	8148519 1547591	COVER RUBBER		
	1547594	VALVE COVER GASKET		
	8170116	VALVE COVER GASKET		
	422541	SCREW, INSCPECTION COVER		

	OEM NO	DESCRIPTION	NOTES	
	346822	OIL SEAL	10*15*3	
	958811	OIL SEAL	15*35*7	
	6876138	OIL SEAL	25*32*5	
	240022	OIL SEAL	25*35*7	
	687348	OIL SEAL	25*35*7	
	244073	OIL SEAL	25*35*7	
	943741	OIL SEAL	26*36*7	
	341050	OIL SEAL	26*37*7/7,5	
	424580	OIL SEAL	29*50*10	
	1546221	OIL SEAL	34,9*62*8	
	6770963	OIL SEAL	42*62*10	
	1543936	OIL SEAL	45*65*8	
	192206	OIL SEAL	45*77*4/7,8	
	947285	OIL SEAL	47,5*76*4/7,7	
	6797454	OIL SEAL	48*65*10	
	6857279	OIL SEAL	48*65*10	
	6876126	OIL SEAL	48*69*10	
	1522373	OIL SEAL	50*65*8	
	192226	OIL SEAL	52*68*6	
	958726	OIL SEAL	55*80*10	
	267316	OIL SEAL	59,9*80*8/10	
	346682	OIL SEAL	60*74*10	
	267268	OIL SEAL	64,9*90*10	
	948826	OIL SEAL	65*80*8	
	6797452	OIL SEAL	65*85*13	
	267075	OIL SEAL	65*90*13	
	6876131	OIL SEAL	70*90*10	
	6876132	OIL SEAL	70*90*10	
	471055	OIL SEAL	76,2/101,68/12	
	477118	OIL SEAL	76,2/101,68/12	
	6790139	OIL SEAL	76,2*125,39/134*16,5/19	
	1610078	OIL SEAL	77*98,4/103*6,3/19,3	
	947269	OIL SEAL	80*95*8	
	267269	OIL SEAL	80*100*10	
	1543908	OIL SEAL	80*100*10	
	948448	OIL SEAL	80*110,05*12	
	1522895	OIL SEAL	80*130,2*12/20	
	1522894	OIL SEAL	80*150*12/20	
	947270	OIL SEAL	85*110*13	

	OEM NO	DESCRIPTION	NOTES	
	469507	OIL SEAL	85,73*114,33*13	
	1669618	OIL SEAL	90*110*11	
	1652622	OIL SEAL	90*111*6/8	
	948642	OIL SEAL	90*125,25*10	
	1652776	OIL SEAL	90*145*10	
	1523239	OIL SEAL	90*145*10/15	
	1523634	OIL SEAL	90*151*10/15	
	520247	OIL SEAL	90*151*11/17	
	947271	OIL SEAL	95*110*10	
	968012	OIL SEAL	100*120*12	
	1070379	OIL SEAL	100*120*12	
	1593459	OIL SEAL	100*140*15,5/20	
	1526828	OIL SEAL	105*130*12	
	1526829	OIL SEAL	105*130*12	
	6773195	OIL SEAL	110*130*12	
	968013	OIL SEAL	110*130*12	
	1089552	OIL SEAL	110*140*12/19	
	1587792	OIL SEAL	110*140*12/21	
	944664	OIL SEAL	117*137/139*32	
	1696066	OIL SEAL	120*140*13	
	946026	OIL SEAL	120,65*152,4*13/1 2	
	946093	OIL SEAL	125*150*13	
	477119	OIL SEAL	127*150*13	
	946027	OIL SEAL	127*169,86*13/14	
	944667	OIL SEAL	133,35*155,6*14	
	1672249	OIL SEAL	140*164*15,5/18	
	1522372	OIL SEAL	140*164*20/23,5	
	944665	OIL SEAL	148*170,2*31,5	
	1522086	OIL SEAL	150*180*10	
	1524281	OIL SEAL	150*180*10	
	1522896	OIL SEAL	150*180*16/18	
	469336	OIL SEAL	155*180*15	
	944666	OIL SEAL	168*188/192,5*30	
	1610765	OIL SEAL	168*188/192,5*30	
	1543896	OIL SEAL	180*205*15	
	3090331	OIL SEAL	ALL	
	273394	OIL SEAL	150*180*10/16	


	OEM NO	DESCRIPTION	NOTES	
	275037	PISTON AND LINER SET 95,25 MM	D50A, D50B, TD50A, TD50B	
	275389 (275066) (275057)	PISTON AND LINER SET 98,43 MM	TD60B, TD60C	
	275394 (275078)	PISTON AND LINER SET 98,43 MM	TD61F, TD61G, TD61GS	
	275379 (275039) (275029)	PISTON AND LINER SET 104,775 MM	D70A, D70B, MD70B	
	275384 (275055) (275040)	PISTON AND LINER SET 104,775 MM	TD70A, TD70B	
	275383 (275054)	PISTON AND LINER SET 104,775 MM	TD70F, TD70FS, TD70G	
	275628 (275079) (275094)	PISTON AND LINER SET 104,775 MM	TD71ACE, TD71AG, TD71AGP, TD71AP, TD71APB, TD71AW, TD71E, TD71F, TD71FQ, TD71FS, TD71FSQ, TD71G, TD73E, TD73G	
	275099 (275036)	PISTON AND LINER SET 120,65 MM	TD100A, THD100D	
	275380 (275044)	PISTON AND LINER SET 120,65 MM	TD100B	
	275639 (275391)	PISTON AND LINER SET 120,65 MM	TD100BG	

	OEM NO	DESCRIPTION	NOTES	
	275396 (275077) (275068) (275083)	PISTON AND LINER SET 120,65 MM	TD100F, TD100G	
	275627 (275089)	PISTON AND LINER SET 120,65 MM	TD101F, TD101FA, TD101FD, TD101G	
	275636	PISTON AND LINER SET 120,65 MM	FL10 / TD102	
	275386 (275060)	PISTON AND LINER SET 130,175 MM	TD120A, TMD120A	
	275385 (275059)	PISTON AND LINER SET 130,175 MM	TSMD120A*, TAMD120AK*, TAMD120B*, TAMD120BCC*, TAMD120C*, TAMD120E* *To Engine -468702	
	275393 (275074)	PISTON AND LINER SET 130,175 MM	TAMD120A*, TAMD120AK*, TAMD120B*, TAMD120BCC*, TAMD120C*, TAMD120E*, TD120C*, TD120D*, TD120E* *From Engine 470130-	
	275398 (275085) (275061) (275397) (275086) (275069)	PISTON AND LINER SET 130,175 MM	TAMD120*, TD120F*, TD120G*, TD120GA*, TD121D*, TD121F*, TD121G*, TMD121C* *To Engine -468702	
	275626 (275399) (275087) (275061) (275075) (275076)	PISTON AND LINER SET 130,175 MM	TAMD120*, TD120F*, TD120G*, TD120GA*, TD121D*, TD121F*, TD121G*, TMD121C* *From Engine 470130-	
	275635	PISTON AND LINER SET 130,175 MM	TD120F, TD120G, TD120GA, TD121F, TD121D, TD121G	
	275633 (275092)	PISTON AND LINER SET 130,175 MM	TID121FG, TAMD122A, TD122F, TD122FK, TD122FR, TD122FS, TD122GA	

	OEM NO	DESCRIPTION	NOTES	
	275634	PISTON AND LINER SET 130,175 MM	TD122F USA, TD122FH, TD122FL	
	275643	PISTON AND LINER SET 144,01 MM	TD162F, TD162FL, TD162FS	
	275644	PISTON AND LINER SET 144,01 MM	F16 / TD162FL	
	3826843	PISTON AND LINER SET 144,01 MM	TD162C	
	-	CYLINDER LINER 95,25 MM	D50A, D50B, TD50A, TD50B	
	-	CYLINDER LINER 98,43 MM	D60, TD60A, TD60B, TD60C	
	465174	CYLINDER LINER 98,43 MM	TD60A, TD61F, TD61G, TD61GS, TID61A, TID61ACE	
	466684	CYLINDER LINER 104,775 MM	D70A, TD61F, MD70B, TD70A, TD70B, TD70E, TD70ES, TD70H, TD70HA, TD70F, TD70FS, TD70G	
	-	CYLINDER LINER 104,775 MM	TD71ACE, TD71AG, TD71AGP, TD71AP, TD71APB, TD71AW, TD71E, TD71F, TD71FQ, TD71FS, TD71FSQ, TD71G, TD73E, TD73G	
	422094	CYLINDER LINER 120,65 MM	D100A, D100B, HD100A, MD100B, THD100A, TMD100A, TD100A, THD100D	




	OEM NO	DESCRIPTION	NOTES	
	467384	CYLINDER LINER 120,65 MM	TD100B	
	-	CYLINDER LINER 120,65 MM	TD100BG, TD100F, TD100G, THD100DB, THD100DC, THD100DD, THD100E, THD100EB, THD100EC	
	479604	CYLINDER LINER 120,65 MM	TD101F, TD101FA, TD101FD, TD101G, TD101KC, TD101G, THD101GC, THD101GD, THD101K, THD101KB, THD101KC, THD101MC	
	-	CYLINDER LINER 120,65 MM	TD102F*, TD102FD*, TD102FDQ*, TD102FF*, TD102FQ* *Engine: Euro1 TD102FL, TD102FM, TD102GB	
	468834	CYLINDER LINER 130,175 MM	TD120A, TMD120A, TAMD120A*, TAMD120AK*, TAMD120B, TAMD120BCC*, TAMD120C*, TAMD120E*, TD120C*, TD120D*, TD120G*, TD120GA*, TD121D*, TD121F*, TD121G*, TMD121C*, *To Engine -468702	
	470480	CYLINDER LINER 130,175 MM	TAMD120A*, TAMD120AK*, TAMD120B*, TAMD120BCC*, TAMD120C*, TAMD120E*, TD120C*, TD120D*, TD120E*, TD120F*, TD120G*, TD120GA*, TD120G*, TD120GA*, TD121D*, TD121F*, TD121G*, TD121F*, *From Engine 470130- TD122F USA, TD122FH, TD122FL	
	478141	CYLINDER LINER 130,175 MM	TD121D, TD121G, TAMD122S, TID121FG, TD122F, TD122FK, TD122FR, TD122FS, TD122GA	
	-	CYLINDER LINER 130,175 MM	TD123E, TD123ES	
	-	CYLINDER LINER 130,175 MM	D12A, FH12	
	-	CYLINDER LINER 144,01 MM	TD162F, TD162FL, TD162FS	




	OEM NO	DESCRIPTION	NOTES	
	-	CYLINDER LINER 144,01 MM	TD162C	
	-	PISTON AND RINGS 95,25 MM	D50A, D50B, TD50A, TD50B	
	-	PISTON AND RINGS 98,43 MM	TD60B, TD60C, TD61F, TD61G, TD61GS	
	-	PISTON AND RINGS 104,775 MM	D70 , TD70 , MD70B	
	-	PISTON AND RINGS 104,775 MM	TD70A , TD70B , TD70F, TD70FS, TD70G	
	-	PISTON AND RINGS 104,775 MM	TD71ACE, TD71AG, TD71AGP, TD71AP, TD71APB, TD71AW, TD71E, TD71F, TD71FQ, TD71FS, TD71FSQ, TD71G, TD73E, TD73G	
	-	PISTON AND RINGS 120,65 MM	TD100A, THD100D	
	-	PISTON AND RINGS 120,65 MM	TD100B, TD100BG	
	-	PISTON AND RINGS 120,65 MM	TD100F, TD100G, TD101F, TD101FA, TD101FD, TD101G	
	-	PISTON AND RINGS 120.65 MM	TD102	

	OEM NO	DESCRIPTION	NOTES	
	-	PISTON AND RINGS 130,175 MM	TD120A, TMD120A	
	-	PISTON AND RINGS 130,175 MM	TAMD120A*, TAMD120AK*, TAMD120B*, TAMD120BCC*, TAMD120C*, TAMD120E*, TD120C*, TD120D*, TD120E* *Engine -468702, 470130-	
	-	PISTON AND RINGS 130,175 MM	TAMD120*, TD120F*, TD120G*, TD120GA*, TD121D*, TD121F*, TD121G*, TMD121C*, *Engine -468702, 470130- TD120F, TD120G, TD120GA, TD121F, TD121D, TD121G	
	-	PISTON AND RINGS 130,175 MM	TID121FG, TAMD122A, TD122F, TD122FK, TD122FR, TD122FS, TD122GA	
	-	PISTON AND RINGS 130,175 MM	TD122F USA, TD122FH, TD122FL	
	-	PISTON AND RINGS 144,01 MM	TD162F, TD162FL, TD162FS	
	-	PISTON AND RINGS 144,01 MM	TD162C	
	275305	PISTON RING SET 95,25 MM	D50A, D50B, TD50A, TD50B	
	270713 (275376) (275320)	PISTON RING SET 98,43 MM	D60A, TD60A, TD60B, TD60C, TD61B, TD61F, TD61FB, TD61FBQ, TD61FHQ, TD61G, TD61GA, TD61GB, TD61GC, TD61GE, TD61GS	
	275308	PISTON RING SET 104,775 MM	D67A, D70A, D70B, TD70A, TD70B, TD70C	

	OEM NO	DESCRIPTION	NOTES	
	275375 (275312)	PISTON RING SET 104,775 MM	TD70F, TD70FS, TD70G, TD71A, TD71F, TD71GE	
	271117	PISTON RING SET 104,775 MM	TD71A, TD71ACE, TD71AG, TD71AGP, TD71AP, TD71APB, TD71AW, TD71FQ, TD71FQK, TD71FS, TD71FSQ, TD71F, TD73E, TD73G	
	275304	PISTON RING SET 120,65 MM	D100A, D100B, HD100A, MD100B, THD100A, TMD100A, TD100A, THD100D	
	275084 (275313)	PISTON RING SET 120,65 MM	TD100B, TD100BG, TD100F, TD100G, THD100, TD101F, TD101FA, TD101FD, TD101G, TD101KC, THD101G, THD101GC, THD101GD, THD101KC	
	270790	PISTON RING SET 120,65 MM	TD102F, TD102FD, TD102FDQ, TD102FF, TD102FH, TD102FL, TD102FM, TD102FQ, TD102FS, THD102KD	
	276197	PISTON RING SET 120,65 MM	TD103	
	270603 275321	PISTON RING SET 130,175MM	TAMD120, TAMD120B, TD120A, TD120C, TD120G, TD120E, TD120F, TD120G, TD120GA, TMD120A, TD121D, TD121F, TD121G, TMD121C, TD122F, TD122FK, TD122FR, TD122FS	
	276167	PISTON RING SET 130,175MM	TD123E, TD123ES	
	276036	PISTON RING SET 144,01MM	TD162F, TD162FS	
	3826935	PISTON RING SET 144,01MM	TD162C	

	OEM NO	DESCRIPTION	NOTES	
	276132	PISTON RING SET	FH12 / D12 A/B	
	85103174	PISTON RING SET	FH12 / D12 C/D	
	275460	CYLINDER LINER SEALING RING KIT	D50A, D50B, TD50A, TD50B	
	271162	CYLINDER LINER SEALING RING KIT	D60A, TD60A, TD60B, TD60C	
	271161	CYLINDER LINER SEALING RING KIT	TD61F, TD61FB, TD61FHQ, TD61G, TD61GA, TD61GB, TD61GC, TD61GE, TD61GS, TD63E, TD63ES, D6A	
	271160	CYLINDER LINER SEALING RING KIT	D70A, D70B, TD70A, TD70B, TD70C, TD70D, TD70E, TD70F, TD70FC, TD70FS, TD70G, TD70H, TD70HA	
	271159	CYLINDER LINER SEALING RING KIT	TD71F, TD71FA, TD71FAQ, TD71FC, TD71FCQ, TD71FD, TD71FQ, TD71FS, TDFSQ, TD71G, TD73E, TD73ES, D7A, D7B	
	271158	CYLINDER LINER SEALING RING KIT	D100, TD100, HD100, THD100, TD101 (eng.no.-199157), THD101 (eng.no.-40891)	
	271157	CYLINDER LINER SEALING RING KIT	TD101 (eng.no.199158-), THD101 (eng.no.40892-), TD102, THD102, TD103, THD103, THD104, D10A, DH10A	
	271181	CYLINDER LINER SEALING RING KIT	TD120A	

	OEM NO	DESCRIPTION	NOTES	
	271156	CYLINDER LINER SEALING RING KIT	TD120C, TD120D, TD120E, TD120F, TD120FA, TD120FB, TD120FC, TD120G, TD120GA	
	271155	CYLINDER LINER SEALING RING KIT	TD121F, TD121FA, TD121FB, TD121FC, TD121FE, TD121FF, TD121FK*, TD121G*, TD121GD* (* eng.no.-131995)	
	270950	CYLINDER LINER SEALING RING KIT	TD121FK*, TD121G*, TD121GD*, TD122, TD123, D12A (* eng.no.131996-)	
	270935	CYLINDER LINER SEALING RING KIT	TD162F, TD162FL, TD162FS, TD163ES, D16A	
	-	CYLINDER LINER SEALING RING KIT	VOLVO BM Ø 105,57 mm	
	-	CYLINDER LINER SEALING RING KIT	VOLVO BM Ø 111,12 mm	
	465394	SHIM (THICKNESS 0,20MM) CYLINDER LINER ADJUSTING SHIM	D60, TD60, TD61, TD63	
	465395	SHIM (THICKNESS 0,30MM)	D60, TD60, TD61, TD63	
	465396	SHIM (THICKNESS 0,50MM)	D60, TD60, TD61, TD63	
	466878	SHIM (THICKNESS: 0,12MM) CYLINDER LINER ADJUSTING SHIM	D70, TD70, TD71, TD73	
	466114	SHIM (THICKNESS 0,20MM)	D70, TD70, TD71, TD73	
	466183	SHIM (THICKNESS 0,30MM)	D70, TD70, TD71, TD73	
	466184	SHIM (THICKNESS 0,50MM)	D70, TD70, TD71, TD73	

	OEM NO	DESCRIPTION	NOTES	
	422619	SHIM (THICKNESS 0,20MM) CYLINDER LINER ADJUSTING SHIM	D100, TD100, TD101, TD102, , TD103, THD104, D10A, DH10A	
	422620	SHIM (THICKNESS 0,30MM)	D100, TD100, TD101, TD102, , TD103, THD104, D10A, DH10A	
	422621	SHIM (THICKNESS 0,50MM)	D100, TD100, TD101, TD102, , TD103, THD104, D10A, DH10A	
	468271	SHIM (THICKNESS 0,20MM) CYLINDER LINER ADJUSTING SHIM	TD120, TD121, TD122, TD123	
	468272	SHIM (THICKNESS 0,30MM)	TD120, TD121, TD122, TD123	
	468273	SHIM (THICKNESS 0,50MM)	TD120, TD121, TD122, TD123	
	1677591	SHIM (THICKNESS 0,20MM) CYLINDER LINER ADJUSTING SHIM	D12A; FH12	
	1677592	SHIM (THICKNESS 0,30MM)	D12A; FH12	
	1677593	SHIM (THICKNESS 0,50MM)	D12A; FH12	
	465816 (420257)	BUSHING, CONNECTING ROD	D50, TD50, TD60, TD61 TD63	
	421142	BUSHING, CONNECTING ROD	D70, TD70	
	471364	BUSHING, CONNECTING ROD	TD71	
	417463	BUSHING, CONNECTING ROD	TD100A, TD100B	

	OEM NO	DESCRIPTION	NOTES	
	271230	MAIN BEARING SET STD.	D50A, D50B, TD50A, TD50B, D60, TD60A, TD60B, TD60C, TD61F, TD61G, TD61GS, TD63ES, TD63E	
	271231	MAIN BEARING SET 0,25MM		
	271232	MAIN BEARING SET 0,50MM		
	271233	MAIN BEARING SET 0,75MM		
	271234	MAIN BEARING SET 1,00MM		
	270432	MAIN BEARING SET STD.	D70A, D70B, TD70A, TD70B, TD70ES, TD70F, TD70FS, TD70G, TD71A, TD71F, TD71FQ, TD71FQK, TD71FS, D71FSQ, TD71G, TDF71F, TD73E, TD73G	
	270433	MAIN BEARING SET 0,25MM		
	270434	MAIN BEARING SET 0,50MM		
	270435	MAIN BEARING SET 0,75MM		
	270438	MAIN BEARING SET STD.	D100A, D100B, HD100A, MD100A, M D100B, TD100A D100BG, TD100G, TD100GA, TD100GG, TD100F, THD100, TMD100A, TD101G, TD101GA, TD101FD, TD101FC, TD101FA, TD101F, THD101, TD102FH, TD102FDQ, TD102FQ, TD102FF, TD102FD, TD102FM, TD102FL, TD103ES	
	270439	MAIN BEARING SET 0,25MM		
	270440	MAIN BEARING SET 0,50MM		
	270441	MAIN BEARING SET 0,75MM		
	270449	MAIN BEARING SET STD.	TD120C, TD120E, TD120F, TD120FC, TID120F, TD120G, TD120GA, TD120GG, TD121FD, TD121F, TD121G DTD121G, TD122FA, TD122F, TD122FH, TD122FL, TD122FS, TD122FR, TD122FK, TD123ES, TD123E	
	270450	MAIN BEARING SET 0,25MM		
	270451	MAIN BEARING SET 0,50MM		
	270452	MAIN BEARING SET 0,75MM		
	270792	MAIN BEARING SET STD.	TD162	
	270793	MAIN BEARING SET 0,25MM		
	270794	MAIN BEARING SET 0,50MM		
	478951	THRUST WASHER	TD100, TD101, TD102 TD120, TD121, TD122	

	OEM NO	DESCRIPTION	NOTES	
	270081	CONNECTING ROD BEARING STD.	D50A, D50B, TD50A, TD50B, D60, TD60A, TD60B, TD60C, TD61F, TD61G, TD61GS, TD63ES, TD63E	
	270082	CONNECTING ROD BEARING 0,25MM		
	270083	CONNECTING ROD BEARING 0,50MM		
	270084	CONNECTING ROD BEARING 0,75MM		
	270085	CONNECTING ROD BEARING 1,00MM		
	270139	CONNECTING ROD BEARING STD	D50A, D50B, TD50A, TD50B, D60, TD60A, TD60B, TD60C, TD61F, TD61G, TD61GS, TD63ES, TD63E	
	270140	CONNECTING ROD BEARING 0,25MM		
	270141	CONNECTING ROD BEARING 0,50MM		
	270142	CONNECTING ROD BEARING 0,75MM		
	270143	CONNECTING ROD BEARING 1,00MM		
	270093	CONNECTING ROD BEARING STD.	D70A, D70B, TD70A, TD70B, TD70ES, TD70F, TD70FS, TD70G, TD71A, TD71F, TD71FQ, TD71FQK, TD71FS, TD71FSQ, TD71G, TDF71F, TD73E, TD73G	
	270094	CONNECTING ROD BEARING 0,25MM		
	270095	CONNECTING ROD BEARING 0,50MM		
	270096	CONNECTING ROD BEARING 0,75MM		
	270115	CONNECTING ROD BEARING SET STD.	D70A, D70B, TD70A, TD70B, TD70ES, TD70F, TD70FS, TD70G, TD71A, TD71F, TD71FQ, TD71FQK, TD71FS, TD71FSQ, TD71G, TDF71F, TD73E, TD73G	
	270116	CONNECTING ROD BEARING SET 0,25MM		
	270117	CONNECTING ROD BEARING SET 0,50MM		
	270118	CONNECTING ROD BEARING SET 0,75MM		
	270099	CONNECTING ROD BEARING SET STD.	D100A, D100B, HD100A, MD100A, MD100B, TD100A, TMD100A, TD100B, D100BG, TD100G, TD100GA, TD100GGT, D100F, THD100, TMD100A, TD101G, TD101GA, D101FD, TD101FC, TD101FA, TD101F, THD101, TD102FH, 102FDQ, TD102FQ, TD102FF, TD102FD, TD102FM, TD102FL, TD103ES	
	270100	CONNECTING ROD BEARING SET 0,25MM		
	270101	CONNECTING ROD BEARING SET 0,50MM		
	270102	CONNECTING ROD BEARING SET 0,75MM		
	270124	CONNECTING ROD BEARING SET STD.	D100A, D100B, HD100A, MD100A, MD100B, TD100A, TMD100A, TD100B, TD100BG, TD100G, TD100GA, TD100GG, TD100F, THD100, TMD100A, TD101G, TD101GA, TD101FD, TD101FC, TD101FA, TD101F, THD101, TD102FH, TD102FDQ, TD102FQ, TD102FF, TD102FD, TD102FM, TD102FL, TD103ES	
	270125	CONNECTING ROD BEARING SET 0,25MM		
	270126	CONNECTING ROD BEARING SET 0,50MM		
	270127	CONNECTING ROD BEARING SET 0,75MM		

	OEM NO	DESCRIPTION	NOTES	
	270105	CONNECTING ROD BEARING SET STD.	MD120A, TD120A, TAMD120A, TMD120A, TAMD120B, TD120D, TD120C, TD120E, TD120F, TD120FC, TD120F, TD120G, TD120GA, TD120GG, TD121FD, TD121F, TD121GD, TD121G, TD122FA, TD122F, TD122FH, TD122FL, TD122FS, TD122FR, TD122FK, TD123ES, TD123E	
	270106	CONNECTING ROD BEARING SET 0,25MM		
	270107	CONNECTING ROD BEARING SET 0,50MM		
	270108	CONNECTING ROD BEARING SET 0,75MM		
	270130	CONNECTING ROD BEARING SET STD.	MD120A, TD120A, TAMD120A, TMD120A, TAMD120B, TD120D, TD120C, TD120E, TD120F, TD120FC, TD120F, TD120G, TD120GA, TD120GG, TD121FD, TD121F, TD121GD, TD121G, TD122FA, TD122F, TD122FH, TD122FL, TD122FS, TD122FR, TD122FK, TD123ES, TD123E	
	270131	CONNECTING ROD BEARING SET 0,25MM		
	270132	CONNECTING ROD BEARING SET 0,50MM		
	270133	CONNECTING ROD BEARING SET 0,75MM		
	270796	CONNECTING ROD BEARING SET STD.	TD162	
	270797	CONNECTING ROD BEARING SET 0,25MM		
	270798	CONNECTING ROD BEARING SET 0,50MM		
	276751	THRUST WASHER SET STD.	D50A, D50B, TD50A, TD50B, D60, TD60A, TD60B, TD60C, TD61F, TD61G, TD61GS, TD63ES, TD63E	
	276752	THRUST WASHER SET 0,10		
	276754	THRUST WASHER SET STD.	D70A, D70B, TD70A, TD70B, TD70ES, TD70F, TD70FS, TD70G, TD71A, TD71F, TD71FQ, TD71FQK, TD71FS, TD71FSQ, TD71G, TDF71F, TD73E, TD73G	
	276758	THRUST WASHER SET STD.	D100A, D100B, HD100A, MD100A, MD100B, TD100A, TMD100A, TD100B, TD100BG, TD100G, TD100GA, TD100GG, TD100F, THD100, TMD100A, TD101G, TD101GA, TD101FD, TD101FC, TD101FA, TD101F, THD101, TD102FH, TD102FDQ, TD102FQ, TD102FF, TD102FD, TD102FM, TD102FL, TD103ES	
	276759	THRUST WASHER SET 0,10		
	276760	THRUST WASHER SET 0,20		
	276791	THRUST WASHER SET STD.	MD120A, TD120A, TAMD120A, TMD120A, TAMD120B, TD120D, TD120C, TD120E, TD120F, TD120FC, TD120F, TD120G, TD120GA, TD120GG, TD121FD, TD121F, TD121GD, TD121G, TD122FA, TD122F, TD122FH, TD122FL, TD122FS, TD122FR, TD122FK, TD123ES, TD123E	
	270929	THRUST WASHER SET STD.	TD162	

	OEM NO	DESCRIPTION	NOTES	
	1545302	BUSHING, CONNECTING ROD	TD100B, TD100BG, TD100G, TD100GA, TD101	
	422708	BUSHING, CONNECTING ROD	TD102, TD103	
	423147	BUSHING, CONNECTING ROD	D120, TD120 (eng.no. -80370)	
	470434	BUSHING, CONNECTING ROD	TD120 (eng.no.80371-) , TD121, TD122, TD123	
	470304 (20381185)	BUSHING, CONNECTING ROD	D12A, D12D,D12C / FH12	
	1543034	BUSHING, CONNECTING ROD	TD162	
	420016	VALVE IN	D50A, D50B	
	420192	VALVE EX	D50A, D50B	
	420016	VALVE IN	TD50A, TD50B	
	420017 (420192)	VALVE EX	TD50A, TD50B	

	OEM NO	DESCRIPTION	NOTES	
	420553 (465548) (465281)	VALVE IN	D60, TD60, TD61, TD63	
	465549 (465282) (8192143)	VALVE EX	D60, TD60, TD61, TD63	
	466380	VALVE IN	D70A, D70B, TD70A, TD70B	
	421017	VALVE EX	D70A, D70B, TD70A, TD70B	
	466379	VALVE IN	TD70F, TD70FS, TD70G, TD71E, TD71G, TD71F, TD71FD, TD71FSQ	
	421680 (471195)	VALVE EX	TD70F, TD70FS, TD70G, TD71E, TD71G, TD71F, TD71FD, TD71FSQ	
	477447 3978768	VALVE IN	TD73	
	477443 3978766	VALVE EX	TD73	
	422016	VALVE IN	TD100A	
	422017	VALVE EX	TD100A	
	479204 (479113) (422717) (1545290) (467502)	VALVE IN	TD100, TD101, TD102 TD103	
	467855 (467682)	VALVE EX	TD100, TD101, TD102 TD103	

	OEM NO	DESCRIPTION	NOTES	
	423016	VALVE IN	MD120A, TAMD120A, TMD120A	
	423017	VALVE EX	MD120A, TAMD120A, TMD120A	
	468302	VALVE IN	TD120, TD121, TD122 TD123	
	468303	VALVE EX	TD120, TD121, TD122 TD123	
	1547492 (3169490) (3964398) (3165231)	VALVE IN	FH12; D12A	
	1547490 (8148574)	VALVE EX	FH12; D12A	
	1543026	VALVE IN	F16; TD162F	
	1543027 (1556473)	VALVE EX	F16; TD162F	
	420280	VALVE GUIDE IN-EX	D50A, D50B, TD50A, TD50B	
	465157 (477877) (477792)	VALVE GUIDE IN-EX	D60, TD60, TD61, TD63	

	OEM NO	DESCRIPTION	NOTES	
	1545135 (421297)	VALVE GUIDE IN-EX	D70A, D70B, TD70A, TD70B, TD70C	
	466386	VALVE GUIDE IN-EX	TD70D, TD70E, TD70F, TD70FS, TD70G, TD70H, TD70HA, TD71E, TD71F, TD71FD, TD71FSQ, TD71G	
	422320	VALVE GUIDE IN	D100A, D100B, TD100A, TD100B, TD100BG, TD100G, TD100GA, TD101GA,	
	1545135 (421297) (11129092)	VALVE GUIDE EX	D100A, D100B, TD100A, TD100B, TD100BG, TD100G, TD100GA, TD101GA,	
	422762	VALVE GUIDE IN	TD100A, TD100B, TD100BG, TD100G, TD100GA, TD101GA,	
	422320	VALVE GUIDE IN	TD120A, TD120C, TD120E, TD120F, TD120G, TD121F, TD121G,TD121GD, TD122F, TD122FS	
	1545135 (421297) (11129092)	VALVE GUIDE EX	TD120A, TD120C, TD120E, TD120F, TD120G, TD121F, TD121G,TD121GD, TD122F, TD122FS	
	1546437	VALVA GUIDE IN-EX	FH12, D12A/B/C	
	1556607 (1543862) (20355012)	VALVE GUIDE IN	F16; TD162F, TD163ES, FH16; D16A	
	1556604 (1543864) (20355015)	VALVE GUIDE EX	F16; TD162F, TD163ES, FH16; D16A	

	OEM NO	DESCRIPTION	NOTES	
	420011	VALVE SEAT IN STD.	D50A, D50B, TD50A, TD50B	
	420012	VALVE SEAT EX STD.	D50A, D50B, TD50A, TD50B	
	465158	VALVE SEAT IN STD.	D60, TD60, TD61	
	465155	VALVE SEAT EX STD	D60, TD60, TD61	
	465238	VALVE SEAT IN 0,20	D60, TD60, TD61	
	465236	VALVE SEAT EX 0,20	D60, TD60, TD61	
	421011	VALVE SEAT IN STD.	D70A, D70B, TD70A, TD70B	
	421012	VALVE SEAT EX STD.	D70A, D70B, TD70A, TD70B	
	421316	VALVE SEAT IN 0,20	D70A, D70B, TD70A, TD70B	
	421313	VALVE SEAT EX 0,20	D70A, D70B, TD70A, TD70B	

	OEM NO	DESCRIPTION	NOTES	
	421011	VALVE SEAT IN STD.	TD70D, TD70E, TD70F, TD70FS, TD70G, TD70H, TD70HA, TD71E, TD71F, TD71FD, TD71FSQ, TD71G	
	466266	VALVE SEAT EX STD.	TD70D, TD70E, TD70F, TD70FS, TD70G, TD70H, TD70HA, TD71E, TD71F, TD71FD, TD71FSQ, TD71G	
	421316	VALVE SEAT IN 0,20	TD70D, TD70E, TD70F, TD70FS, TD70G, TD70H, TD70HA, TD71E, TD71F, TD71FD, TD71FSQ, TD71G	
	466307	VALVE SEAT EX 0,20	TD70D, TD70E, TD70F, TD70FS, TD70G, TD70H, TD70HA, TD71E, TD71F, TD71FD, TD71FSQ, TD71G	
	422011	VALVE SEAT IN STD.	D100A, D100B, TD100A	
	422012	VALVE SEAT EX STD.	D100A, D100B, TD100A	
	467590	VALVE SEAT IN 0,20	D100A, D100B, TD100A	
	467591	VALVE SEAT EX 0,20	D100A, D100B, TD100A	
	467474	VALVE SEAT IN STD.	TD100B, TD100BG, TD100G, TD100GA, TD101FD, TD101FC, TD101FA, TD101F, TD102FH, TD102FQ	
	467475	VALVE SEAT EX STD.	TD100B, TD100BG, TD100G, TD100GA, TD101FD, TD101FC, TD101FA, TD101F, TD102FH, TD102FQ	

	OEM NO	DESCRIPTION	NOTES	
	467474	VALVE SEAT IN STD.	TD102FF, TD102FD, TD102F, TD102FM, TD102FL, TD103ES	
	1545886	VALVE SEAT EX STD	TD102FF, TD102FD, TD102F, TD102FM, TD102FL, TD103ES	
	423011	VALVE SEAT IN STD.	TD120, TD121, TD122, TD123	
	468448	VALVE SEAT EX STD	TD120, TD121, TD122, TD123	
	423208	VALVE SEAT IN 0,20	TD120, TD121, TD122, TD123	
	468449	VALVE SEAT EX 0,20	TD120, TD121, TD122, TD123	
	468305	VALVE STEM KEY	TD100, TD101, TD102, TD120, TD121, TD122, TD123	
	1677875 (465284)	VALVE STEM KEY	D12A; FH12	
	478074 (469365) (407224) (417133) (466932)	VALVE CAP	TD100, TD101, TD102, TD120, TD121, TD122, TD123	
	422993 (423058)	ADJUSTING SCREW, ROCKER ARM NUT, ROCKER ARM 422993 + 940175	TD100, TD101, TD102, TD120, TD121, TD122, TD123	

	OEM NO	DESCRIPTION	NOTES	
	420021	PUSH ROD	TD60	
	467820 (422021) (8121477)	PUSH ROD	TD100, TD101, TD102	
	423021 (8121478)	PUSH ROD	TD120, TD121, TD122, TD123	
	467853 422363	CAMSHAFT	TD100A, TD100C, THD100D THD100DA, THD100DB, THD100DC, THD100DD	
	1545071 479450	CAMSHAFT	TD100G, TD100GA, THD100EA, THD100EB, THD100EC, TD101*, TD102*, (*earlyproduction) THD101, THD102	
	8194480 479610	CAMSHAFT	TD100 / 101 / 102 F10 / FL10	
	468723 (478750)	CAMSHAFT	TD120C, TD120D, TD120E, TD120F, TD120FA, D120FB, TD120G, TD120GA, *TD121, *TD122 (*early production)	
	8193727 479620	CAMSHAFT	TD120 / 121 / 122 F12 / NL12	
	8148524	CAMSHAFT	D12A / FH12 340 / 380 / 420 Ps	
	1543704	CAMSHAFT	TD162 / TD163 D16A / F16 / FH16	

	OEM NO	DESCRIPTION	NOTES	
	470424 478437	CONNECTING ROD 6 kg VOLVO	TD121 / TD 122 F12 Ch.314000 N12,NL12	
	4804115	CRANKSHAFT ENGINE	TD42 TRACTOR	
	4804294	CRANKSHAFT ENGINE	TD45 TRACTOR	
	465678 465678	CRANKSHAFT ENGINE	TD60	
	465798 420662	CRANKSHAFT ENGINE	TD61 / L90A	
	471749	CRANKSHAFT ENGINE	TD70	
	477116	CRANKSHAFT ENGINE	TD71	
	1545657 467709 6888669	CRANKSHAFT ENGINE	TD100 / TD101 TD102 / THD100 THD101 / THD102	
	8194456 8194304	CRANKSHAFT ENGINE 14 HOLES	TD102 / TD103	
	470681 6888740 468617	CRANKSHAFT ENGINE	TD120 / TD121	

	OEM NO	DESCRIPTION	NOTES	
	8125583 478676 6888125	CRANKSHAFT ENGINE 14 HOLES	TD122 / TD123	
	1547468 20411189	CRANKSHAFT ENGINE	D12 / D12A FH12 420ps	
	- 422076 - 422077 422078 - 422079 422080 - 422081 422082	BEARING SET, CAMSHAFT	TD60, TD61, TD63, TD70, TD71, TD73, TD100, TD101, TD102, TD103, TD120, TD121, TD122, TD123	
	467335 467334	VALVE SPRING, INNER VALVE SPRING, OUTER	TD100 / TD101 TD102 / TD103	
	468066 468067	VALVE SPRING, INNER VALVE SPRING, OUTER	TD120 / TD121 TD122 / TD123	
	467365 467714 422181	PLUG, CYLINDER HEAD	D100, HD100, TD100, THD100, TD101, THD101, TD102, THD102, TD103, THD103, THD104, TD120, TD121, TD122, TD123	
	469327 422182	GASKET, PLUG CYLINDER HEAD	D100, HD100, TD100, THD100, TD101, THD101, TD102, THD102, TD103, THD103, THD104, TD120, TD121, TD122, TD123	
	467367 (467649)	PLUG, CYLINDER BLOCK	D50, TD50, D60, TD60, TD61, TD63, D70, TD70, TD71, TD73, D100, HD100, TD100, THD100, TD101, THD101, TD102, THD102, TD103, THD103, THD104, TD120, TD121, TD122, TD123, TD162, TD163, D6A, D10A, DH10A, D16	
	469328 421145 468462 1556907	GASKET, PLUG CYLINDER BLOCK	D50, TD50, D60, TD60, TD61, TD63, D70, TD70, TD71, TD73, D100, HD100, TD100, THD100, TD101, THD101, TD102, THD102, TD103, THD103, THD104, TD120, TD121, TD122, TD123, TD162, TD163, D6A, D10A, DH10A, D16	
	1543937 1556860	PLUG, CYLINDER HEAD	TD162	

	OEM NO	DESCRIPTION	NOTES	
	479260 (423139)	RUBBER SEAL	D100A, D0100B, TD100, TD101, TD102, TD103, D10A	
	422086 467918	CYLINDER HEAD SCREW	TD100A, TD100B, TD100BG, TD100G, TD100GA, TD101G, TD101GA, TD101F, TD101FA, TD102F, TD102FD, TD102FF, TD102FL, TD103	
	470261 423485	CYLINDER HEAD SCREW	TD120C, TD120D, TD120E, TD120F, TD120FC, TD120G, TD120GA, TD121G, TD121GD, TD121F, TD121FD, TD122F, TD122FS, TD122FR, TD122FL, TD122FH, TD122FA, TD123E, TD123ES	
	422067	SCREW, CYLINDER BLOCK	TD100 / 101 / 102 VOLVO	
	1545479 417464	SCREW, CONNECTING ROD	TD100 / 101 / 102 VOLVO	
	467506	WASHER UPPER, CYLINDER HEAD	TD100 / 101 / 102 VOLVO	
	1547967	ADJUSTING WASHER THK 2.00	FM9 / FM12 / FH12 FL12 / NH12 / B12	
	1547968	ADJUSTING WASHER THK 2.05	FM9 / FM12 / FH12 FL12 / NH12 / B12	
	1547969	ADJUSTING WASHER THK 2.10	FM9 / FM12 / FH12 FL12 / NH12 / B12	
	1547970	ADJUSTING WASHER THK 2.15	FM9 / FM12 / FH12 FL12 / NH12 / B12	





	OEM NO	DESCRIPTION	NOTES	
	1547971	ADJUSTING WASHER THK 2.20	FM9 / FM12 / FH12 FL12 / NH12 / B12	
	1547972	ADJUSTING WASHER THK 2.25	FM9 / FM12 / FH12 FL12 / NH12 / B12	
	1547973	ADJUSTING WASHER THK 2.30	FM9 / FM12 / FH12 FL12 / NH12 / B12	
	465547 465144 411085 7411085	INJECTOR SLEEVE	D50A, D50B, TD50A, TD50B D60A, TD60A	
	466284 412017	INJECTOR SLEEVE	D70A, D70B, TD70, TD70A, TD70B, TD70C, TD70D, TD70E	
	467417 423076 7467417	INJECTOR SLEEVE	D100A, D100B, TD100A, TD100B, TD100C, THD100	
	468263 423270	INJECTOR SLEEVE	TD120A, TD120C, TD120D, TD120E	
	1543223	INJECTOR SLEEVE	TD162F, TD162FL, TD162FS, TD163ES, D16A	
	1546718 276811	INJECTOR SLEEVE KIT	D12A / D12B FH12	
	276836 271087	INJECTOR SLEEVE KITS	TD162F, TD162FL, TD162FS, TD163ES, D16A	

	OEM NO	DESCRIPTION	NOTES	
	422740	FLYWHEEL	TD100	
	422746	FLYWHEEL	TD120	
	479543	FLYWHEEL 10 HOLES (Ø 430mm)	F12	
	478913	FLYWHEEL 14 HOLES (Ø 380mm)	F10 / F12 CH 314000	
	478931	FLYWHEEL 14 HOLES (Ø 430mm)	FH12	
	1677033	FLYWHEEL (Ø 430mm)	VOLVO	
	420314	FLYWHEEL RING GEAR	TD60/ TD70	
	420794 423082	FLYWHEEL RING GEAR	TD100/ TD101/ TD02/ TD120 / TD121 TD122/ TD123	
	471532	FLYWHEEL RING GEAR	D12A/ FH 12	
	8193939	FLYWHEEL RING GEAR	TD 162	

	OEM NO	DESCRIPTION	NOTES	
	479477 468554 479478 1676819	FLYWHEEL HOUSING	TD100,TD101, TD102,TD120, TD121,TD122	
	-	GEAR BOX HOUSING	TD100,TD101, TD102,TD120, TD121,TD122	
	422427	LOCK WASHER, FLYWHEEL	TD100, TD101 mot.- 187886, TD120, TD121 mot.-117448	
	477118	SEALING RING, CRANKSHAFT FRONT	TD61F, TD61FB, TD61FBQ, TD61FHQ, TD61G, TD61GA, TD61GB, TD61GC, TD61GE, TD61GS, TD63E, TD63ES, TD71F, TD71FA, TD71FAQ, TD71FC, TD71FCQ, TD71FD, TD71FQ, TD71FS, TD71G, TD73E, TD73ES, D6A, D7A, D7B	
	469507 (424983)	SEALING RING, CRANKSHAFT FRONT	TD100BG, TD100C, TD100G, TD100GA, HD100, THD100, TD101F (From Eng.168546-), TD101G (From Eng.174867-), THD101, TD102, TD103, TD121 (From Eng.91926-), TD122, TD123E, TD123ES, D10A	
	424763	SEALING RING, CRANKSHAFT FRONT	THD102, THD103, THD104, DH10A	
	477119 (471056)	SEALING RING, CRANKSHAFT REAR	TD60A F6, TD60B, TD60C, TD61F, TD61FB, TD61FBQ, TD61FHQ, TD61G, TD61GA, TD61GB, TD61GE, TD61GS, TD63E, TD63ES, TD70F, TD70FC, TD70FS, TD70G, TD71F, TD71FA, TD71FC, TD71FD, TD71FS, TD71G, TD73E, TD73ES, D6A, D7A, D7B	
	469336 422157 424171 467058 467148 468553	SEALING RING, CRANKSHAFT REAR 20441697	D100A, D100B, TD00A, TD100B From Eng.58276-, TD100BG, TD100C, TD100G, TD100GA, TD101, THD101, TD102, THD102, TD103, THD103, TD120A (From Eng.13194-), TD120C, TD120D, TD120E, TD120F, TD120G, TD121, TD122, TD123E, TD123ES, D10A, DH10A	
	1543896 85108352	SEALING RING, CRANKSHAFT REAR	TD162, TD163E, TD163ES, D12A, D16A	
	8148471	SEALING RING, FUEL PUMP Ø 12X24X6/5	FH12	

	OEM NO	DESCRIPTION	NOTES	
	421080	GEAR, CRANKSHAFT	TD60, TD70	
	471528	GEAR, CRANKSHAFT	D70	
	423080	GEAR, CRANKSHAFT	TD100, TD101, TD102, TD103, TD120, TD121, TD122, TD123	
	1677849	GEAR, CRANKSHAFT	FH12 (engine 1948-)	
	421079	GEAR, CRANKSHAFT	TD60, TD70	
	423079	GEAR, CAMSHAFT	TD100, TD101, TD102, TD120, TD121, TD122, TD123	
	467461 420081 467179	IDLER GEAR, TIMING GEAR HOUSING	TD100, TD101, TD102, TD120, TD121, TD122	
	467463 (422766)	AXLE, IDLER GEAR	TD100, TD101, TD102, TD120, TD121, TD122	
	469324 465789	BUSHING, IDLER GEAR	TD100, TD101, TD102, TD120, TD121, TD122	
	1677839	IDLER GEAR	FH12, (engine 1948-)	

	OEM NO	DESCRIPTION	NOTES	
	1677841	IDLER GEAR	FH12, (engine 1948-)	
	1677843	IDLER GEAR	FH12, (engine 1948-)	
	1677844	IDLER GEAR	FH12, (engine 1948-)	
	1677845	IDLER GEAR	FH12, (engine 1948-)	
	1677847	IDLER GEAR	FH12, (engine 1948-)	
	1547485	GEAR, DRIVING DEVICE	FH12	
	1677985 (8170199)	HUB, IDLER GEAR	FH12 For 20.77845	
	1677663 (8170219)	HUB, IDLER GEAR	FH12 For 20.77839 For 20.77841	
	946121	VALVE	F10, F12, N10, N12, FL10	
	276122	CONVERSION GASKET SET, ENGINE OVERHAUL	TD100, TD101	

	OEM NO	DESCRIPTION	NOTES	
	276124	CONVERSION GASKET SET, ENGINE OVERHAUL	TD120, TD121	
	469823	GASKET, INSPECTION COVER	D100, TD100, TD101 TD102, TD103, TD120, TD121, TD122, TD123	
	270762 275717	GASKET SET, DECARBONIZING	D60, TD60	
	270761 275527 7275527	GASKET SET, DECARBONIZING	D70, TD70	
	276034	GASKET SET, DECARBONIZING (WITHOUT VALVE CAP)	D100A, D100B TD100A, TD100B, TD100BG TD100C* (*eng.no.-145715)	
	276035	GASKET SET, DECARBONIZING (WITHOUT VALVE CAP)	TD100C* (*eng.no.145716-) TD100G, TD100GA TD101, TD102, TD103, D10A	
	275741	GASKET SET, DECARBONIZING	THD100D*, THD100DA*, THD100DB*, THD100DC*, THD100DD*, THD100EA, THD100EB, THD100EC, THD100ED, THD100EE, THD100EK, THD101, THD102, THD103, THD104KB, THD104KF, DH10A (*eng.no.23199-)	
	275554	GASKET SET, DECARBONIZING	TD120, TD121, TD122, TD123	
	276638	GASKET SET, DECARBONIZING	TD162F, TD162FL, TD162FS, TD163ES, D16A	
	420066	VALVE COVER GASKET	D50, TD50, D60, TD60	

	OEM NO	DESCRIPTION	NOTES	
	421066	VALVE COVER GASKET	D70, TD70	
	423146	VALVE COVER GASKET, UPPER	D100A*, D100B*, TD100A*, TD100B*, TD100C* (*eng.no.-145715) HD100A*, DH100D*, THD100A*, THD100D*, THD100DA*, THD100DB*, THD100DC*, THD100DD* (*eng.no.-23198) B588R THD100D* (*eng.no.-1554)	
	423145	VALVE COVER GASKET, LOWER	D100A*, D100B*, TD100A*, TD100B*, TD100C* (*eng.no.-145715) HD100A*, DH100D*, THD100A*, THD100D*, THD100DA*, THD100DB*, THD100DC*, THD100DD* (*eng.no.-23198) B588R THD100D* (*eng.no.-1554)	
	424694	VALVE COVER GASKET, UPPER	TD100C (eng.no.145716-) TD100G, TD100GA, THD100D*, THD100DA*, THD100DB*, HD100DC*, THD100DD*, TD101, THD101, TD102, THD102, TD103, THD103, THD104KB, THD104KF, D10A, DH10A (*eng.no.23199-) B588R THD100D (eng.no.1555-)	
	424693	VALVE COVER GASKET	TD100C (eng.no.145716-) TD100G, TD100GA, THD100D*, THD100DA*, THD100DB*, HD100DC*, THD100DD*, TD101, THD101, TD102, THD102, TD103, THD103, THD104KB, THD104KF, D10A, DH10A (*eng.no.23199-) B588R THD100D (eng.no.1555-)	
	465682	OIL, PUMP	TD60	
	467517 (479319) (1545119) (422039)	OIL PUMP	D60, TD60, D70, TD70, TD100A, TD100B, TD100BG, TD100G, TD100GA, TD101G, TD101F, TD101FA, TD101FD	
	276155 (275570)	REPAIR KIT, OIL PUMP	D60, TD60, D70, TD70, TD100A, TD100B, TD100BG, TD100G, TD100GA, TD101G, TD101F, TD101FA, TD101FD	
	420867 (471570)	OIL PUMP	TD61	
	276151 271272 275773	REPAIR KIT, OIL PUMP	TD61	

	OEM NO	DESCRIPTION	NOTES	
	421039 (466387) 466530	OIL PUMP	TD70	
	275715	REPAIR KIT, OIL PUMP	TD70	
	471733 (477547)	OIL PUMP	TD71	
	275777	REPAIR KIT, OIL PUMP	TD71	
	276152	REPAIR KIT, OIL PUMP	TD102, TD103; F10, FL10, N10	
	275731 (275571)	REPAIR KIT, OIL PUMP	TD120A, TD120E, TD120G, TD120GA	
	276156	REPAIR KIT, OIL PUMP	TD121G, TD121GD, TD121F, TD121FD, TD122FS, TD122FK, TD122FH, TD122FA, TD123E, TD123ES	
	8193737 1677050	OIL PUMP	D12A FH 12 (OLD)	
	-	REPAIR KIT, OIL PUMP 1547509 + 1547510	D12A FH 12 (OLD)	
	8170465 20709848	OIL PUMP	D12 A/B/C FH 12 (NEW)	

	OEM NO	DESCRIPTION	NOTES	
	-	REPAIR KIT, OIL PUMP	D12 A/B/C FH 12 (NEW)	
	1556018 (1556730) (1556177)	OIL PUMP	TD162F / FH16	
	271083 (276150)	REPAIR KIT, OIL PUMP 271083 + 276150	TD162F / FH16	
	469177	DRIVE GEAR, OIL PUMP	TD60, TD70	
	471941	DRIVE GEAR, OIL PUMP	TD61, TD71	
	421046	IDLER GEAR, OIL PUMP	TD60, TD70	
	471942	IDLER GEAR, OIL PUMP	TD61, TD71	
	425027	DRIVE GEAR, OIL PUMP	For : 20.9319 For : 20.8351	
	470356	DRIVE GEAR, OIL PUMP	For: 20.8649 (eng.no.-136240)	
	478232 257757 1545825 257758	DRIVE GEAR, OIL PUMP	For : 20.9317, For : 20.8649 (eng.no.136241-)	

	OEM NO	DESCRIPTION	NOTES	
	422047	IDLER GEAR, OIL PUMP	For : 20.9319 For : 20.9317 For : 20.8351 For : 20.8649	
	420048 3978693	BEARING SLEEVE	TD60, TD61, TD70, TD71	
	422313	BEARING SLEEVE	For : 20.9319 For : 20.9317 For : 20.8351 For : 20.8649	
	471188	BUSHING, IDLER GEAR OIL PUMP	TD60, TD70	
	470347	BUSHING, IDLER GEAR OIL PUMP	TD61, TD71	
	422314	BUSHING, BEARING SLEEVE	For : 20.9319 For : 20.9317 For : 20.8351 For : 20.8649	
	1547486	IDLER GEAR , OIL PUMP	FH12 / OLD	
	414621	STRAINER OIL PUMP	D50A, D50B, TD50A, TD50B, D60A, TD60, D70A, D70B, TD70A, TD70B, TD70C, TD70D, TD70E, TD70H, D100A, D100B, TD100A, TD100B, TD100C, TD120	
	- 470376 956973 470377 470375 466908 470385 470918 470379	SUCTION PIPE KIT , OIL PUMP FLANGE FERRULE CONNECTOR OIL PRESSURE PIPE FITTING BRACKET BRACKET SUCTION PIPE	TD121 , TD122	

	OEM NO	DESCRIPTION	NOTES	
	- 469465 949658 470291 468727 471085 469468 469846	REPAIR KIT, REDUCING VALVE	TD100G, TD100GA, TD120, TD121, TD122	
	421123	REDUCING VALVE	TD100, TD120	
	422836	REDUCING VALVE	TD101, TD102, TD103; F10, FL10, TD121, TD122, TD123	
	471706	REDUCING VALVE	TD101; F10, FL10	
	471707	REDUCING VALVE	TD102, TD103; F10, FL10, TD121 (eng.no.106308-), TD122, TD123	
	422850	OIL NOZZLE	TD102	
	468539	OIL NOZZLE	TD120, TD121, TD122, TD123	
	1524290 (949175)	PLUG OIL TANK, OIL SUMP, GEARBOX, REAR AXLE	F6, F6S, FL6, FL7, FS7, F10 FL10, F12, FH12, F16, FH16, N10, NL10, N12, NL12, B6, B9, B10, B12	
	421753 (420292)	OIL FILLER CAP	TD100, TD120	

	OEM NO	DESCRIPTION	NOTES	
	467739	RUBBER HOSE	F10, F12	
	351574	RUBBER HOSE, OIL COOLER	TD100	
	467538	RUBBER HOSE, OIL COOLER	F88, FL6, F10, FL10, N88, N10, NL10, N12 (mot.TD120A eng.no.25838-),	
	468706	RUBBER HOSE, OIL COOLER	F12, N12 (excl.TD120A), B12, NL12 AUS, B12BR	
	469484 468329	RUBBER GASKET, OIL FILTER HOUSING	TD100A (eng.no.62343-132654), TD100B (eng.no.62343-132461)	
	469487 467914	RUBBER GASKET, OIL FILTER HOUSING	TD100A (eng.no.132655-), TD100B (eng.no.132462-), TD100C, TD100G, TD100GA, TD101, TD102, TD103	
	469486 (468651)	RUBBER GASKET, OIL FILTER HOUSING	TD120 (excl.TD120A), TD121, TD122, TD123	
	468210	INJECTOR SEALS	TD120	
	469455	INJECTOR SEALS	TD60, TD70, TD100 TD101, TD102, TD103 TD120, TD121, TD122 TD123	
	276948 276644 276845 276935	REPAIR KIT INJECTOR	FH12, FL12, FM12, B12	


	OEM NO	DESCRIPTION	NOTES	
	1677019	SEALING RING	D12, FH12	
	233179 243459	NOZZLE 0 433 271 036 (150S720)	D50A, D50B, TD50A, D67, D67C, TD67C	
	238896 (240339)	NOZZLE 0 433 271 043 (150S178)	TD70H, D100A, D100B, TD100A, TD100B, THD100A, THD100B, THD100D, TMD100A/B/C	
	467654 468708	NOZZLE 0 433 271 865 (150S762)	TD100B, TD100G, THD100B, THD100D, TD120A, TD120C, TD120E	
	1545153	NOZZLE 0 433 171 052 (150P52)	TD100G, TD100GA, THD100A, TMD100A/B/C, TD101F, TD101FA, TD101G, TD101GA	
	468218 241935	NOZZLE 0 433 271 280 (150S582)	TD120A, TD120C, TD120E	
	468826	NOZZLE 0 433 171 032 (150P31)	TD120F, TD121F, TD121FA, TD121G, TD122F, TD122FH	
	470114	NOZZLE 0 433 171 043 (150P43)	TD120G, TD120GA, TD121F, TD121FA	
	470934	NOZZLE 0 433 171 134 (148P149)	TD121FG, TD121FH, TD122F, TD122FK, TD122FL, TD122FH, TD122FS	
	035096 (479775)	OVERFLOW VALVE	ALL MODELS	



	OEM NO	DESCRIPTION	NOTES	
	238041	HOLLOW SCREW	ALL MODELS	
	240072	FEED PUMP	N10 (ch.no.-49000) N12 (ch.no.-12000)	
	243083	FEED PUMP	F10 (ch.no.-25000), N10 (ch.no.-49000), N12 (ch.no.-12000), F88, G88, F89, G89	
	076703 1698348	HAND PUMP	ALL MODELS	
	3826073	HAND PUMP	ALL MODELS	
	241136 3094313	FEED PUMP, REPAIR KIT	ALL MODELS	
	-	REPAIR KIT, FEED PUMP	ALL MODELS " NEW "	
	466398 477173	DIAPHRAGM, FUEL PUMP	ALL MODELS	
	424580	OIL SEAL, INJECTION PUMP DRIVING UNIT Ø 29X50X10	D70*, TD70*, TD71, D100, HD100, TD100, THD100, TD101, THD101, TD102, THD102, TD103, TD120, TD121, TD122 (excl. TD122FS) *Not For F86, FB86, F87, N86	

	OEM NO	DESCRIPTION	NOTES	
	1546221	OIL SEAL, INJECTION PUMP DRIVING UNIT Ø 34.9X62X8	FL7 / FL10 / FL12 F16 / FH16 / NL10 B10 / B12	
	842467	GEAR, INJECTION PUMP	TD60	
	479985	GEAR, INJECTION PUMP	TD123	
	417512 (479459)	FRICTION DISC, INJECTION PUMP	D70, TD70, TD71, D100, HD100, TD100, THD100, TD101, THD101, TD102, THD102, TD120, TD121, TD122	
	479458	FRICTION DISC, INJECTION PUMP	TD103, TD123, TD163	
	-	REPAIR KIT, PUMP COUPLING	TD101, TD102, TD120, TD121, TD122	
	-	SCREW AND WASHER SET (PUMP COUPLING)	TD101,TD102, TD120, TD121, TD122 NEW MODEL	
	466405	INJECTOR SEAL		
	466420	STEEL RING INJECTOR SLEEVE		
	469205	INJECTOR SEAL		

	OEM NO	DESCRIPTION	NOTES	
	470181	CLAMP, INJECTOR PIPE (2HOLES)	ALL MODELS	
	470183	CLAMP, INJECTOR PIPE (3HOLES)	ALL MODELS	
	478712	SEALING RING, EXHAUST PRESSURE REGULATOR	F88, F89, F10, F12, N10, N12	
	417110	NUT, INJECTOR SCREW	F10, F12, N10, N12	
	467870 467711	CYLINDER HEAD	TD100 , F10	
	1545199 424868	CYLINDER HEAD	TD100G, TD101G TD102F	
	468869	CYLINDER HEAD	TD120F, TD120G	
	470332	CYLINDER HEAD	TD120F, G , GA	
	-	EXHAUST MANIFOLT, COMPLETE 1545346(467551) X 1 467552 X 1	TD100B	
	-	EXHAUST MANIFOLT, COMPLETE 478662 (470417) X 1 470418 X 1 470416 X 2	TD121, TD122	

	OEM NO	DESCRIPTION	NOTES	
	-	EXHAUST MANIFOLT, COMPLETE 423273 X 1 423274 X 2	TD120A / F89	
	-	EXHAUST MANIFOLT, COMPLETE 422155 X 1 422156 X 2	TD100A / F88	
	-	EXHAUST MANIFOLT, COMPLETE 1547520(3964708) X 1 1547521(3964707) X 2	D12A / FH12	
	-	EXHAUST MANIFOLT, COMPLETE 8194521(1545029) X 1 479277 8194048(1545028) X 1 477112	TD100G, TD100GA, TD101G, TD101GA, TD101F	
	-	EXHAUST MANIFOLT, COMPLETE 8194522(1545326) X 1 8194048(1545028) X 1 477112	FL10 / TD101G,TD101F,TD10 2F TD102FL, TD103E, TDTD103ES	
	-	EXHAUST MANIFOLT, COMPLETE 8194520(1545322) X 1 477111 8194048(1545028) X 1 477112	N10	
	-	EXHAUST MANIFOLT, COMPLETE 8193545(470566) X 1 8193546(470567) X 1	N12	
	-	EXHAUST MANIFOLT, COMPLETE 466093 X 1 466094 X 1	TD70	
	-	EXHAUST MANIFOLT, COMPLETE 465104 X 1 465108 X 1	TD60	
	-	EXHAUST MANIFOLT, COMPLETE 3978601 X 1 3978602 X 1	TD71	

	OEM NO	DESCRIPTION	NOTES	
	-	EXHAUST MANIFOLT, COMPLETE 1556798 X 1 1543534 X 1	F16 / FH16	
	-	EXHAUST MANIFOLT, COMPLETE 1556121(1697909) X 1 1543534 X 1	F16 / FH16	
	470323	SEALING RING, EXHAUST MANIFOLD	F12	
	467507	LOCK WASHER, EXHAUST MANIFOLD	TD100A; F10, TD100B, TD100BG; F88, F10, N10	
	467331	LOCK WASHER, EXHAUST MANIFOLD	TD100A; F10, TD100B, TD100BG; F10, N10	
	966717	LOCK WASHER, EXHAUST MANIFOLD	TD100G, TD100GA, TD101, THD101, TD102, THD102, TD103, THD103, THD104, D10A, DH10A	
	423350	LOCK WASHER, EXHAUST MANIFOLD	TD120A TD120C, TD120D (eng.no.-40162), TD120E, TD120FA, TD120FB, TD120G, TD120GA N12, TD121, TD122, TD123 N12, NL12 AUS, NL12S	
	468740	LOCK WASHER, EXHAUST MANIFOLD	TD120C, TD120D (eng.no.- 40162), TD120E, TD120FA, TD120FB, TD120G, TD120GA N12, TD121, TD122, TD123 N12, NL12 AUS, NL12S	
	468646	LOCK WASHER, EXHAUST MANIFOLD	TD120C, TD120D (eng.no.40163-), TD120E, TD120F, TD120FC, TD120G, TD120GA, TD121, TD122, TD123; F12, B12	
	942167	LOCK WASHER, TURBO CONNECTION	TD40A, TD41G, TD50A, TD50B, TD60A, TD60B, TD60C, TD70 excl. F86, F87, N86	

	OEM NO	DESCRIPTION	NOTES	
	120307	LOCK WASHER, TURBO CONNECTION	TD100A, TD100B, TD100BG, TD100C, THD100A B58 ch.9765-, THD100D	
	1545277	LOCK WASHER, TURBO CONNECTION	TD100G, TD100GA, TD101 (eng.no.-220274), THD100EA, THD100EB, THD100EC, THD100ED, THD100EE, THD100EK, THD101 (eng.no.- 44495)	
	468219	LOCK WASHER, TURBO CONNECTION	TD120, TD121, TD122 (eng.no.-143482) (excl. NL12S)	
	270769	GASKET SET, EXHAUST MANIFOLD	D60A*, TD60A* for B6, F6	
	270768	GASKET SET, EXHAUST MANIFOLD	TD60, F6S	
	270771	GASKET SET, EXHAUST MANIFOLD	D70, TD70	
	270958	GASKET SET, EXHAUST MANIFOLD	D100A, D100B, TD100A, TD100B, TD100C, TD100BG, THD100A, THD100D, THD100DA, THD100DB, THD100DC, THD100DD	
	276052	GASKET SET, EXHAUST MANIFOLD	TD100G, TD100GA, THD100EA, THD100EB, THD100EC, THD100ED, THD100EE, THD100EK, TD101, THD101, TD102, THD102, TD103, THD103, THD104	
	270772	GASKET SET, EXHAUST MANIFOLD	TD120, TD121, TD122, TD123	
	271088	GASKET SET, EXHAUST MANIFOLD	TD162F, TD162FS, TD163FL, TD163ES	

	OEM NO	DESCRIPTION	NOTES	
	420708 420617 420609	GASKET, EXHAUST MANIFOLD	TD60, F6S	
	420538	GASKET, EXHAUST MANIFOLD	TD61	
	421534 421305 421403 471344	GASKET, EXHAUST MANIFOLD	D70, TD70	
	471650	GASKET, EXHAUST MANIFOLD	TD71	
	424634 422074	GASKET, EXHAUST MANIFOLD	D100A, D100B, TD100A, TD100B, TD100C, TD100BG, THD100A, THD100D, THD100DA, THD100DB, THD100DC, THD100DD	
	479107	GASKET, EXHAUST MANIFOLD	TD100G, TD100GA, THD100EA, THD100EB, THD100EC, THD100ED, THD100EE, THD100EK, TD101, THD101, TD102, THD102, TD103, THD103, THD104	
	470534 423323 468647	GASKET, EXHAUST MANIFOLD	TD120, TD121, TD122, TD123	
	1547881 8170959 8187272	GASKET, EXHAUST MANIFOLD	D12A/D12B/D12C FH12	
	1543858 8130038	GASKET, EXHAUST MANIFOLD	TD162F / TD162FL TD162FS / TD162ES D16A	
	470939	GASKET, TURBOCHARGER	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	411710	GASKET, TURBOCHARGER	ALL MODELS	
	423174	GASKET, INTAKE MANIFOLD	TD100, TD101, TD102 TD120, TD121, TD122	
	469829	GASKET, INTAKE MANIFOLD	TD100, TD101, TD102 D10A, DH10A	
	423281	SEALING RING, WATER PIPE	TD120, TD121, TD122 TD123	
	1674673 1676642	SILENCER	FL7, FL10*, B10B, B10R TD102KF With exhaust emission left side and right side *Incl. TRIDEM with vertical exhaust pipe	
	1661420	SILENCER, VERTICAL	FL7, FL10, TD102F	
	1674157 (1664990) (1544355)	SILENCER	F10 ch.25001-, F12 ch.34001-, excl. 8x2, 8x4 ch.318965-, ch.425458- With exhaust emission left side* Excl. With spark eliminator Excl.4x4, 6x6 Sweden, Excl. TRIDEM Excl. Switzerland	
	1544007	SILENCER	F10, F12	
	1544008	SILENCER	F10, F12	
	8149183 (1674209) (1664067)	SILENCER	FL7, FL10, F12, N12	

	OEM NO	DESCRIPTION	NOTES	
	1660548	SILENCER	N12	
	1665545	SILENCER	F10 CH.314000 F12 CH.314000 F16, TD162	
	1676499	SILENCER	FL12, FH12, FH16	
	1676496 3979909	SILENCER	FL12, FH12, FH16	
	1587272 1581580	PIPE, SILENCER	For Silencer; 20.44007 For Silencer; 20.44008	
	1587274	PIPE, SILENCER	F10, F12	
	8159336 3943900	PIPE, SILENCER	For Silencer; 20.76642	
	1082689 (1618758)	PIPE, SILENCER	For Silencer; 20.74157	
	1594300	PIPE, SILENCER	For Silencer; 20.74157 For Silencer; 20.44374	
	1629939	PIPE, SILENCER	For Silencer; 20.76496 FH12	

	OEM NO	DESCRIPTION	NOTES	
	1626097	PIPE, SILENCER	For Silencer; 20.76496 FL12, FH12, FH16	
	1629054	PIPE, SILENCER LOW CHASSIS	For Silencer; 20.76496 For Silencer; 20.76499 FL12, FH12, FH16	
	1628883	PIPE, SILENCER STD. CHASSIS	For Silencer; 20.76496 For Silencer; 20.76499 FH12, FH16	
	1628052	PIPE, SILENCER STD. CHASSIS	For Silencer; 20.76496 For Silencer; 20.76499 FH12, FH16	
	8147305	PIPE, SILENCER LOW CHASSIS	For Silencer; 20.76496 For Silencer; 20.76499 FL12, FH12, FH16	
 	6892117	EXHAUST HOSE, FLEXIBLE DIAM. 5"X400MM	F10* ch.-25000 Australia, F12* ch.-34000 excl.short cab, F16 TD163 ch.- 377426	
	1078116 (8152564)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X467MM	FL10 4x4, FL10 8x2, 8x4	
	1078115 (8152565)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X498MM	FL7, FL10, F12 ch.314000- 6x6, N7 ch.11215- N10 ch.49001-56693 N12 ch.8831-18480..	
	1078121 (8152558)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X325MM	FL7 ch.337246-, FL10, FS10, F12 6x6 ch.314000- , F16 B10M LHD ch.41083-	
	1078123 (8152556)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X250MM	FL7, FL10 vertical exhaust pipe, F12 4x4/6x6 Sweden emission left	
	1078122 (8152557)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X283MM	FL7* , FL10 4x4, F12* 6x4/8x4 ch.314000- 377242, F12* ch.314000- F16* TRIDEM, N7* ch.11215-, N10 ch.33769, N12 ch.1900-12000	

	OEM NO	DESCRIPTION	NOTES	
 	1078118 (8152562)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X380MM	FL7 TD73 vertical silencer, NL10BR ch.654001-, NL12BR ch.654001-, B10L	
	1078119 (8152560)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X360MM	FL7; TD73/D7A/D7B excl.8x2, 8x4, F10/F12 excl., F16 ch.-342818, F16 ch.342819-, NL10, NL10BR ch.635001-654000, NL10S, NL12 Australia, NL12BR ch.635001- 654000, NL12BR ch.654001- NL12S, B12BR ch.35001-	
	1078127 (8152552)	EXHAUST HOSE, FLEXIBLE DIAM. 4 1/2"X160MM	FL10 LHD 8X2, 8X4 exhaust emission left, FL10 special 65560 TRIDEM	
	1078110 (8156350)	EXHAUST HOSE, FLEXIBLE DIAM. 5"X350MM	FH12/FL12/FH16 front section, horizontal silencer, FH12/FL12/FH16 rear section, with exhaust emission left side, F16/FH16 vertical exhaust pipe, B12ch.5000-	
	1078111 (8156351)	EXHAUST HOSE, FLEXIBLE DIAM. 5"X150MM	FH12/FL12/FH16 horizontal silencer, exhaust emission left/excl.chassis height 810	
	1078113 (8147410)	EXHAUST HOSE, FLEXIBLE DIAM. 5"X141MM	FH12/FL12/FH16 horizontal silencer, exhaust emission left/excl.chassis height 810	
	1593265	EXHAUST HOSE, FLEXIBLE DIAM. 4"X425MM	N10/N12 Iran, Peru	
	1589141 (1599375)	CLAMP, EXHAUST HOSE INNER DIAM. 120MM		
	1605164 (3943974)	HEAT SHIELD SILENCER ALL MODELS	FL6, FL7, FS7 ch.25001-, FL10, F12 ch.34001-, FH12, FL12, FH16, N10 ch.306000-, NL10 AUS, NL10BR, NL10S, N12 ch.306000-, NL12 AUS, NL12BR, NL12S, B10B, B9M/B10M* ch.20001-29999, B10R* *With particulate filter	
	8152590 (1605629)	EXHAUST HOSE, FLEXIBLE	FL10 exhaust system with vertical silencer, B10M ch.40000-41082*, B10B, B12 *left hand drive, right hand drive excl.wheel base 5000	

	OEM NO	DESCRIPTION	NOTES	
	1609345 (1586825)	EXHAUST HOSE, FLEXIBLE	F10, F12	
	1083681	CLAMP, EXHAUST HOSE		
	3943850	CLAMP, EXHAUST HOSE		
	8156156 20383088 20455908	CLAMP, EXHAUST HOSE	FH12 / FH16	
	467310	CLAMP, EXHAUST HOSE 114MM	F7, FL7, FE7, FS7, F10, FL10, F12, F16, FH16, N7, N10, NL10, N12, NL12, B10B, B10L, B12	
	1624612 (1605016) (1508850)	CLAMP, EXHAUST HOSE FOR EXHAUST PIPES WITH FLANGE 140MM	F7, FL7, F10, FL10, FS10, F12, FL12, F16, N7 ch.no.- 12000, N10, NL10 AUS, N12, NL12BR, B7 ch.no. 30000-, B9M, B10L, B10M	
	1624613	CLAMPS, EXHAUST PIPE		
	1629499	CLAMPS, EXHAUST PIPE	FH12, FH16, FL12, FM10, FM12, B12	
	6850149	RUBBER CUSHION, EXHAUST SYSTEM	F82, F83, F84, F85, F86, F87, F88, F89, G89, F4, F6, F6S, F7, F10, F12, N84, N86, N88, N7, N10, NL10BR, N12, N12BR, NL12BR, B54, B55, B57, B58, B59, B6, B7F, B9M, B10M, B10L, B10M, B10R, B12, B12BR, C10M	
	271082	GASKET SET, TURBO CONNECTION	TD50A eng.no.-20145, TD60A for F84, F85	

	OEM NO	DESCRIPTION	NOTES	
	270752	GASKET SET, TURBO CONNECTION	TD50A eng.no.20146-, TD50B, TD70A, TD70B, TD70C, TD70D for Holset-Schwitzer Turbo	
	270767	GASKET SET, TURBO CONNECTION	TD100A, TD100B, TD100BG For F10	
	270997	GASKET SET, TURBO CONNECTION	*Excl. F10; TD100A*, TD100B*, TD100BG* TD100C, For N12; TD120A/TD120E/TD120G/ TD120GA	
	276815	GASKET SET, TURBO CONNECTION	TD100G, TD100GA, THD100D*, THD100DA*, THD100DB*, THD100DC*, THD100DD*, THD100E all, TD101F, TD101FA, TD101FC, TD101FD, TD101G, TD101GA, TD101GB, THD101, TD101, THD102, TD103, THD103, D10A *eng.no.23199-	
	-	GASKET SET, TURBO CONNECTION	TD120C*, TD120D*, TD120E*, TD120F*, TD120FC*, TD120G*, TD120GA*, TD121G, TD121GD, TD122FK, TD122FL, TD122FR, TD122FS, TD123ES *For F12	
	271089	GASKET SET, TURBO CONNECTION	TD162F, TD162FS, TD163FL, TD163FS	
	468893	DIFFUSER, TURBOCHARGER	F10 / F12	
	468330	EXHAUST BRAKE	B58 / B10 / N10 / N12	
	1617338	EXHAUST BRAKE	NL10 / NL12	
	8149396 1674189	FAN CLUTCH	FH12	

	OEM NO	DESCRIPTION	NOTES	
	20517753 20466635 20805997 20981227	FAN CLUTCH (CONVERTED TO VISCOUS)	FH12	
	1674553	FAN CLUTCH	FH16	
	20397619	FAN CLUTCH	FH12	
	20397618	FAN CLUTCH	FM9	
	8112950	FAN CLUTCH	FL7, FL10	
	1675786 3183672	FAN RETAINER	NL12, FL10 FH12, FH16	
	20564240 20451412 20810755 20915058 21157186	FAN RETAINER	FH12/ FM12/ FM9 NEW MODEL	
	1677176	ORING THERMOSTAT	NH12, FL12, FH12	
	1674865 1674126 1674204	FAN DIA: 720 X 127mm	FH12	
	376733	FAN DIA: 750/680 X 180mm	BUS	

	OEM NO	DESCRIPTION	NOTES	
	-	FAN DIA: 750 X 178mm		
	1542952	FAN (8 BLADES) Ø 76 – 750 mm	F12	
	476976	FAN (8 BLADES) Ø 76 – 680 mm	F89, F12, N12	
	1544648	FAN (8 BLADES) Ø 42 – 520 mm	F88, F10	
	475141	FAN (8 BLADES) Ø 51 – 535 mm	F10	
	1542549	FAN (6 BLADES) Ø 42 – 520 mm	F88, F10	
	475142	FAN (4 BLADES) Ø 42 – 520 mm	N10, N88	
	-	FAN (8 BLADES) Ø 38 - 555 mm	F89	
	-	FAN (8 BLADES) Ø 51 - 680 mm	N10	
	1661878 (465328)	PULLEY	F10, F12, N10, N12 N88, N89, F88, F89	

	OEM NO	DESCRIPTION	NOTES	
	1660004	LEVER	F10, F12	
	1664691 1664692	LEVER	F10, F12	
	1660003 466753 467325	LEVER	F10, N10, N12, NL10	
	1664695	STUB	F10, F12	
	1545268	SPRING	F10, F12, N10, N12 N88, N89, F88, F89	
	421540 3979897	BELT TENSIONER, COMPLETE	NL10, FL7, FL10	
	1660001	BELT TENSIONER, COMPLETE	N10, N12, NL10	
	471318	SPRING KIT	F10- F12 / N10- N12 VOLVO	
	1660113 1660112	SHAFT, FAN RETAINER	TD100,TD101, TD120 TD121	
	-	CLAMP	VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	-	CLAMP	VOLVO	
	-	CLAMP	VOLVO	
	-	CLAMP	VOLVO	
	-	CLAMP	VOLVO	
	-	CLAMP	VOLVO	
	-	CLAMP, FAN SHROUD (WITHOUT FAN SHROUD)	VOLVO	
	1660375 (1660376) 1544428	AIR FILTER OUTER	F10 ch.-344407, F12 ch.-344407	
	1080918	AIR FILTER OUTER	F10 ch.344408-, F12 ch.344408-	
	1665563	AIR FILTER OUTER	FL10 ch.324581-	
	1660619	AIR FILTER OUTER	N10, N12	

	OEM NO	DESCRIPTION	NOTES	
	1544449	AIR FILTER OUTER	NL12	
	1665898	AIR FILTER OUTER	FH12	
	1665908	AIR FILTER OUTER	FH16	
	1661808	AIR FILTER INNER	Together with 20.60376	
	1080920	AIR FILTER INNER	Together with 20.80918	
	1665886	AIR FILTER INNER	Together with 20.65563	
	1544298	AIR FILTER INNER	Together with 20.60619	
	1660903	AIR FILTER INNER	Together with 20.44449	
	1665937	AIR FILTER INNER	Together with 20.65898, Together with 20.65908	
	823701	AIR FITLER (MARINE TYPE)		

	OEM NO	DESCRIPTION	NOTES	
	865152	AIR FITLER (MARINE TYPE)		
	842280	AIR FITLER (MARINE TYPE)		
	423135	OIL FILTER	TD100A, TD100B	
	466634	OIL FILTER	TD100A, TD100G, TD120, FH12	
	477556	OIL FILTER, BY-PASS	FH12	
	466987	FUEL FILTER	F10, FL10, N10, F12 NL12, FH12	
	420799 8193841	FUEL FILTER	FH12	
	1699830 (1661964)	WATER FILTER	F16	
	8159975	FUEL FILTER	FH12	
	3943382	COVER, WATER SEPERATOR	FH12 / FH16 / FM12	

	OEM NO	DESCRIPTION	NOTES	
	-	WATER PUMP	D42	
	465475 1699783 1698613	WATER PUMP	TD60 A TD60 B	
	466088	WATER PUMP	TD70	
	275607 276806	REPAIR KIT, WATER PUMP	TD60 A TD60 B TD70	
	467915 (1699789) (1545427)	WATER PUMP	N10 ch.-49000; TD100A, N10, NL10S ch.304000-; TD101 USA,	
	467906 (1699785)	WATER PUMP	F10 ch.-25000; TD100A, TD100B, TD100BG, TD100G, TD100GA	
	1545248 (1699788)	WATER PUMP	N10 ch.-49000; TD100B, TD100BG, TD100G, N10 ch.49001-; TD101G, TD102, NL10, NL10S, N10 MK2; TD102	
	1545246 (1698617) 467906 1699785	WATER PUMP	F10 ch.25001-314000; TD101G, TD101GA, F10 Intercooler ch.314001-; TD102, TD103	
	422311	WATER PUMP	F88, N88; D100B, TD100A, TD100B	
	275618 (276800) (275986)	REPAIR KIT, WATER PUMP for 89.67915 / 89.7906 89.45248 / 89.45246 89.2311	D100B, TD100A, TD100B, TD100BG, TD100G, TD100GA, TD101G, TD101GA, TD101 USA, TD102, TD103	

	OEM NO	DESCRIPTION	NOTES	
	1545261 (468250) (468937) (470232)	WATER PUMP	F10 ch.25001-, FL10; TD101F, FL10 Interco., FS10; TD102F, F12 ch.-34000; TD120C, TD120D, TD120E, TD120F, TD120FC, TD120G, TD120GA, F12 ch.34001-; TD121F, TD121FD, TD121G, TD121GD, F12 Intercooler., NL12, NL12S; TD122FK, TD122FS, N12 ch.-12000; TD120A, TD120E, TD120G, TD120GA, N12 ch.12001-; TD121F, TD121G, TD121GA, NL10S; TD121GA	
	275615 (276802)	REPAIR KIT, WATER PUMP		
	422791	WATER PUMP	F10 Interco., F12 Interco.; TD102F, TD122FK, TD122FS OCS. ENG.	
	270791	REPAIR KIT, WATER PUMP	F10 Interco., F12 Interco.; TD102F, TD122FK, TD122FS OCS. ENG	
	1675945 8149937 3184802 20431484	WATER PUMP	F10 ch.314000-; TD102, TD103E, FL10; TD103ES, FS10; TD103, NL10, NL10S; F12, FL12, NL12, NL12S; TD123E, TD123ES	
	276936 276814	REPAIR KIT, WATER PUMP	F10 ch.314000-; TD102, TD103E, FL10; TD103ES, FS10; TD103, NL10, NL10S; F12, FL12, NL12, NL12S; TD123E, TD123ES	
	470265 468114 468130 468509 468927 470216	GEAR, WATER PUMP	for 89.45261 for 89.2791 for 89.75945	
	1547155 (8148460) (8157781) 1676746 8149882 8149941	WATER PUMP	FH12	
	1547156	REAR SECTION, WATER PUMP	FH12	
	276121 276852	REPAIR KIT, WATER PUMP	FH12	


	OEM NO	DESCRIPTION	NOTES	
	8170305	WATER PUMP	D12C / FH12 FM12 / NH12	
	20431135 20734268 8170833 85000452 20713787	WATER PUMP	FH12, FM12, NH12, B12, D12C	
	8149980	WATER PUMP	F16 / FH16	
	275609	REPAIR KIT, WATER PUMP	B58, B10	
	470226 468927	IDLER GEAR, COOLANT PUMP	F10, F12 OLD MODEL	
	470231	IDLER GEAR, COOLANT PUMP	F10, F12 NEW MODEL	
	1547483	GEAR, WATER PUMP	D12 / FH12	
	8170309	GEAR, WATER PUMP	FH12	
	958811	SEALING RING, COOLANT PUMP		

	OEM NO	DESCRIPTION	NOTES	
	1664500 1544671	RADIATOR 825 X 765 X 53	F10 / F12	
	8149681 1676436 1665249 8500328 8112566	RADIATOR	FH12 / 360 hp	
	9518422 8112786 9517543 100310942 3018818 3028701 8112681	RADIATOR	B10M	
	8149683 1676435 8112961 1676635	RADIATOR 900 X 890 X 50	FH12 / 420 hp FH16	
	20460178 20517350 20536920 20722444	RADIATOR	FM9 / FM10 / FM12	
	1665349	RADIATOR 900 X 740 X 50	FH12 / 360 HP	
	1664352 1542735	CHARGE AIR COOLER 740 X 760	F10 / F12	
	1664351	CHARGE AIR COOLER 745 X 765	F 12 CH 314000	
	1665242 1676631	CHARGE AIR COOLER	FH12	
	1675428 1676633 1676718	CHARGE AIR COOLER 885 X 915	FH 12 420 Power FH 16 520 Power	
	1664585	CHARGE AIR COOLER 720 X 650	NL 10 / NL 12	
	1661936	CHARGE AIR COOLER	FL 10 / FS 10	

	OEM NO	DESCRIPTION	NOTES	
	20383598 1623569	RUBBER BELLOWS	FH 12 / 16	
	1080152 (1587240)	RUBBER BELLOWS	F10, F12	
	1655865 (267932) (1527090)	GEAR LEVER	F10, F12, F16; L.H.D. Getr.R62, SR62, MR62, R1400, SR1400, R1700, SR1700, SR2000	
	1576294	BELLOWS	F10, F12	
	1696684	BALL JOINT, GEARBOX LHT	F4, FL4, F6, F6 USA, FE6, F6S, FL6, F7, F7 USA, FS7, FE7, F10, F12, F16, N12, N12 USA, FH12, FH16, B6, B7, B7F, B10M	
	1696685	BALL JOINT, GEARBOX RHT	F4, FL4, F6, F6 USA, FE6, F6S, FL6, F7, F7 USA, FS7, FE7, F10, F12, F16, N12, N12 USA, FH12, FH16, B6, B7, B7F, B10M	
	1190131	BALL JOINT, GEARBOX LHT	B10, B58, B7	
	1190132	BALL JOINT, GEARBOX RHT	B10, B58, B7	

	OEM NO	DESCRIPTION	NOTES	
	1527234 (382745)	BALL JOINT, GEARBOX RHT	F6S, FL616-619, F7, F7 USA, FL7, FS7, FE7, F10, FL10, FS10, F12, FL12, F16, N7 ch.12001- N10, N10 USA, NL10S, NL10 AUS, N10BR MARK2, N12, N12 USA, NL12S, NL12 AUS, N12BR MARK2, B7 ch.30000-, B10M ch.20001-, B10M ch.40000-	
	1527453	BALL JOINT M10x1/M14X1,5mm	NL10 / NL12 / B10 B7 / B58	
	1668179	BALL JOINT, GEARBOX RHT	FH12, FH16	
	1526275	SPRING, GEARBOX		
	183368	NEEDLE BEARING		
	1669436	BALL JOINT	FH12 / FH16 OLD	
	20366968 3191939	BALL JOINT	FH12 / FH16 NEW	
	266444	GEARBOX CONTROL CABLE	F89, G89; L.H.D. SR61 ch.-5186, F89, G89; R.H.D. SR61	
	382652	GEARBOX CONTROL CABLE	F89/G89 SR61 LHD, F89/G89 SR61 RHD ch.- 6855	
	267862	GEARBOX CONTROL CABLE	F7; R.H.D. ch.-21449; R62, F10; R.H.D. ch.- 19625; R62	

	OEM NO	DESCRIPTION	NOTES	
	267863	GEARBOX CONTROL CABLE	F10 L.H.D. ch.-19625, F10 R.H.D. ch.-19625, F12 R.H.D. ch.-19731 Gearbox: R62, SR62	
	267866	GEARBOX CONTROL CABLE	F12 SR62 LHD ch.19781, F12 MR62B LHD ch.-2941	
	382910	GEARBOX CONTROL CABLE	N86, NB86	
	382911	GEARBOX CONTROL CABLE	F86, FB86; SR61 R.H.D. AUS., F88, FB88, G88; SR61 L.H.D. ch.49736-, F88, FB88, G88; SR61 R.H.D. ch.30001-, F89, G89; SR61 ch.-5185	
	382912	GEARBOX CONTROL CABLE	F86, FB86; R51 R.H.D., F88, FB88, G88; R61 L.H.D. ch.49736-, F88, FB88, G88; SR61 ch.30001-49735, F88, FB88, G88; R60/61 ch.30001-	
	382913	GEARBOX CONTROL CABLE	F86, FB86 R50, R51 LHD, F89, G89 R61 ch.- 5185, F6S R62 RHD, F7 R52 RHD	
	382915	GEARBOX CONTROL CABLE	N88, NB88, N7 ch.- 11549 R51, R52	
	382943	GEARBOX CONTROL CABLE	N10 ch.-39079; MR61, MR62, N12 ch.-8288; MR61B, MR62B	
	382944	GEARBOX CONTROL CABLE	N7 ch.-14498 SR62, N10 ch.-39079, N12 ch.-8288; R61, SR61, R62, SR62	
	273081	REPAIR KIT, GEARBOX CONTROL CYLINDER	F86, FB86, F87, F88, F89, G89, F6S, F7, N86, NB86, N88, NB88, N7, N10, N12 For gearbox:R50, R51, R52, R60, R61, SR61	

	OEM NO	DESCRIPTION	NOTES	
	276146 (273748)	REPAIR KIT, GEARBOX CONTROL CYLINDER	F6S, FL616-619, F7, FL7, F10, FL10, F12, N7, N10, N12 For gearbox: R52B, MR62, MR62B, R62, SR62, R63	
	273082	REPAIR KIT, GEARBOX INHIBITOR VALVE	F86, FB86, F87, F88, FB88, G88, F89, G89, F6S, F7, F10, F12, N86, NB86, N88, NB88, N7, N10, N10BR MK2, N12 For gearbox: R50, R51, R52*, R52B*, R60, MR61, R61, MR62B*, R62, SR62*, SR63, R62 -27350, MR62B/SR62 -44215 LHD , MR62B/SR62 -51499 RHD, SR62 F12 - 41171 LHD	
	271195 276335	REPAIR KIT, GEARBOX INHIBITOR VALVE	F6S, FL616-619, F7, FE7, FL7, F10, FL10, F12, N7, N10, N10BR, N12, N12BR MK2 For gearbox: R52, R52B, MR62B, R62, SR62	
	276108	REPAIR KIT, GEARBOX INHIBITOR VALVE	FL616-619, FE7, FL7, FS7, F10 ch.25001-, FL10, F12 ch.34001- , F16, N10 ch.306000-, NL10 AUS, NL10BR, NL10S, N12 ch.306000-, NL12 AUS, NL12S For gearbox: R1000, R1400, SR1400, R1700, SR1700, SR2000	
	273665	REPAIR KIT, SPLIT CYLINDER	F88, FB88, G88, F89, G89, F7, FL7, F10, FL10, F12, N7, N10, N10BR MK2, N12, N12BR MK2 For gearbox: SR62, SR70, SR71	
	267844	SHAFT, SPLIT CYLINDER	F88, FB88, G88, F89, G89, F7, FL7, F10, FL10, F12, N7, N10, N10BR MK2, N12, N12BR MK2 For gearbox: SR62, SR70, SR71	
	1527599 (266722)	FORK AND PIN, SPLIT CYLINDER	F88, FB88, G88, F89, G89, F7, FL7, F10, FL10, F12, N7, N10, N10BR MK2, N12, N12BR MK2 For gearbox: SR62, SR70, SR71	
	270925 (3094465) (1669700)	REPAIR KIT, SPLIT CYLINDER	FL7, FS7, F10 ch.25001-, FL10, F12 ch.34001-, FH12, N10 ch.306000- , N10BR MK2, NL10 AUS, NL10BR, NL10S, N12 ch.306000-, N12BR MK2, N12 AUS, NL12BR, NL12S For gearbox: SR1400, SR1700, SR1900	
	270926	REPAIR KIT, RANGE CYLINDER OLD VERSION	FL616-619, FE7, FL7, FS7, F10, FL10, F12, FH12, N10, N10BR MK2, NL10 AUS, NL10BR, NL10S, N12, N12BR MK2, NL12 AUS, NL12BR, NL12S, R1000 gearbox no.-11842, R1400 - 27186, SR1400 -27286, R1700 -9636, SR1700 -63971, SR1700 Geartronic - 64825, SR1900 -457, G7EGS	
	276820 3092050 3093230	REPAIR KIT, RANGE CYLINDER NEW VERSION	R1400, R1700, SR1400 SR1700, SR1900	

	OEM NO	DESCRIPTION	NOTES	
	270899	REPAIR KIT, RANGE CYLINDER	R1400, R1700, SR1400 SR1700, SR1900	
	271198 276813 (3094518)	REPAIR KIT FOR COVER TO SPLIT CYLINDER, AND RANGE CYLINDER	F616-F619, FE7, FL7, FS7, F10, F12, FH12, F16, FH16, N10, N10BR MK2, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B9M*, B10M* For gearbox: R1000, R1400, SR1400, R1700, SR1700, SR1900, SR2000, SRO2400, *G7EGS gearbox no. -2126	
	-	REPAIR KIT, INHIBITOR VALVE	FOR: 1669324	
	-	REPAIR KIT, INHIBITOR VALVE	FOR: 1068951	
	1669678 1652756	PISTON, RANGE CYLINDER	R1400, R1700, SR1400 SR1700, SR1900	
	273667	REPAIR KIT, GEARBOX INHIBITOR VALVE	FOR: 267859	
	382364	SPEEDOMETER GEAR	Z11	
	382368	SPEEDOMETER GEAR	Z12	
	382372	SPEEDOMETER GEAR	Z13	
	382376	SPEEDOMETER GEAR	Z14	

	OEM NO	DESCRIPTION	NOTES	
	382380	SPEEDOMETER GEAR	Z15	
	382384	SPEEDOMETER GEAR	Z16	
	1527208	BEARING, SPEEDOMETER GEAR		
	1580493	SPEEDOMETER CABLE	L: 4.000mm	
	1655421 (267208)	COVER, GEARBOX	SR62	
	1656121 1653057	COVER, GEARBOX	R1400, R1700, SR1400, SR1700	
	1656128	COVER, GEARBOX	SR1400, SR1700, SR1900	
	267316	SEALING RING, GEARBOX 59,90X80X8/10	F88, F87, F7, FE7, FL7, N7 Gearbox: R50, R51, R52, R52B	
	267268	SEALING RING, CLUTCH HOUSING TO GEARBOX 64,9X90X10	F86, FB86, F87, F88, FB88, F89, G89, FL616-619, F7, FE7, FL7, FS7, F10, FL10, F12, F16, N88, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12BR, g.box G7-EGS	
	267269	SEALING RING, TRANSFER CASE HOUSING 80X100X10	F86, FB86, F87, F88*, F89*, G89*, F6S, FL616-619, F7, FE7, FL7, F10, FL10, F12, N88, NB88, N7, N10, N10BR MK2, N12, N12BR MK2 For gearbox: R50, R51, R52B, R60, MR61, R61, MR62, MR62B, R62, SR62, R63	

	OEM NO	DESCRIPTION	NOTES	
	1578100	CONTACT, SPLIT CYLINDER		
	382353	OIL FILTER, GEARBOX	R50, R51, R52, R52B, R60, R61, R62, SR61, SR62, MR61, MR62, MR62B	
	423135	OIL FILTER, GEARBOX	N10 ch.-305999, N12 ch.-305999, F10 ch.-313999, F12 ch.-313999 For 11-23135	
	3517857 (1266286)	OIL FILTER, GEARBOX	F10 ch.-25001-, F12 ch.34001-, FL10, N10 ch.49001-, N12 ch.-12001-	
	1526188	OIL FILTER, GEARBOX	F16	
	270823	GASKET SET, GEARBOX	F7, FL7, F10, FL10, F12, N7, N10, N10BR MK2, N12, N12BR MK2 For gearbox: R61, SR61, R62, MR62, MR62B, SR62, R63	
	382173	SLECTOR FRAME	R60, R61, SR61, R62, SR62, MR62	
	382565 (382183)	SLIDE	R50, R51, R52, R61, SR61, R62, SR62, MR62, R70, SR70	
	382184	INPUT SHAFT 29 T	R61	
	267849	INPUT SHAFT	R62, MR62	

	OEM NO	DESCRIPTION	NOTES	
	382250	INPUT SHAFT	SR61	
	1527077	INPUT SHAFT	SR62	
	267944	GEAR 31T	SR61, SR62	
	267285	COUNTER SHAFT 28T	SR62	
	382255	COUNTER SHAFT 28T	SR61	
	382257	GEAR 427	SR61, SR62	
	382797	ENGAGING RING	R61, R62, SR61, SR62, MR62	
	267284	ENGAGING RING	SR62	
	266811	ENGAGING RING	SR61	
	382605	COUPLING SLIVE	R61, SR61	

	OEM NO	DESCRIPTION	NOTES	
	382777	SYNCHRRONIZER HUB	R60, R61, R62, MR62, SR61, SR62	
	266984	GEAR 3RD 34T	R61, R62, MR62, SR61, SR62	
	266983	GEAR 2ND 41T	R61, R62, MR62, SR61, SR62	
	266505	ENGAGING RING	R61,SR61	
	267921	COUPLING SLEEVE	R62, MR62, SR62	
	382101	COUPLING SLEEVE	R50, R51, R60, R61, SR61	
	382800	COUPLING SLEEVE	R52, R61, R62, MR62, SR61, SR62	
	382197	SYNCHRRONIZER HUB	R52, R61, R62, MR62, SR61, SR62	
	266982	GEAR 1ST 48T	R61, R62, MR62. SR61, SR62	
	382559	COUNTER SHAFT 27T	R61, R62, MR62	

	OEM NO	DESCRIPTION	NOTES	
	266987	COUNTER SHAFT 27T	SR61, SR62	
	382597	GEAR REVERSE 30T	R61, R62, MR62, SR61, SR62	
	382564	GEAR REVERSE 15T	R61, R62, MR62, SR61, SR62	
	266767	COUPLING SLEEVE	R50, R51, R52, R60, R62, MR62, SR61, SR62	
	382560	MAIN SHAFT 22T	R61, R62, MR62, SR61, SR62	
	382189	GEAR CONSTANT 44T	R60, R61, R62, MR62	
	382248	GEAR CONSTANT 45T	SR61, SR62	
	382190	GEAR 3RD 39T	R60, R61, R62, MR62, SR61, SR62	
	382191	GEAR 2ND 33T	R60, R61, R62, MR62, SR61, SR62	
	382232	REVERSE SHAFT	R60, R61, R62, MR62, SR61, SR62	

	OEM NO	DESCRIPTION	NOTES	
	382220	ENGAGING RING	R60, R61, SR61	
	267949	ENGAGING RING	SR62	
	382216	OUTPUT SHAFT	R60, R61, RSR61	
	266536	OUTPUT SHAFT	SR62	
	267954	ENGAGING RING	R62, MR62, SR62	
	267953	ENGAGING RING	R62, MR62, SR62	
	1526943	COUPLING SLEEVE	R62, MR62, SR62	
	382223	COUPLING SLEEVE	R60, R61, SR61	
	382563	GEAR 36T	R61, SR61	
	267350	GEAR 36T	SR62	

	OEM NO	DESCRIPTION	NOTES	
	382562	GEAR 36T	R61, R62, MR62, SR61, SR62	
	382561	COUNTER SHAFT 15T	R61, R62, MR62, SR61, SR62	
	266925	ENGAGING RING	SR70	
	267234	COUPLING SLEEVE	SR70	
	181565	BEARING RACE Ø 55X65X46	R50, R51, R52, R60, R61, R62, MR62, SR61, SR62	
	181569	BEARING RACE	R60, R61, R62, MR62, SR61, SR62	
	266938	WASHER	R61, R62, MR62, SR61, SR62	
	266939	THRUST WASHER	R50, R51, R52, R60, R61, R62, MR62, SR61, SR62	
	382234	THRUST WASHER	R60, R61, R62, MR62, SR61, SR62	
	1522293	NUT	SR2000, SRO2400, R70, SR70, Diff.EV72, EV87, EV90, EV91	

	OEM NO	DESCRIPTION	NOTES	
	1672236 (1655310)	INPUT SHAFT	R1000	
	1653095 (1652520)	INPUT SHAFT	R1400, R1700, SR1400, SR1700	
	1652521	INPUT SHAFT	R1000, SR1400, SR1700,SR1900	
	1656031	INPUT SHAFT	R1000, SR1400, SR1700,SR1900	
	1656030 (1668470)	INPUT SHAFT	R1400, R1700, R1900	
	1668241	COUPLING SLEEVE	R1000, SR1400, SR1700,SR1900	
	1653092 (1652522)	GEAR SPLITTER	R1000, SR1400, SR1700,SR1900	
	1653921	ENGAGING RING	R1000, SR1400, SR1700,SR1900	
	1655557 (1669416)	GEAR 1SD	R 1000	
	1653093 (1669804)	GEAR SPLITTER	R1000, SR1400, SR1700,SR1900	

	OEM NO	DESCRIPTION	NOTES	
	1667137	GEAR 3 RD.	R1000 B12	
	1653088 (1652536)	GEAR 3RD	R1000, SR1400, SR1700,SR1900	
	1069318	GEAR 1 RD. (NEW MODEL)	R1700	
	1652527 (1653378)	GEAR 1ST	R1400, R1700	
	1669656 (1652901) (1656038) (1669652)	GEAR 1 ST	SR1700, SR1900	
	1653376 (1652529)	GEAR 2ST	R1400, R1700, SR1400, SR1700	
	1652871	GEAR 3RD	R1400, R1700	
	1652872	GEAR	R1400, R1700, SR1400, SR1700	
	1653920	ENGAGING RING	R1000, R1400, R1700	
	1668213	GUIDE SLEEVE	R1000, R1400, R1700, SR2000, SRO2400	

	OEM NO	DESCRIPTION	NOTES	
	1668240 (1653240)	COUPLING SLEEVE	R1000, R1400, R1700	
	1669032	ENGAGING SLEEVE	Sr1700, Sr1900	
	1653924	ENGAGING RING	R1000, R1400, R1700	
	1669353	ENGAGING RING	R1700, R1900	
	1668214 (1653945)	GUIDE SLEEVE	R1000, SR1400, SR1700, SR1900	
	1668244 (1653944)	COUPLING SLEEVE	R1000, SR1400, SR1700, SR1900	
	1669034	ENGAGING SLEEVE	R1700, R1900	
	1652544	HUB	R1000, SR1400, SR1700, SR1900	
	1652545	COUPLING SLEEVE	R1000, SR1400, SR1700, SR1900	
	1652550	SUN GEAR	R1000, SR1400, SR1700, SR1900	

	OEM NO	DESCRIPTION	NOTES	
	1653117 (1693883) (1669805)	GEAR	SR1400, SR1700, SR1900	
	1653922	ENGAGING RING	SR1400, SR1700, SR1900, SR2000, SRO2400	
	1669351	ENGAGING RING	SR1700, SR1900	
	1668212 (1653942)	GUIDE SLEEVE	SR1400, SR1700, SR1900	
	1668242	COUPLING SLEEVE	SR1400, SR1700, SR1900, SR2000, SRO2400	
	1652528	GEAR 1ST	SR1400, SR1700, SR1900	
	1653925	ENGAGING RING	SR1400, SR1700, SR1900	
	1669352	ENGAGING RING	SR1700, SR1900	
	1653935	ENGAGING RING	R1400, R1700, SR1400, SR1700	
	1653936	ENGAGING RING	R1400, R1700, SR1400, SR1700	

	OEM NO	DESCRIPTION	NOTES	
	1668245	GUIDE SLEEVE	SR1400, SR1700, SR1900	
	1669035	ENGAGING SLEEVE	SR1700, SR1900	
	1656251	MAIN SHAFT	SR1400, R1700	
	1668065 (20366733)	MAIN SHAFT	R1000 B12	
	1652523	MAIN SHAFT	R1400, R1700	
	1652524	MAIN SHAFT	SR1400, SR1700, SR1900	
	1668148	MAIN SHAFT	SR1400, SR1700, SR1900	
	1652617	GEAR	SR1400, SR1700, SR1900	
	1667138	GEAR 3 ST.	R100 B12	
	1656265	HUB	SR1400, SR1700, SR1900	

	OEM NO	DESCRIPTION	NOTES	
	1656266	COUPLING SLEEVE	SR1400, SR1700, SR1900	
	1655558 (1669450)	GEAR REVERSE	R 1000	
	1652618	GEAR REVERSE	SR1400, SR1700, SR1900	
	1673432	GEAR REVERSE	R1700, SR1700, SR1900	
	1656226	SUN GEAR	SR1400, SR1700, SR1900	
	1655553 (1672237)	GEAR	R 1000	
	1668248 (1653948)	COUPLING SLEEVE	R1000, SR1400, SR1700	
	1652539	DRIVE GEAR	R1400, R1700, SR1400, SR1700	
	1652593 (1652592)	OUTPUT SHAFT (PLANET CARRIER COMPLETE)	R1400, R1700, SR1400, SR1700, SR1900	
	276115	PLANET GEAR KIT	R1400, R1700, SR1400, SR1700, SR1900	

	OEM NO	DESCRIPTION	NOTES	
	1656209	RING GEAR	R1400, R1700, SR1400, SR1700, SR1900	
	1668452	ENGAGING RING	R1400, R1700, SR1400, SR1700, SR1900	
	1668458	ENGAGING SLEEVE	R1400, R1700, SR1400, SR1700, SR1900	
	1668450	ENGAGING RING	R1400, R1700, SR1400, SR1700, SR1900	
	1652727	SIDE CONTROL SHAFT	R1400, R1700, SR1400, SR1700	
	1667078	DRIVE GEARAXLE SHAFT ASS.	R1000	
	1652628 (3192123)	DRIVE GEARAXLE SHAFT ASS.	R1700, R1700, SR1400, SR1700, SR1900	
	1653840	SHAFT AXEL	R1700, R1700, SR1400, SR1700	
	1667266 (1653841)	ENGAGING SLEEVE (POWER TAKE-OFF)		
	1656232	SPACER	SR1700, SR1900	

	OEM NO	DESCRIPTION	NOTES	
	1652548	SPACER	R1000, R1400, R1700	
	1652578	INNER BUSH	R1700, R1700	
	1652817	SPACER RING	SR1400, SR1700, SR1900	
	1652776	SEALING RING, OUTPUT SHAFT Ø 90X145X10/15	SR1400, SR1700, SR1900, SR2000	
	1653956 1653909 1668202	SYNCHRONIZER CONE	SR1400, SR1700 SR1900	
	1653960 1653903	SYNCHRONIZER CONE	SR1400, SR1700 SR1900	
	1653961 1653905 1653951	SYNCHRONIZER CONE	SR1400, SR1700 SR1900	
	1653962 1653906	SYNCHRONIZER CONE	SR1400, SR1700 SR1900	
	1653964	SYNCHRONIZER CONE	SR1400, SR1700 SR1900	
	267345	LEVER, HANDLE	For: 27.2422	

	OEM NO	DESCRIPTION	NOTES	
	382262	BUSHING, SELECTOR FORK	R61, R62, SR61, SR62	
	943741	SEALING RING	R61, R62, SR61, SR62	
	1655126 1527598	LEVER, SPLIT CYLINDER AND SELECTOR FORK		
	1526461	OIL COOLER, GEARBOX	SR61, SR62	
	1527510 267409 267413	BALL BEARING (FAG 539090)	R61, R62, SR61, SR62	
	1576103	RUBBER CUSHION, GEARBOX	N10 ch.-29718, N12 ch.-5176, F10 ch.-25000, F12 ch.-34000 Gearbox: R62, SR62	
	1586316	RUBBER CUSHION, GEARBOX	F7, F10, F12, N7, N10, N12 Gearbox: R62, SR62, MR62	
	1605093	RUBBER CUSHION, GEARBOX	SR70	
	1614600	RUBBER CUSHION, GEARBOX	F10 ch.25001-, F12 ch.34001-, N10 ch.306000-, NL10 AUS, N12 ch.306000-, NL12 AUS, NL12S	
	1081660	RUBBER CUSHION, GEARBOX	FL608-615, F10 ch.314000- F12 ch.314000-	

	OEM NO	DESCRIPTION	NOTES	
	3097099 8550978 272909	REPAIR KIT, BRAKE ADJUSTING Z-CAM L	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	3097100 8550977 272908	REPAIR KIT, BRAKE ADJUSTING Z-CAM R	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1696924	PINION, Z-CAM L	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1696925	PINION, Z-CAM R	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	272910 1696453	CROSS SHAFT, Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	3090997 1081819	ADJUSTING DEVICE Z-CAM / L (NEW VERSION)	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	3090998 1081820	ADJUSTING DEVICE Z-CAM / R (NEW VERSION)	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1606775	ADJUSTING DEVICE Z-CAM / L (OLD VERSION)	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1607502	ADJUSTING DEVICE Z-CAM / R (OLD VERSION)	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	3097092 1696444	RETURN SPRING Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	

	OEM NO	DESCRIPTION	NOTES	
	1698967	GAITER,ADJUSTING PIN Z-CAM For 67.76099, 67.90964	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	276097	REPAIR KIT REVERSE LOCK Z-CAM / L	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	276098	REPAIR KIT REVERSE LOCK Z-CAM / R	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	272906	REPAIR KIT Z-CAM L	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	272907	REPAIR KIT Z-CAM R	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1696446	THRUST PIN Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	3097299 1698346 1696445	PIN RETURN SPRING Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1626699	GAITER ADJUSTING PIN Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	3090954 1696448	DUST COVER Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	272905	SEALING KIT Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	

	OEM NO	DESCRIPTION	NOTES	
	1696449	COVER BRAKE Z-CAM	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1696450	GASKET, Z-CAM	For 67.96449	
	272904	COVER, REPAIR KIT Z-CAM	For 67.97099, 67.50977	
	276096	REPAIR KIT ADJUSTING PIN, Z-CAM	OLD VERSION	
	276099	REPAIR KIT ADJUSTING PIN, Z-CAM	OLD VERSION	
	3090964 (276100)	REPAIR KIT ADJUSTING PIN, Z-CAM	NEW VERSION	
	1697234	SEALING RING, Z-CAM		
	1586683 (341720)	BRAKE SHOE SPRING	ALL MODELS	
	346499	BRAKE SHOE SPRING	ALL MODELS	
	55098	BRAKE SHOE SPRING 4,5X28X200-230	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	1695051	SPRING, BRAKE SHOE Ø3,5X4,5X24X223	ALL MODELS	
	351949 1505324	SLACK ADJUSTER REAR , L	F10 / F12 / N10 / N12	
	351950 1505325	SLACK ADJUSTER REAR , R	F10 / F12 / N10 / N12	
	1587483	SLACK ADJUSTER FRONT , L	F10 / F12 / N10 / N12	
	1587484	SLACK ADJUSTER FRONT , R	F10 / F12 / N10 / N12	
	-	SLACK ADJUSTER, TRAILER	ALL MODELS	
	272800 3091286	REPAIR KIT, AUTOMATIC SLACK ADJUSTER	ALL MODELS	
	3090075 270827 271172	BRAKE SHOE Z-CAM WIDTH 175 mm (1 Pcs.)	FL7, F10, FL10, F12, FH12, F16, FH16, NL10 Australia, NL10S, NL12	
	3090076 270828 271173	BRAKE SHOE Z-CAM WIDTH 200 mm (1 Pcs.)	FL7, F10, FL10, F12, FH12, F16, FH16, NL10 Australia, NL10S, NL12	
	3090077 270829 271174	BRAKE SHOE Z-CAM WIDTH 225 mm (1 Pcs.)	FL7, F10, FL10, F12, FH12, F16, FH16, NL10 Australia, NL10S, NL12	

	OEM NO	DESCRIPTION	NOTES	
	1592875	SLACK ADJUSTER,L-R		
	1581466	SLACK ADJUSTER,L-R		
	1605932	SLACK ADJUSTER,L-R		
	1135019	SLACK ADJUSTER,L-R		
	1586194	SLACK ADJUSTER,L-R		
	6869601	SLACK ADJUSTER,L-R		
	1590239	SLACK ADJUSTER,L-R		
	1590556	SLACK ADJUSTER,L-R		
	1599738	SLACK ADJUSTER,L-R		
	1196321	SLACK ADJUSTER,L-R		
	1196322	SLACK ADJUSTER,L-R		
	1136433	SLACK ADJUSTER,R		
	1195462	SLACK ADJUSTER,R		
	1136432	SLACK ADJUSTER,L		
	1195461	SLACK ADJUSTER,L		
	1586191	SLACK ADJUSTER,R		
	1586193	SLACK ADJUSTER,R		
	1586190	SLACK ADJUSTER,L		
	1586192	SLACK ADJUSTER,L		



	OEM NO	DESCRIPTION	NOTES	
	3095173	BRAKE LINING	Ø 125 mm	
	3095174	BRAKE LINING	Ø 125 mm	
	3095175	BRAKE LINING	Ø 150 mm	
	3095176	BRAKE LINING	Ø 150 mm	
	3095177	BRAKE LINING	Ø 175 mm	
	3095178	BRAKE LINING	Ø 175 mm	
	3095179	BRAKE LINING	Ø 200 mm	
	3095180	BRAKE LINING	Ø 200 mm	
	3095181	BRAKE LINING	Ø 225 mm	
	3095182	BRAKE LINING	Ø 225 mm	

	OEM NO	DESCRIPTION	NOTES	
	1629832	PROTECTING PLATE Ø234 X 446 X 30.5	FH 12 / FH 16 FM10/FM12	
	1629833	PROTECTING PLATE Ø234 X 446 X 44	FH 12 / FH 16 FM10/FM12	
	1629834	PROTECTING PLATE Ø234 X 446 X 55.5	FH 12 / FH 16 FM10/FM12	
	1629835	PROTECTING PLATE Ø234 X 446 X 68	FH 12 / FH 16 FM10/FM12	
	1629836	PROTECTING PLATE Ø234 X 446 X 80.5	FH 12 / FH 16 FM10/FM12	
	1584671	ANCHOR PIN BRAKE ROLLER S-CAM	Ø 56X25mm	
	1584673	ANCHOR PIN BRAKE ROLLER S-CAM	Ø 68X30mm	
	1586716	ANCHOR PIN BRAKE ROLLER S-CAM	Ø 116X30mm	
	1588403 1577884	CLAMP SHOE, FRONT SPOKE WHEEL HUB 94X83X62 / Ø20mm	ALL MODELS	
	1581193	CLAMP SHOE, FRONT SPOKE WHEEL HUB 112X43X53 / Ø20mm	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	324005	BRAKE DRUM, REAR	N88, F86, F88, B58, B57	
	1577439	BRAKE DRUM, FRONT	F7, N7, F10, N10, F12, N12	
	1589429	BRAKE DRUM, REAR	F7, N7, F10, N10, F12, N12	
	1590313 1134818	BRAKE DRUM, REAR	F12	
	1599678	BRAKE DRUM, FRONT	F10, F12, F16, FL7, FL10, FL12, FH12, FH16, N10, NL10S, NL12S	
	1599679	BRAKE DRUM, REAR	F10, F12, F16, FL7, FL10, FL12, FH12, FH16, N10, NL10S, NL12S	
	352787 (1590146)	BRAKE DRUM, REAR	N7, N10, N12, F89, F7, F10, F12, B59	
	352788	BRAKE DRUM, FRONT	N7, N10, N12, F89, F7, F10, F12, B59	
	1599009	BRAKE DRUM, FRONT	F10, F12, F16, FL7, FL10, FL12, FH12, FH16, N10, NL10S, NL12S	
	1599010	BRAKE DRUM, FRONT	FL7, FL10, F12, FH12, F16, FH16, N10, NL10S, N12, NL12S, B10/12	
	1599011	BRAKE DRUM, REAR	F10, F12, F16, FL7, FL10, FL12, FH12, FH16, N10, NL10S, NL12S	
	1599012	BRAKE DRUM, REAR	F10, F12, F16, FL7, FL10, FL12, FH12, N10S, N12, NL12S, B10B, B12	
	335217 (335005)	BRAKE DRUM, FRONT	N88, F86, F88, B58, UNILEX B57	
	1500537	BRAKE DRUM, FRONT	B57, B58	
	366865 (1584129)	BRAKE DRUM, FRONT	F10, N10	
	366866 1584131 1586005	BRAKE DRUM, REAR	F10, N10	
	352786	BRAKE DRUM, FRONT	F89, N7, N10, N12, F10, F12, B59	
	1075310	BRAKE DRUM, REAR	FL7, F12, N12 CAME Z	
	1075306	BRAKE DRUM, FRONT	F10, F12, F16, FL7, FL10, N10, N12	
	1599968	BRAKE DRUM, REAR	F12, F16	

	OEM NO	DESCRIPTION	NOTES	
	- 943406 943491 943402	WHEEL BOLT AND NUT SET WHEEL BOLT WHEEL NUT WITH THRUST PLATE WHEEL NUT	F88, FB88, G88 ch.30001-, F89, G89, N10 ch.-13311	
	- 943405 943491 943402	WHEEL BOLT AND NUT SET WHEEL BOLT WHEEL NUT WITH THRUST PLATE WHEEL NUT	F88, FB88, G88 ch.6998-, F89, G89 6x2 ch.6998-, N10 ch.-17189,	
	- 1573081 943491	WHEEL BOLT AND NUT SET FRONT/REAR	FL7, FL10, F7, F10 ch.25001-, F12 ch.34001-, F16 B9M, B10M	
	- 1573082 943491	WHEEL BOLT AND NUT SET REAR	FL7, FL10, F7, F10, F12, F16, F86, FB86, F87, F88, FB88, G88 ch.30001-, F89, G89, N7, N10, N12 B9M, B10M	
	- 1589009 943491	WHEEL BOLT AND NUT SET REAR	FL10, F10, F12, F16, N10, N12, B9M, B10M ch.11500-	
	1588406	WHEEL BOLT AND NUT SET M20X2X57	TRILEX WHEEL (659112616)	
	362164	WHEEL BOLT AND NUT SET M20X2X60	TRILEX WHEEL (659112500)	
	1577424	WHEEL BOLT AND NUT SET M20X2X75	TRILEX WHEEL (659112509)	
	1581687	WHEEL BOLT AND NUT SET M20X2X100	TRILEX WHEEL (659112611)	
	1608293 (1581604)	WHEEL BOLT AND NUT SET M20X2X115	TRILEX WHEEL (659112612)	


	OEM NO	DESCRIPTION	NOTES	
	1608732	BRAKE CYLINDER	TYPE 24 / 30	
	1605860	BRAKE CYLINDER	TYPE 30 / 30	
	-	BRAKE CYLINDER	TYPE: 24	
	-	BRAKE CYLINDER	TYPE: 30	
	-	BRAKE CYLINDER	TYPE: 24/24	
	-	BRAKE CYLINDER	TYPE: 30/30	
	-	BRAKE CYLINDER	TYPE: 36/30	
	-	REPAIR KIT	TYPE: 24/24	
	-	REPAIR KIT	TYPE: 30/30	
	-	REPAIR KIT	TYPE: 36/30	



	OEM NO	DESCRIPTION	NOTES	
	353314	DIAPHRAGM, BRAKE CYLINDER	TYPE: 9	
	325197	DIAPHRAGM, BRAKE CYLINDER	TYPE: 12	
	1614796	DIAPHRAGM, BRAKE CYLINDER	TYPE: 16	
	1614797 (1609309)	DIAPHRAGM, BRAKE CYLINDER	TYPE: 20	
	1614798 (1609310)	DIAPHRAGM, BRAKE CYLINDER	TYPE: 24	
	1614799 (1609311)	DIAPHRAGM, BRAKE CYLINDER	TYPE: 30	
	1518481 1518741	DIAPHRAGM, BRAKE CYLINDER	TYPE: 36	
	-	DIAPHRAGM, BRAKE CYLINDER	TYPE: 20 LONG STROKE	
	-	DIAPHRAGM, BRAKE CYLINDER	TYPE: 24 LONG STROKE	
	-	DIAPHRAGM, BRAKE CYLINDER	TYPE: 30 LONG STROKE	

	OEM NO	DESCRIPTION	NOTES	
	966513	HOSE, BRAKE 12,7-12,7-500	F84/F85/F86/F87/F88 F7/FL7/F10/FL10/F12/ F16 N7/N10/N12	
	966514	HOSE, BRAKE 12,7-12,7-550	F6/FL616/FL619/F7/FL 7/F10 FL10/F12/F16 B9M/B10M	
	966515	HOSE, BRAKE 12,7-12,7-600	F86/F87/FL608/FL619/ F7/FL7 F10/FL10/F12/F16/N7/ N10 NL10/N12/NL12 B9M/B10M	
	966517	HOSE, BRAKE 12,7-12,7-700	F88/FL608/FL619/F7/ FL7 F10/FL10/F12/F16/N10 /NL10 N12/NL12	
	966519	HOSE, BRAKE 12,7-12,7-800	F86/F87/F88/F89/F7/F L7 F10/FL10/F12/F16 N7/N10/NL10/N12/NL1 2 B9M/B10M	
	966555	HOSE, BRAKE 12,7-M16-550	F7/FL7/F10/FL10/F12/ F16 N7/N10/NL10/N12/NL1 2 B9M/B10M/B12	
	966556	HOSE, BRAKE 12,7-M16-600	F7/FL7/F10/FL10/F12/ F16 N7/N10/NL10/N12/ NL12 B9M/B10M/B12/C10M	
	966557	HOSE, BRAKE 12,7-M16-650	F7/FL7/F10/FL10/F12/ F16 N7/N10/NL10/N12/ NL12 B9M/B10M/B12	
	966558	HOSE, BRAKE 12,7-M16-700	F7/FL7/F10/FL10/F12/ F16 N7/N10/NL10/N12/NL1 2 B9M/B10M	
	966567	HOSE, BRAKE 12,7-M22-500	F7/F10/FL10/F12 N7/N10/N12/B9M/B10 M	

	OEM NO	DESCRIPTION	NOTES	
	966578	HOSE, BRAKE 9,5-9,5-500	F89/G89/F7/F10/F12 N7/N10/N12/B9M/B10 M	
	966579	HOSE, BRAKE 9,5-9,5-550	F10/F12 N7/N10/N12	
	966580	HOSE, BRAKE 9,5-9,5-600	F6/F7/F10/F12 N7/N10/N12	
	966581	HOSE, BRAKE 9,5-12,7-650	N7/N10/N12	
	1606681	BUSHING, BRAKE SHOE	F10, F12, N10, N12	
	1606683	BUSHING, BRAKE SHOE	F10, F12, N10, N12	
	1586974	BUSHING, BRAKE SHOE	F10, F12, N10, N12	
	232458	JOURNAL CROSS 44X126	F6, F6S, FE6, FL608-615, FL616-619, F7, FE7, FL7, FS7, F10 ch.-25000, FL10, FL12, F12 ch.314000-, N7, NL10S, NL12S, N10/N12 ch.306000- B7, B10M	
	1651032	JOURNAL CROSS 50X152,60	F7, F7 USA, FS7, FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N10, N10 USA, NL10 AUS, NL10BR, NL10S, N12, N12 USA, NL12 AUS, NL12BR, NL12S, B10B, B10M, B10R, C10M, B12, B12BR	
	232362 (262985)	JOURNAL CROSS 52X136	F7, F10, N10, N12, F86, F88, F89, G88, G89	

	OEM NO	DESCRIPTION	NOTES	
	232540	JOURNAL CROSS 57X144	F609, F610, F611, F613, F614	
	1651229 1067293	JOURNAL CROSS 57X152,7	FL7, F10 ch.25001-, F10 ch.314000-, FL10, FS10, F12, FL12, FH12, F16, FH16, N10, NL10 AUS, NL10BR, NL10S, N12, N12 USA, NL12S, NL12 AUS, NL12BR	
	1068247	UNIVERSAL JOINT	Ø 52 x 147	
	1068253 1651237	UNIVERSAL JOINT	Ø 59 x 167.50	
	1068250	UNIVERSAL JOINT	Ø 57 x 152	
	1070172	UNIVERSAL JOINT		
	6212893	UNIVERSAL JOINT		
	1651030	FLANGE, PROPELLER SHAFT 12 HOLES (50mm)	FL7, FL10, FH12, FH16	
	231500	FLANGE, PROPELLER SHAFT 8 HOLES (50mm)	F88, F89, F10, F12	
	1651211	FLANGE, PROPELLER SHAFT 8 HOLES (57mm)	F10, F12, N10, N12	

	OEM NO	DESCRIPTION	NOTES	
	1651226 (1651172)	FLANGE, PROPELLER SHAFT 12 HOLES Q EST.203, Q SPIDER 57 MM	FL10, F10, N10, F12, N12, FH12, F16	
	232397	FLANGE, PROPELLER SHAFT 8 HOLES Q EST.174,50, Q SPIDER 50 MM	F7, FL7, FL10, F10, F12, N10, N12, F88, F89, G88, G89	
	20471436 1068228	FLANGE, PROPELLER SHAFT 4 HOLES 59mm	FM 7, FM9, FM10,12 FH 12, FH 16, NH12 FL6	
	1651247	FLANGE, PROPELLER SHAFT 4 HOLES 52mm	FM 7, FM9, FM10,12 FH 12, FH 16, NH12 FL6	
	1522300	COMPANION FLANGE	EV72, EV87	
	382990	COMPANION FLANGE	EV80B, EV81B, EV81C, EV82, EV85B, DR80	
	1522297 (1523272)	COMPANION FLANGE	EV87	
	1523262 (1524358) (1652597)	COMPANION FLANGE	EV91	
	1523263	COMPANION FLANGE	EV71, EV72, EV87, EV90	
	1523282 (1523280)	COMPANION FLANGE		

	OEM NO	DESCRIPTION	NOTES	
	382778	NUT	R61, R62, SR61, SR62	
	943805	NUT	EV80B, EV81B, EV81C EV82, EV85B, DR80	
	311760	SPIDER, DIFF.CARRIER	EV81B, EV81C, EV87	
	384094	SPIDER, DIFF.CARRIER	EV80, EV85, DR80	
	1524580 (1522364)	CUP, DIFFERENTIAL	EV87	
	1522293	NUT	EV72, EV87, EV90, EV91	
	1522079	THRUST WASHER, DIFF.	EV72, EV87	
	383760	THRUST WASHER, DIFF.	EV72, EV87	
	948448	OIL SEAL, COMPANION FLANGE 80X110,05X12	F7, FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10 AUS, NL10S, NL12 AUS, NL12S	
	948642	OIL SEAL 90X125,25X10	EV72, EV87	

	OEM NO	DESCRIPTION	NOTES	
	1522895 (943141)	OIL SEAL, PINION DIFF. CARRIER 80X130,2X12/20	EV71, EV80, EV80B, EV81, EV81B, EV81C, EV82, DR80; F86, F87, F88, G89, FS6, F7, FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N86, N88, N7, N10, N12, B7, B9, B10	
	1522894 (946257)	OIL SEAL, DIFF. 80X150X12/20	EV85B	
	273394 1522086 1522896	OIL SEAL KIT, REAR AXLE HUB REDUCTION OIL SEAL 150X180X10 OIL SEAL 150X180X16	F88, FB88, G88, F89, G89, N88, N10 ch.- 56683, N12 ch.-18480, NL10BR, NL12BR, B58, B10	
	1522372 3094807	OIL SEAL, REAR AXLE HUB REDUCTION 140X164X15,5/23	FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B9M, B10M	
	944665	OIL SEAL, WHELL HUB 140X170,2X31,5		
	1610765 (944666)	OIL SEAL INNER, REAR WHEEL HUB 168X188/192,5X30	F7, F10, FL10, F12, FH12, F16, FH16, N10, N12	
	3090331	SEALING RING, OUTER REAR WHEEL HUB	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1610078	SEALING RING, OUTER REAR WHEEL HUB	F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10, NL10S, N12, NL12, NL12S, B7, B10B, B10L, B12, B12BR	
	1523634	OIL SEAL, DIFFERENTIAL CARRIER Ø 90X151X10/15	EV-71 NEW MODELS	
	1526008	OIL SEAL, POWER TAKE-OFF Ø 55X80X8	ALL	

	OEM NO	DESCRIPTION	NOTES	
	948635	OIL SEAL, POWER TAKE-OFF Ø 38X62X10	ALL	
	1522373	OIL SEAL, REAR AXLE Ø50X65X8	RAN371, RAN372 RAN471	
	948767	O-RING, REAR AXLE HUB	FL7, F10, FL10, F12, FH12, FL12, F16, FH16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B9M, B10M	
	1523742 3192819 1522394 1523492	COVER	NEW MODELS	
	1522983	THRUST WASHER	RAN2, EV81	
	1522984	THRUST WASHER	RTN1, EV87	
	1524398 120226	THRUST WASHER EV87	FL10, FL12, FH12	
	1523186	THRUST WASHER EV90	F10, F12, NL10, NL12 FL10, FL12, FH12	
	1522393	THRUST WASHER REAR AXLE	RAN471 NEW MODELS	
	120228	THRUST WASHER	EV87	

	OEM NO	DESCRIPTION	NOTES	
	1523185	THRUST WASHER	EV90	
	1629701 1134386	PLUG, REACTION ROD	F10, F12, NL10, NL12 FL10, FL12, FH12, FH16	
	1590885	BUSHING (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1502292	HUP CAP (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1586521	PROTECTING PLATE (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1586518	WEAR RING (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1620742	GASKET COVER (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1593522	SEALING RING (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1586520	SEALING RING (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1593431	THRUST WASHER (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	

	OEM NO	DESCRIPTION	NOTES	
	1590508	RING (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1509219	THRUST WASHER (BOGIE SUSPENSION)	F7, FL7, F40, FL10, F12, F16, N7, N10, NL10, N12, NL12	
	1590064	THRUST WASHER (BOGIE SUSPENSION)		
	1613339	THRUST WASHER (BOGIE SUSPENSION)		
	1613081	BRACE (BOGIE SUSPENSION)		
	955295 13955295	BOLT FOR THRUST WASHER		
	1593470 1509217 1586517 8156726	CRADLE, BOGIE SUSPENSION	F10, F12	
	8162242	REAR BRACKET, FRONT SPRING LH		
	1611534	REAR BRACKET, FRONT SPRING RH		
	1613279	SPRING ANCHORAGE FRONT SUSPENSION	F10 / F12	

	OEM NO	DESCRIPTION	NOTES	
	1619857	SPRING ANCHORAGE FRONT SUSPENSION	F10 / F12	
	1605815	SPRING ANCHORAGE FRONT SUSPENSION	F10 / F12	
	1590744	SPRING ANCHORAGE FRONT SUSPENSION	F10 / F12	
	1581842	SPRING ANCHORAGE FRONT SUSPENSION LH	F10 / F12	
	363806	SPRING ANCHORAGE FRONT SUSPENSION RH	F10 / F12	
	-	BRACKET, FRONT SUSPENSION	F10 / F12	
	1624481	BRACKET, SHOCK ABSORBER	F10 / F12	
	1619860 20548421	SHACKLE, FRONT SPRING	F10 / F12	
	1590360 1586442	SHACKLE, FRONT SUSPENSION	F10 / F12	
	1582780	REAR BRACKET, FRONT SPRING	F10 / F12	

	OEM NO	DESCRIPTION	NOTES	
	1619858	BRACKET, SHOCK ABSORBER	F10 / F12	
	-	BRACKET, TIE ROD, V-STAY	ALL	
	3197878 1509220	WASHER	F10, F12	
	1626994 3078006	FRONT WHEEL HUB	FH12 / FH16	
	1026311	FRONT WHEEL HUB	FH12 / FH16	
	1626992 3078007	REAR WHEEL HUB	FH12 / FH16	
	100034	DIFFERENTIAL HUB	FH12 / FH16	
	1523100	DRIVE SHAFT L=980 MM	FL7, FL10, F7, F10, F12, N7, N10, N12, B10M, B58BR	
	1673055 (1523315)	DRIVE SHAFT L=970 MM	F10, F12, N12 1988-	

	OEM NO	DESCRIPTION	NOTES	
	1523101	DRIVE SHAFT L=1016 MM	FL7, FL10, F7, F10, F12, N7, N10, N12, B10M, B58BR	
	1673056 (1523314)	DRIVE SHAFT L=1025 MM	F10, F12, N12 1988-	
	3950209 8157021	PISTON, AIR BELLOWS	FL6, FL7, FL10, FL12 FH12, FH16	
	1599326	PLATE, AIR BELLOWS	F10, F12, FH12, FH16	
	271561	GASKET KIT, STEERING PUMP	For 92.4642	
	465059	GEAR, STEERING PUMP	For All Pumps	
	8156040 (1598561)	PRESSURE HOSE STEERING PUMP TO STEERING GEAR	F10/ F12; LHD/RHD N12	
	8156045 (1598852)	PRESSURE HOSE STEERING PUMP TO STEERING GEAR	F10/ F12; LHD/RHD N7; LHD	
	8156033 (1598851)	PRESSURE HOSE STEERING PUMP TO STEERING GEAR	NL10S, NL12S, N10, N12	
	8156044 (1598853)	PRESSURE HOSE STEERING PUMP TO STEERING GEAR	NL10S, NL12S	

	OEM NO	DESCRIPTION	NOTES	
	250270	STEERING GEAR ZF NO: 8097 955 143		
	250303	STEERING GEAR ZF NO: 8098 955 294		
	271538	GASKET KIT, STEERING GEAR ZF NO: 8045 633 012	F7, F10, F12	
	271525	GASKET KIT, STEERING GEAR	F7, F10, F12, N7, N10, N12	
	271524	GASKET KIT, STEERING GEAR ZF NO: 8045 633 001	N7, N10, N12, F7, F10, F12	
	271552	GASKET KIT, STEERING GEAR ZF NO: 8045 633 015	N7, N10, N12	
	271559	GASKET KIT, STEERING GEAR ZF NO: 8043 633 025	F7, F10, F12, F16	
	1662328	GASKET KIT, STEERING GEAR ZF NO: 8043 633 024	F7, F10, F12, F16	
	1662390	GASKET KIT, STEERING GEAR ZF NO: 8043 633 021	F10, F12, F16	
	3090285	GASKET KIT, STEERING GEAR	NI10, NL12, FH12, FH16	



	OEM NO	DESCRIPTION	NOTES	
	1626751	STEERING ROD (DRAG LINK)	F10 ch.314000-, F12 ch.314000-, F16 LHD	
	1626750	STEERING ROD (DRAG LINK)	F10 ch.314000-, F12 ch.314000-, F16, F16 AUS RHD	
	1626749	STEERING ROD (DRAG LINK)	F10 ch.314000-, F12 ch.314000- LHD	
	1606283 (1576092)	STEERING ROD (DRAG LINK)	F10 ch.-313999, F12 ch.-313999 LHD	
	1606284	STEERING ROD (DRAG LINK)	F10 ch.-313999, F12 ch.-313999 RHD	
	1626492	STEERING ROD (DRAG LINK)	N10 ch.306000, N12 ch.306000	
	1626493	STEERING ROD (DRAG LINK)	N7, N10, N10 ch.306000 LHD, N12 ch.306000 LHD	
	1588017	STEERING ROD (DRAG LINK)	N7 LHD, N10 LHD, N12 LHD N10 ch.306000, N12 ch.306000	
	1588018	STEERING ROD (DRAG LINK)	N7, N10, N12 RHD	
	1592939	STEERING ROD (DRAG LINK)	FL7, FL10 LHD	



	OEM NO	DESCRIPTION	NOTES	
	1592940	STEERING ROD (DRAG LINK)	FL7, FL10 RHD	
	1075005	STEERING ROD (DRAG LINK)	FH12, FH16	
	1075663 3988704 20393069	STEERING ROD (DRAG LINK)	FH12, FH16	
	8153931	STEERING ROD (DRAG LINK)	FH12, FH16	
	1628636	STEERING ROD (DRAG LINK)	FH12, FH16	
	1075153	STEERING ROD (DRAG LINK)	FH12, FH16	
	1699400 (1696900)	BALL JOINT M52X1,5 LH	FL7, FL10, FL12, FH12, FH16	
	1699401 (1696901)	BALL JOINT M52X1,5 RH	FL7, FL10, FL12, FH12, FH16	
	1695776 (1507826) (1698557)	BALL JOINT, DRAG LINK M30X1,5 RHT	FL7, F10, FS10, FL10, F12, FL12, F16, N7, N10, NL10S, NL10 AUS, N12, NL12 AUS, B10M, B10B, B12	
	1698840 (6869744) (1698558)	BALL JOINT, DRAG LINK M30X1,5 LHT	FL7, F10, F12, FL12, F16, NL10S, B10M, B10B, B12	

	OEM NO	DESCRIPTION	NOTES	
	1698846 (1698532) (1507823)	BALL JOINT, TRACK ROD M30X1,5 RHT	FE6, FL616-619, FL7, FS7, F10, FS10, FL10, F12, FL12, F16, NL10S, NL10 AUS, N12, N12 AUS, NL12S	
	1698847 (1698533) (1507822)	BALL JOINT, TRACK ROD M30X1,5 LHT	FE6, FL616-619, FL7, FS7, F10, FS10, FL10, F12, FL12, F16, NL10S, NL10 AUS, N12, N12 AUS, NL12S	
	3090727	BALL JOINT, DRAG LINK M30X1,5 RHT	FH12, FH16	
	3090728	BALL JOINT, TRACK ROD M30X1,5 LHT	FH12, FH16	
	1698190	BALL JOINT, TRACK ROD M28X1,5 LHT		
	1698191	BALL JOINT, DRAG LINK M28X1,5 RHT		
	1585618 (349619) (1503662)	FILTER ELEMENT, STEERING PUMP	F4, F6, F6S, F7, F10, F12, F16, FL4, FL6, FL7, FL10, FL12, FH12, FH16, N7, N10, N12, NL10S, NL12S, B6, B7, B10, B12, C10	
	323139	FILTER ELEMENT, STEERING PUMP		
	1573868 (8152288) (8158299) 3986622	RESERVOIR, CLUTCH CONTROL		
	341050	OIL SEAL, STEERING GEAR 26X37X7/7,5	F84, F85, F88, G88, F89, F6, F7, FL7, F10, FL10, FS10, F12, FL12, F16, N84, N86, N88, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B57, B58, B9M, B10M, B12	

	OEM NO	DESCRIPTION	NOTES	
	1592945	OIL RESERVOIR		
	1586076	SPRING, ACCELERATOR LINKAGE	F7, FE7, FS7, F10, FS10, F12, F16, N7 ch.-12000, N10 ch.- 49000, N10 ch.306000-, N10 USA, NL10 AUS, N12 ch.306000-, N12 USA, NL12 AUS, B6, B7 ch.20000-, B7 ch.30000-	
	1586922	SPRING, ACCELERATOR LINKAGE	F7, FE7, FS7, F10, FS10, F12, F16, N7 ch.-12000, N10 ch.- 49000, N10 ch.306000-, N10 USA, NL10 AUS, N12 ch.306000-, N12 USA, NL12 AUS, B6, B7 ch.20000-, B7 ch.30000-	
	1608537	SPRING, ACCELERATOR LINKAGE	F7, FE7, FS7, F10, FS10, F12, F16, N7 ch.-12000, N10 ch.- 49000, N10 ch.306000-, N10 USA, NL10 AUS, N12 ch.306000-, N12 USA, NL12 AUS, B6, B7 ch.20000-, B7 ch.30000-	
	3034566	SPRING, ACCELERATOR LINKAGE	B10, B12	
	8155199 (1626477) 3963418	PLUG, FOR HUB CAP	FL616-619, FL7, FS7, F10, F12, FH12, FL12, F16, FH16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S	
	20390132	PLUG, FOR HUB CAP	FL616-619, FL7, FS7, F10, F12, FH12, FL12, F16, FH16, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S	
	1089552 (1587792)	OIL SEAL, FRONT WHEEL HUB 110X140X12/19	FL616-619, F7, FE7, FL7, FS7, FL10, FS10, F12, FH12, FL12, F16, FH16, N10, NL10S, N12, NL12S, B7, B9M, B10M, C10M, B12	
	944665	OIL SEAL, WHEEL HUB 148X170,2X31,5		
	944667	OIL SEAL, FRONT WHEEL HUB 133,35X156,6X14/12	F86, F88, G88, G89, F7, F10, F12, N7, N10, N12, B57/58/59, B9M, B10M	

	OEM NO	DESCRIPTION	NOTES	
	1546480	OIL SEAL, DRIVE UNIT 45X62X8	FH12 / FH16	
	1522384	NUT (REAR AXKE)	N10, N12, F10, F12, NL10, NL12, FH12, FH16	
	324665 311401	NUT (REAR WHEEL HUB)	F7, FK7, F10, FL10, F12, FH12, F16, FH16	
	334374	NUT (REAR WHEEL HUB)		
	191178	NUT (REAR WHEEL HUB)	F7, FK7, F10, FL10, F12, FH12, F16, FH16	
	1605838	WASHER, FRONT WHEEL HUB	F10, F12, NL10, NL12 FH12, FH16	
	1575525	LOCK WASHER, FRONT WHEEL HUB	F86, F87, F88, F89, G89, F7, FL7, F10, FL10, F12, N7, N10, N12, B57, B58, B59, B9M, B10M	
	191179	LOCK WASHER, REAR WHEEL HUB	F84, F85, F88, G88, F89, F6, F7, FL7, F10, FL10, FS10, F12, FH12, FL12, F16, FH16, N84, N86, N88, N7, N10, NL10 AUS, NL10S, N12, NL12 AUS, NL12S, B57, B58, B9M, B10M, C10M, B12	
	8150263	BUSHING, KING PIN	FOR: 92.90267	
	8150264	BUSHING, KING PIN	FOR: 92.90266	

	OEM NO	DESCRIPTION	NOTES	
	1580493	SPEEDOMETER CABLE	F10, F12	
	1605917	CONTROL ROD, ACCELERATOR LINKAGE	FL7 / FL10 / FL12	
	1605921	CONTROL ROD, ACCELERATOR LINKAGE	FL7 / FL10 / FL12	
	959079	BALL JOINT, ACCELERATOR LINKAGE	F88,F89,FL10,F12 F16,N10,N12,NL12	
	1614180	STOP CONTROL CABLE ----- HAND THROTTLE CONTROL CABLE	FL7 ch.313629-, 883659-, F10 ch.40145-, FL10 ch.313698-, 883659-, F12 ch.64517-, F16, N10 ch.313553-, 553076-, NL10 AUS, NL10S, N12 ch.313594-, 553076-, NL12 AUS, NL12S, B9M, B10B, B10M, B12	
	324560	HAND THROTTLE CONTROL CABLE	F84/F85 ch.-14710, F86, F87 ch.-22768, F89/G89 ch.-9703, N84, N86, NB86, N88, NB88, N7 ch.-8774, N10 ch.-33769, N12, B54, B57, B58 ch.-9764	
	1577212	HAND THROTTLE CONTROL CABLE		
	324560	HAND THROTTLE CONTROL CABLE	F89/G89/ N88, NB88,N7,N10,N12 B54, B57, B58	
	6779714	STOP CONTROL CABLE	FL6 / FL7	
	6777149	HAND THROTTLE CONTROL CABLE	FL6 / FL7	

	OEM NO	DESCRIPTION	NOTES	
	-	ABS - BRAKE SYSTEM CABLE 5 POLE	L : 3.00 mm	
	-	ABS - BRAKE SYSTEM CABLE 5 POLE	L : 4.00 mm	
	-	EBS – ELECTRICAL SYSTEM CABLE 7 POLE	L : 3.00 mm	
	-	EBS – ELECTRICAL SYSTEM CABLE 7 POLE	L : 4.00 mm	
	-	TRAILER ABS 15 POLE CABLE	L : 3.00 mm	
	-	TRAILER ABS 15 POLE CABLE	L : 4.00 mm	
	6212614	ANCHOR		
	848093	ANCHOR		
	240458	ANCHOR		
	244539 (845108)	SHAFT AND CLUTCH ASSAMBLY		

	OEM NO	DESCRIPTION	NOTES	
	6212791	FIELD WINDING		
	6212612 (6212705)	FIELD WINDING		
	243702	FIELD WINDING		
	477049	STARTER MOTOR	FL7, FM7, FS7, B7	
	465929	STARTER MOTOR	B10	
	465930	STARTER MOTOR	F10, F12, FL10, N10, N12, B12	
	240340	STARTER MOTOR	F10, F88, FB88, G88, N10	
	465931	STARTER MOTOR	F12, N12	
	240488	ACTUATOR SOLENOID	ALL MODELS	
	240493	STARTER SOLENOID	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	243180	STARTER PINION 11RD		
	6643675	STARTER PINION 9RD		
	240456	COVER		
	240453	ROLLER BEARING		
	240496	PROTECTING CASING		
	6212621	CARBON BRUSH SET		
	240455	BUSHING		
	240481	BUSHING		
	244348 (244315)	BEARING SHIELD		
	844408	BEARING SHIELD		



	OEM NO	DESCRIPTION	NOTES	
	240740	BEARING SHIELD		
	240449	BEARING SHIELD		
	1697032	STATOR		
	3091570	ROTOR		
	1697031	ROTOR		
	6779261	ALTERNATOR 28V 55A	B12, F7, F10, F12, F16, FL6, FL7, FL10, N7, N10, N12	
	1607362	ALTERNATOR 28V 55A	F7, F10, F12, FL6, FL7, FL10, N7, N10, N12	
	8156816	ALTERNATOR 28V 55A	FL12, FH16	
	1096757	ALTERNATOR 28V 55A	FH16	
	1089861	ALTERNATOR 28V 55A	F10, F12, F16, FL10, NL10, NL12, FL7, N10, N12	
	6239266	CHARGER REGULATOR		

	OEM NO	DESCRIPTION	NOTES	
	3090431	RECTIFIER		
	3090260	RECTIFIER		
	3097731 (3094731)	RECTIFIER		
	244426 (1698185) (6239266)	CHARGER REGULATOR		
	-	REPAIR KIT, AIR DRYER	ALL MODELS	
	272701	REPAIR KIT, FOUR CIRCUIT PROTECTION VALVE		
	271186	REPAIR KIT, (PROTECTION VALVE)		
	270890	REPAIR KIT, FOOT BRAKE VALVE		
	1508614	FOOT BRAKE VALVE	WABCO REF: 461 307 475 0	
	1500494	FOOT BRAKE VALVE		


	OEM NO	DESCRIPTION	NOTES	
	272571	REPAIR KIT, FOOT BRAKE VALVE		
	20410545 1628491 20374068	FOOT BRAKE VALVE MB 4690 96.00200	FH12 / FH 16	
	3093073	REPAIR KIT, FOOT BRAKE VALVE	For: 96.410545	
	1697318	REPAIR KIT, LOAD SENSING VALVE		
	-	REPAIR KIT, LEVELLING VALVE	For: 96.07728	
	273668	REPAIR KIT, (LEVELLING VALVE)	For; 96.00500	
	272539	REPAIR KIT, RELAY EMERGENCY VALVE	WABCO REF: 971 002 003 2	
	-	REPAIR KIT, FOOT BRAKE VALVE	BOSCH REF: 1 487 010 178	
	272750	REPAIR KIT, TRAILER CONTROL VALVE	For: 96.85346	
	244818 3094877	REPAIR KIT, TRAILER CONTROL VALVE	For: 96.07887	

	OEM NO	DESCRIPTION	NOTES	
	272517	REPAIR KIT, RELAY VALVE	For: 96.76736	
	571174	RELAY VALVE	WABCO REF: 973 011 001 0	
	-	REPAIR KIT, RELAY VALVE	For: 96.1174	
	-	REPAIR KIT, LEVELLING VALVE	For 96.7838 For 96.7839	
	272577	REPAIR KIT, HAND BRAKE VALVE	For: 96.09055	
	272794	REPAIR KIT, HAND BRAKE VALVE	For: 96.88103	
	1581929 1505043 1135002	QUICK RELEASE VALVE	M 22 X 1,5	
	1588769	QUICK RELEASE VALVE	M 16 X 1,5	
	272504	RELEASE VALVE		
	1590128	PRESSURE REGULATOR	(M22x1,5) (5,5 Bar)	


	OEM NO	DESCRIPTION	NOTES	
	1598426	PRESSURE REGULATOR	(M22X1,5) (5,5 BAR)	
	-	PRESSURE REGULATOR	(M22X1,5) (6 BAR)	
	-	REPAIR KIT, PRESSURE REGULATOR	For: 96.90128 For: 96.98426 For: 96.00145	
	-	REPAIR KIT, UNLOADER VALVE	For: 96.00160	
	1505044	DISTRIBUTOR VALVE	ALL MODELS	
	-	ABS SENSOR L: 400 mm	WABCO REF : 441 032 808 0	
	-	ABS SENSOR L: 1000 mm	WABCO REF : 441 032 809 0	
	-	DIRECTIONAL CONTROL VALVE	WABCO REF: 463 013 112 0	
	1572175	SAFETY VALVE	TYPE : KX1729/1 9,30bar M16*1,5	
	1622431	SAFETY VALVE	TYPE : KX1729/2 10,30bar M16*1,5	

	OEM NO	DESCRIPTION	NOTES	
	-	SAFETY VALVE	TYPE : KX1729/3 10,7bar M16*1,5	
	1591738	SAFETY VALVE	TYPE : KX1729/4 13,5bar M16*1,5	
	-	SAFETY VALVE	TYPE : KX1729/5 12.9bar M16*1,5	
	263945	REPAIR KIT,	BENDIX REF:280.375	
	-	REPAIR KIT, RELAY VALVE	KNORR REF: I80221	
	-	REPAIR KIT, RELAY VALVE	KNORR REF: I68094	
	244322	REPAIR KIT, RELAY VALVE	BOSCH REF: 1 487 010 007	
	-	REPAIR KIT, RELAY VALVE	BOSCH REF: 1 487 010 234	
	-	REPAIR KIT, TRAILER CONTROL VALVE	KNORR REF: I 81234	
	3091493	REPAIR KIT, TRAILER CONTROL VALVE	BOSCH REF: 1 487 010 166	

	OEM NO	DESCRIPTION	NOTES	
	3035101	REPAIR KIT, AIR DRYER VALVE	WABCO REF: 432 431 274 0	
	-	REPAIR KIT, FOOT BRAKE VALVE	BOSCH REF: 1 487 010 060	
	-	REPAIR KIT, TRAILER CONTROL VALVE	KNORR REF: I 93262	
	1613328	FOOT BRAKE VALVE	F10, F12, F16, B12 NL10, NL12	
	1598125	FOOT BRAKE VALVE	BOSCH REF: 0 481 064 115	
	1695943	FOOT BRAKE VALVE	WABCO REF: 461 324 520 0	
	1527590	VALVE, DIRECTIONEL CONTROL	ALL MODELS (OLD MODEL)	
	1591032	INHIBITOR VALVE	KNORR REF: AE1122	
	1591031	FILTER, AIR TANK	F10 / F12	
	365723	AUTOMOTIC DRAIN VALVE KNORR EE4106	ALL	

	OEM NO	DESCRIPTION	NOTES	
	-	SPANSET, TRAILER 8 M.	ALL MODELS	
	-	SPANSET, TRAILER 10 M.	ALL MODELS	
	-	SPANSET, TRAILER 12 M.	ALL MODELS	
	1573549 1593411	GRILLE (SET)	F10, F12	
	1573821 1590873	GRILLE	F10, F12 (Old Model)	
	1611590 1608148	GRILLE	F10, F12 (New Model)	
	1589663	LOCK, GRILLE	F10, F12	
	- 1575509 1575508 1575507	EMBLEM SET "V,O,L,V,O" EMBLEM "V" EMBLEM "O" EMBLEM "L"	F10, F12	
	1594360	MUDFLAP	F10, F12	
	476015	GRILL, AIR INLET	F10, F12	

	OEM NO	DESCRIPTION	NOTES	
	1572503	EMBLEM "F10"	F10	
	1572502	EMBLEM "F12"	F12	
	1612329	EMBLEM "F10"	F10	
	1612331	EMBLEM "F12"	F12	
	1577011	EMBLEM "10 TURBO 6"	F10	
	1577010	EMBLEM "12 TURBO 6"	F12	
	1697967 (1517959)	DOOR SHELL L	F10, F12	
	1697968 (1517960)	DOOR SHELL R	F10, F12	
	1571117	DOOR EXTENSION L	F10, F12	
	1571118	DOOR EXTENSION R	F10, F12	



	OEM NO	DESCRIPTION	NOTES	
	1509604 1614491 1509789	CAB SIDE L	F10, F12	
	1509605 1614490 1509599	CAB SIDE R	F10, F12	
	1594077	STOWAGE COMPARTMENT HATCH	F10, F12	
	1588738 1585729	FRONT SECTION	F10, F12	
	1517957	WINDSCREEN FRAME	F10, F12	
	1509726	WINDSCREEN FRAME L	F10 ch.-25000, F12 ch.-34000	
	1509727	WINDSCREEN FRAME R	F10 ch.-25000, F12 ch.-34000	
	1614428	WINDSCREEN FRAME L		
	1614429	WINDSCREEN FRAME R		
	1610787	DIRT DEFLECTOR L	F10 ch.314000-, F12 ch.314000-, F16	


	OEM NO	DESCRIPTION	NOTES	
	1610788	DIRT DEFLECTOR R	F10 ch.314000- F12 ch.314000- F16	
	1586591	CORNEL PANEL L	F10 ch.-313999, F12 ch.-313999	
	1586592	CORNEL PANEL R	F10 ch.-313999, F12 ch.-313999	
	1587659 (1580301)	DIRT DEFLECTOR L	F10 ch.-313999 F12 ch.-313999	
	1587660 (1580302)	DIRT DEFLECTOR R	F10 ch.-313999 F12 ch.-313999	
	1605420 (1587463)	CAP, HEAD LAMP L	F10 ch.-313999 F12 ch.-313999	
	1605421 (1587464)	CAP, HEAD LAMP R	F10 ch.-313999 F12 ch.-313999	
	1586142 1611594	CAP, HEAD LAMP L	F10 ch.-313999 F12 ch.-313999	
	1586143 1611591	CAP, HEAD LAMP R	F10 ch.-313999 F12 ch.-313999	
	1089122 (1621903)	RETAINER L	F10 ch.314000- F12 ch.314000- F16	

	OEM NO	DESCRIPTION	NOTES	
	1089123 (1621904)	RETAINER R	F10 ch.314000- F12 ch.314000- F16	
	1611178	BRACKET	F10 ch.314000- F12 ch.314000- F16	
	1698146 (1621184)	HOUSING, LIGHT INDICATOR L	F10 ch.314000- F12 ch.314000- F16	
	1698147 (1621185)	HOUSING, LIGHT INDICATOR R	F10 ch.314000- F12 ch.314000- F16	
	1578428	COVER PLATE L	F10, F12	
	1089967 (1509945)	COVER PLATE R	F10, F12	
	1509844	FOOT STEP, UPPER OLD VERSION	F10, F12	
	1509846	FOOT STEP, LOWER OLD VERSION	F10, F12	
	1610896	FOOT STEP NEW VERSION	F10, F12	
	1623888 (1509762)	MUDGUARD, FRONT	F10, F12	

	OEM NO	DESCRIPTION	NOTES	
	1585235 1610806	MUDGUARD, FRONT	F10 ch.25001-, F12 ch.34001-	
	6778814	EMBLEM	F10 ch.314000-, F12 ch.314000- FL10, F16	
	1573830	BUMPER	F10, F12	
	1573864	BUMPER	F10, F12	
	8158216 (8150689)	BUMPER	F10 ch.314000- F12 ch.314000-	
	8158218	BUMPER	FL10 ch.377359- FL10 ch.561897-	
	6861728	WIND DEFLECTOR R	F10, F12, F16	
	6861729	WIND DEFLECTOR L	F10, F12, F16	
	1188626	SUN VISOR, BLUE	F10, F12	
	1188627	SUN VISOR, RED	F10, F12	

	OEM NO	DESCRIPTION	NOTES	
	1188628	SUN VISOR, GREEN	F10, F12	
	1584316	SUN VISOR, GREY	F10, F12	
	1188629	BRACKET SET, SUN VISOR 1584306/1584307 1584308/1584309	F10, F12	
	1081350 8151400	ENGINE BONNET	NL10 / NL12	
	1081346	FRONT MUDGUARD, L	NL10 / NL12	
	1081347	FRONT MUDGUARD, R	NL10 / NL12	
	1614697	SUN VISOR, GREY	NL10, NL12	
	-	SUN VISOR, BLUE	NL10, NL12	
	-	SUN VISOR, GREEN	NL10, NL12	
	-	SUN VISOR, RED	NL10, NL12	

	OEM NO	DESCRIPTION	NOTES	
	-	BRACKET SET, SUN VISOR	NL10, NL12	
	1594405 (1089032)	GRILLE	FL7, FL10	
	1086217 1609538	WIND DEFLECTOR L	FL7, FL10	
	1086218 1609539	WIND DEFLECTOR R	FL7, FL10	
	1664815	GRILL, AIR INLET		
	8158218	BUMPER	FL10 ch.377359 FL10 ch.561897	
	1592452	HOUSING, FOOT STEP -PLASTIC- L	FL7, FL10	
	1592453	HOUSING, FOOT STEP -PLASTIC- R	FL7, FL10	
	1598743	FOOT STEP	FL7, FL10	
	3963328 (1089394)	MUDGUARD, FRONT	FL7, FL10	

	OEM NO	DESCRIPTION	NOTES	
	1599652	SUN VISOR, GREY	FL7, FL10	
	-	SUN VISOR, GREEN	FL7, FL10	
	-	SUN VISOR, BLUE	FL7, FL10	
	-	SUN VISOR, RED	FL7, FL10	
	8191220 8143393	PANEL, FRONT	FH12, FH16	
	8191316 (8189295)	PANEL, FRONT	FH12, FH16	
	8141236	FRONT MUDGUARD L	FH12, FH16, FM12, FM16	
	8141237	FRONT MUDGUARD R	FH12, FH16, FM12, FM16	
	8154633	MUDGUARD L	FH12, FH16, FM12, FM16	
	8154634	MUDGUARD R	FH12, FH16, FM12, FM16	

	OEM NO	DESCRIPTION	NOTES	
	8141234	MUDGUARD L	FH12, FH16, FM12, FM16	
	8141235	MUDGUARD R	FH12, FH16, FM12, FM16	
	8141003	COVER L	FH12, FH16, FM12, FM16	
	8141004	COVER R	FH12, FH16, FM12, FM16	
	1619690 (1086533) 20398907	DOOR EXTENSION L	FH12, FH16, FM12, FM16	
	1619691 (1086534) 20398908	DOOR EXTENSION R	FH12, FH16, FM12, FM16	
	8189195 (8144107) 8189300	COVER, L	FH12, FH16, FM12, FM16	
	8189196 (8144108) 8189301	COVER, R	FH12, FH16, FM12, FM16	
	8141289	PROTECTING PLATE LAMP BAKALITE L	FH12, FH16, FM12, FM16	
	8141290	PROTECTING PLATE LAMP BAKALITE R	FH12, FH16, FM12, FM16	

	OEM NO	DESCRIPTION	NOTES	
	3090972 1062547 3980869 20398385	HOUSING HEAD LAMP L	FH12, FH16	
	3090971 1062548 3980870 20398386	HOUSING HEAD LAMP R	FH12, FH16	
	8144553	MUDGUARD, FRONT L	FH12, FH16, FM12, FM16	
	8144554	MUDGUARD, FRONT R	FH12, FH16, FM12, FM16	
	1619148 (8189092)	DEFLECTOR L	FH12, FH16	
	1619149 (8189093)	DEFLECTOR R	FH12, FH16	
	8156540	MUDGUARD, FRONT L	FH12, FH16 FM12, FM16	
	1623459	MUDGUARD, FRONT R	FH12, FH16 FM12, FM16	
	3171391	REAR MUDGUARD	FH12/ FH16 NEW MODELS	
	8155808	REAR MUDGUARD	FH12/ FH16 FM10/ FM12	


	OEM NO	DESCRIPTION	NOTES	
	8156551	REAR MUDGUARD	FH12/ FH16 FM10/ FM12	
	8156554	REAR MUDGUARD	FH12/ FH16 FM10/ FM12	
	8156556	TENSIONER MUDGUARD	FH12/ FH16 FM10/ FM12	
	1079981	TENSIONER, MUDGUARD	FH12/ FH16 FM9/ FM10/ FM12 NEW MODELS	
	20498623	MUDGUARD TENSIONER RUBBER 2.SERIES	FH12, FH16, FM12, FM16 NEW VERSION	
	8191313 (8191103) 20379437	FOOT STEP, LOWER	FH12, FH16	
	8191314 (8191104) 20379438	FOOT STEP, MIDDLE	FH12, FH16	
	8191315 (8191105) 20379439	FOOT STEP, UPPER	FH12, FH16	
	8189337 (8191188) (8152722)	SPOILER	FH12, FH16	
	8144454 (8189329)	BUMPER	FH12, FH16, FM12, FM16	

	OEM NO	DESCRIPTION	NOTES	
	3963592 8151861	BRACKET SET, SUN VISOR LONG CABIN	FH 12 / 16 FM 10 / 12	
	8189318 (8140923)	SUN VISOR, GREY	FH12, FH16, FM12, FM16	
	8189319	SUN VISOR, RED	FH12, FH16, FM12, FM16	
	8189320	SUN VISOR, GREEN	FH12, FH16, FM12, FM16	
	8189321	SUN VISOR, BLUE	FH12, FH16, FM12, FM16	
	8189310 (1619092)	SUN VISOR, GREY 2 HOLES	FH12, FH16, FM12, FM16	
	8189311	SUN VISOR, RED 2 HOLES	FH12, FH16, FM12, FM16	
	8189312	SUN VISOR, GREEN 2 HOLES	FH12, FH16, FM12, FM16	
	8189313	SUN VISOR, BLUE 2 HOLES	FH12, FH16, FM12, FM16	
	3963593 8151862	BRACKET SET, SUN VISOR SMALL CABIN	FH 12 / 16 FM 10 / 12	

	OEM NO	DESCRIPTION	NOTES	
	- 20467422 20467412 20467414 20467424	BRACKET SET, SUN VISOR	FH 12 / 16 NEW FM 9 / 10 / 12	
	8189314 1619093	SUN VISOR, GREY 5 HOLES	FH12, FH16, FM12, FM16	
	8189315	SUN VISOR, RED 5 HOLES	FH12, FH16, FM12, FM16	
	8189316	SUN VISOR, GREEN 5 HOLES	FH12, FH16, FM12, FM16	
	8189317	SUN VISOR, BLUE 5 HOLES	FH12, FH16, FM12, FM16	
	1674900	AIR INLET, UPPER WITHOUT GRILL	FH12	
	1674243	GRILL, AIR INLET	FH12	
	1676532	AIR INLET, LOWER	FH12	
	20372226	FOOT STEP, L	FH12, FH16, FM12	
	20372227	FOOT STEP, R	FH12, FH16, FM12	

	OEM NO	DESCRIPTION	NOTES	
	1584575	CABIN AIR FILTER	F10, F12, FL10, FL12 F16	
	8143691	CABIN AIR FILTER	FH12 / FH16 / FM10 FM12 / FM7	
	3175417 20425625	BUMPER	FH 12 / 16 NEW	
	3175418 20425626	BUMPER, LH	FH 12 / 16 NEW	
	3175419 20425627	BUMPER, RH	FH 12 / 16 NEW	
	3175406 20529638	FOOT STEP, LH	FH 12 / 16 NEW FM 9 / 10 / 12	
	3175407 20529640	FOOT STEP, RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20452886	COVER, HEADLAMP LH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20452887	COVER, HEADLAMP RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20452847	FRAME, LH	FH 12 / 16 NEW FM 9 / 10 / 12	


	OEM NO	DESCRIPTION	NOTES	
	20452848	FRAME, RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20507020 20453930	CONCEALING PANEL LH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20507021 20453931	CONCEALING PANEL RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20425418	COWL, SIGNAL LAMP LH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20425419	COWL, SIGNAL LAMP RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	3175927	FOOT STEP, LH	FH 12 / 16 NEW FM 9 / 10 / 12	
	3175928	FOOT STEP, RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20467037	DOOR EXTENSION LH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20467038	DOOR EXTENSION RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	3175929	MUDGUARD, LH	FH 12 / 16 NEW FM 9 / 10 / 12	

	OEM NO	DESCRIPTION	NOTES	
	3175930	MUDGUARD, RH	FH 12 / 16 NEW FM 9 / 10 / 12	
	20360788	FOOT STEP, LOWER LH	FH 12 / 16 FM 9 / 10 / 12	
	20360789	FOOT STEP, LOWER RH	FH 12 / 16 FM 9 / 10 / 12	
	20379439	FOOT STEP, UPPER LH / RH	FH 12 / 16 FM 9 / 10 / 12	
	1587694	COVER, BATTERY BOX	F10 ch.-25000, F12 ch.-34000	
	1590507	COVER, BATTERY BOX	F10 ch.25001-, F10 ch.314000-, F12 ch.34001-, F12 ch.314000-, F16 FL7, FL10, FS10	
	3127594	COVER, BATTERY BOX	FH12, FH16, FM12, FM16	
	309042	STRAP, BATTERY COVER	F10 / F12 FH12 / FH16 FM12 / FM16	
	1083670 1618521	GAS SPRING, GRILLE	F10 ch.314000-, F12 ch.314000-, F16	
	1611159	GAS SPRING, GRILLE	FL7, FL10, FL12	

	OEM NO	DESCRIPTION	NOTES	
	1619106	GAS SPRING , GRILLE	FH12 / FH16	
	8143670 3981920	GAS SPRING , BOOT LID	FH12 / FH16	
	1614564	DOOR HANDLE (WITHOUT LOCK)	F10	
	1613085	DOOR HANDLE (WITHOUT LOCK)	F12	
	1063327	INSIDE HANDLE BASE, LH	FH12, FH16 FM10, FM12	
	1063328	INSIDE HANDLE BASE, RH	FH12, FH16 FM10, FM12	
	20379593	INSIDE HANDLE LEVER, LH - RH	FH12, FH16 FM10, FM12	
	3090483	LOCK CYLINDER KIT 1 CYL. / 2 KEY	FH12, FH16 FM10, FM12	
	3090484	LOCK CYLINDER KIT 2 CYL. / 2 KEY	FH12, FH16 FM10, FM12	
	20398466	OUTSIDE HANDLE, LH	FH12, FH16 FM10, FM12	

	OEM NO	DESCRIPTION	NOTES	
	20398467	OUTSIDE HANDLE, RH	FH12, FH16 FM10, FM12	
	3175365	OUTSIDE COVER, L	FH12, FH16 FM10, FM12	
	3175366	OUTSIDE COVER, R	FH12, FH16 FM10, FM12	
	3176545	WINDOW REGULATOR, LH	FH12, FH16 FM10, FM12	
	3176546	WINDOW REGULATOR, RH	FH12, FH16 FM10, FM12	
	20588325	DOOR LOCK, LH	FH12, FH16 FM10, FM12	
	20588326	DOOR LOCK, RH	FH12, FH16 FM10, FM12	
	8150636	WINDOW REGULATOR, LH	FL7, FL10, FL12	
	8150637	WINDOW REGULATOR, RH	FL7, FL10, FL12	

	OEM NO	DESCRIPTION	NOTES	
	8150630	WINDOW REGULATOR, LH	FL7, FL10, FL12	
	8150631	WINDOW REGULATOR, RH	FL7, FL10, FL12	
	1610883	DOOR LOCK OUTER, LH	FL7, FL10, FL12	
	1610923	DOOR LOCK OUTER, RH	FL7, FL10, FL12	
	1612333	DOOR HANDLE GASKET	FL7, FL10, FL12	
	1610882	DOOR LOCK, LH	FL7, FL10, FL12	
	1610922	DOOR LOCK, RH	FL7, FL10, FL12	
	1660269 6892111	CLAMP, AIR INLET	F10, F12	
	1082466 (1508722)	WINDOW REGULATOR L/R	F10, F12	
	1500858	WINDOW REGULATOR L	N10, N12	

	OEM NO	DESCRIPTION	NOTES	
	1500859	WINDOW REGULATOR R	N10, N12	
	1605245 1254749 1518420	HANDLE	F10, F12, N10, N12	
	3944648	CAP, CAB MOUNTING FRONT L	FH12 / FH16 OLD	
	3944649	CAP, CAB MOUNTING FRONT R	FH12 / FH16 OLD	
	335443	RESERVOIR, ANTI- FREEZE	ALL MODELS	
	-	AIR HOSE, CABIN	ALL MODELS	
	-	AIR HOSE, CABIN	ALL MODELS	
	-	MUDGUARD, TRAILER 2100X 1340X 650 mm	ALL MODELS	
	-	MUDGUARD, TRAILER 2100X 1340X 450 mm	ALL MODELS	
	-	MUDGUARD, TRAILER 1900X 1200X 460 mm	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	-	MUDGUARD, TRAILER 48X 80 mm	ALL MODELS	
	-	MUDGUARD 70X 65 mm	ALL MODELS	
	-	REAR MUDGUARD		
	-	COVER, BATTERY BOX		
	-	MUDGUARD, REAR NEW MODEL		
	-	MUDGUARD, REAR		
	-	MUDGUARD, FRONT-REAR		
	1609559 1612357 1588976 1607749 1589008 1599401	MUDGUARD, REAR A:134CM, B:65CM, L:210CM, H:67CM	ALL MODELS	
	1611389 1605811 1605812 1610215	MUDGUARD, REAR	F, FL, NL SERIES	

	OEM NO	DESCRIPTION	NOTES	
	8154385 (1077451)	MUDGUARD BRACKET	FH12, FH16 FM12, FM16	
	20466895 3197851	MUDGUARD BRACKET	FM9, FM12	
	20466894	MUDGUARD BRACKET	FM9, FM12	
	20456709	SUN VISOR	FH12 / FH16 2.VERSION	
	20527443	SUN VISOR	FH12 / FH16 2.VERSION	
	1699010	MAIN MIRROR UNHEATED Ø 384X200X105	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	
	1699011	MAIN MIRROR HEATED(24v) Ø 384X200X105	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	
	1699014	GLASS , MAIN MIRROR UNHEATED	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	
	1699015	GLASS , MAIN MIRROR HEATED	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	

	OEM NO	DESCRIPTION	NOTES	
	1699012	MAIN MIRROR UNHEATED Ø 203X173X105	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	
	1699013	MAIN MIRROR HEATED(24v) Ø 203X173X105	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	
	1699016	GLASS , MAIN MIRROR UNHEATED	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	
	1699017	GLASS , MAIN MIRROR HEATED	FL7,FL10,F10 F12,FL12,F16 NL10,NL12	
	1581550	MAIN MIRROR UNHEATED Ø 373X185X50	F10, F12	
	1594412 1581616 1594411	MAIN MIRROR HEATED(24v) Ø 373X185X50	F10, F12	
	1581599	GLASS , MAIN MIRROR UNHEATED	F10, F12	
	1581602	GLASS , MAIN MIRROR HEATED(24v)	F10, F12	



	OEM NO	DESCRIPTION	NOTES	
	6793879	MAIN MIRROR UNHEATED Ø 365X179X65	FL6	
	6793880	MAIN MIRROR HEATED(24v) Ø 365X179X65	FL6	
	1697926	GLASS , MAIN MIRROR UNHEATED	FL6	
	3090006	GLASS , MAIN MIRROR HEATED	FL6	
	352026	MAIN MIRROR UNHEATED Ø 310X219X90	F88,F89,N10, N12,F10,F12	
	1599034 1572146	MAIN MIRROR HEATED(24v) Ø 310X219X90	F88,F89,N10, N12,F10,F12	
	352507	GLASS , MAIN MIRROR UNHEATED	F88,F89,N10, N12,F10,F12	
	3090010	GLASS , MAIN MIRROR HEATED	F88,F89,N10, N12,F10,F12	

	OEM NO	DESCRIPTION	NOTES	
	1599462 3090395	MAIN MIRROR UNHEATED Ø 438X210X105	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1594902 1621353	MAIN MIRROR HEATED(24v) Ø 438X210X105	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1697007	GLASS , MAIN MIRROR UNHEATED	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1697008	GLASS , MAIN MIRROR HEATED	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1618973	MAIN MIRROR UNHEATED Ø 225X225X90	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1618769 1621354	MAIN MIRROR HEATED(24v) Ø 225X225X90	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1697984	GLASS , MAIN MIRROR UNHEATED	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1697862	GLASS , MAIN MIRROR HEATED	FL7, FL10, F10, F12, F16, FS7, NL10, NL12	
	1622446 6793881 1607029 1622444	MAIN MIRROR UNHEATED Ø 246X149X30	F10, F12, F16, NL10 NL12, FL10, FL7	
	1697679	MAIN MIRROR HEATED(24v) Ø 246X149X30	F10, F12, F16, NL10 NL12, FL10, FL7	

	OEM NO	DESCRIPTION	NOTES	
	3980924	MAIN MIRROR, L HEATED (WITHOUT HANDLE)	FH12 , FH16 FM12 , FM16 NH 12	
	3980926	MAIN MIRROR, L HEATED AND ELECTRIC REMOTE CONTROLLED (WITHOUT HANDLE)	FH12 , FH16 FM12 , FM16 NH 12	
	3091256	GLASS UNIT, MAIN MIRROR UNHEATED	FH12 , FH16 FM12 , FM16 NH 12	
	3980925	MAIN MIRROR, R HEATED (WITHOUT HANDLE)	FH12 , FH16 FM12 , FM16 NH 12	
	3980934	MAIN MIRROR, R HEATED AND ELECTRIC REMOTE CONTROLLED (WITHOUT HANDLE)	FH12 , FH16 FM12 , FM16 NH 12	
	3091257	GLASS UNIT, MAIN MIRROR UNHEATED	FH12 , FH16 FM12 , FM16 NH 12	
	3980933	MAIN MIRROR, R HEATED (WITHOUT HANDLE)	FH12 , FH16 FM12 , FM16 NH 12	
	3980935	MAIN MIRROR, R HEATED AND ELECTRIC REMOTE CONTROLLED (WITHOUT HANDLE)	FH12 , FH16 FM12 , FM16 NH 12	
	3091259	GLASS UNIT, MAIN MIRROR UNHEATED	FH12 , FH16 FM12 , FM16 NH 12	

	OEM NO	DESCRIPTION	NOTES	
	1096643	MAIN MIRROR UNHEATED	FH 12 / 16 FH 12 / 16 NEW FM 9 / 12 NH 12	
	3090736	GLASS UNIT, MAIN MIRROR UNHEATED	FH12 , FH16 FM12 , FM16	
	3091756 3090737 3092854	GLASS UNIT, MAIN MIRROR HEATED (24v)	FH12 , FH16 FM12 , FM16	
	3090738	GLASS UNIT, MAIN MIRROR UNHEATED	FH12 , FH16 FM12 , FM16	
	3091757 3090739	GLASS UNIT, MAIN MIRROR HEATED (24v)	FH12 , FH16 FM12 , FM16	
	20455986 20567670	MIRROR GLASS 24v HEATED WITH PLASTIC 425 X 200	FH12 / FH16 NEW NH 12	
	-	MIRROR GLASS NON HEATED WITH PLASTIC 425 X 200	FH12 / FH16 NEW NH 12	
	20455995 20567685	MIRROR GLASS 24v HEATED WITH PLASTIC 188 X 170	FH12 / FH16 NEW NH 12	
	-	MIRROR GLASS NON HEATED WITH PLASTIC 188 X 170	FH12 / FH16 NEW NH 12	

	OEM NO	DESCRIPTION	NOTES	
	20455979	MAIN MIRROR, L	FH SERIES 2.Version 2005>	
	20455980	MAIN MIRROR, R	FH SERIES 2.Version 2005>	
	-	WHEEL TRIM	335mm, 10 Holes	
	-	WHEEL TRIM	335mm, 10 Holes	
	-	WHEEL TRIM	588mm, For Rim: 20"-22,5" Rear	
	-	WHEEL TRIM	430mm, For Rim: 17,5" Front	
	-	WHEEL TRIM	570mm, For Rim: 20"-22,5" Front	
	3183516	WHEEL TRIM	570mm, For Rim: 20"-22,5" Rear	
	-	WHEEL TRIM	430mm, For Rim: 17,5" Rear	
	-	WHEEL TRIM	588mm, For Rim: 20"-22,5" Rear	

	OEM NO	DESCRIPTION	NOTES	
	1508320	WINDOW GLASS WINDSCREEN Ø 770 X 2254	F10 , F12	
	1590571	WINDOW GLASS WINDSCREEN Ø 797 X 2255	F10 , F12	
	1085853	WINDOW GLASS WINDSCREEN Ø 863 X 2265	FL7 , FL10	
	1606672 1614393	WINDOW GLASS WINDSCREEN Ø 569 X 1712	N7 , N10 , N12 NL10 , NL12	
	1619250 8189873	WINDOW GLASS WINDSCREEN Ø 845 X 2200	FH 12 , FH16	
	1586037 (9520400) 1599007	FILLER CAP, FUEL TANK WITHOUT LOCK DIAM. 60MM	F4, FL4, F6, F6S, FL608-615, FL616-619, F7, FL7, FS7, F10, FL10, F12, FH12, F16, FH16, N7, N10, N10BR MK2, NL10 AUS, NL10BR, NL10S, N12, B12, B12BR Excl. Australia	
	6795590	FILLER CAP, FUEL TANK WITHOUT LOCK DIAM. 80MM	F4, FL4, F6, F6S, FL608-615, FL616-619, F7, FL7, FS7, F10, FL10, F12, FH12, F16, FH16, N7, N10, N10BR MK2, NL10 AUS, NL10BR, NL10S, N12, B12, B12BR Excl. Australia	
	8158995 308069	FILLER CAP, FUEL TANK WITH LOCK DIAM. 60MM	F4, FL4, F6, F6S, FL608-615, FL616-619, F7, FL7, FS7, F10, FL10, F12, FH12, F16, FH16, N7, N10, N10BR MK2, NL10 AUS, NL10BR, NL10S, N12, B12, B12BR Excl. Australia	
	8158693 1189577 8152630	FILLER CAP, FUEL TANK WITH LOCK DIAM. 80MM	F4, FL4, F6, F6S, FL608-615, FL616-619, F7, FL7, FS7, F10, FL10, F12, FH12, F16, FH16, N7, N10, N10BR MK2, NL10 AUS, NL10BR, NL10S, N12, B12, B12BR Excl. Australia	
	-	WHEEL TRIM, FRONT - PLASTIC - 22.5	ALL MODELS	

	OEM NO	DESCRIPTION	NOTES	
	MCK-1171/N	REPAIR KIT, BRAKE CALIPER	VOLVO	
	MCK-1102/N	REPAIR KIT, BRAKE CALIPER	VOLVO	
	MCK-1253	REPAIR KIT, BRAKE CALIPER	VOLVO	
	MCK-1254	REPAIR KIT, BRAKE CALIPER	VOLVO	
	MCK-1139	REPAIR KIT, BRAKE CALIPER	VOLVO	
	MCK-1238	REPAIR KIT, BRAKE CALIPER	VOLVO	
	MCK-1171	REPAIR KIT, BRAKE CALIPER	VOLVO	
	MCK-1192	REPAIR KIT, BRAKE CALIPER	VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	K 001300	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 010603	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 010604	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 000944	REPAIR KIT, BRAKE CALIPER	VOLVO	
	II 304130065	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 000696	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 000687	REPAIR KIT, BRAKE CALIPER	VOLVO	
	II 358510062	REPAIR KIT, BRAKE CALIPER	VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	K 001274	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 000375	REPAIR KIT, BRAKE CALIPER	VOLVO	
	II 339680062	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 000472	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 001925	REPAIR KIT, BRAKE CALIPER	VOLVO	
	K 001532	REPAIR KIT, BRAKE CALIPER	VOLVO	
	93161192	REPAIR KIT, BRAKE CALIPER	VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	II 368470064	REPAIR KIT, BRAKE CALÍPER	VOLVO	
	II 197140062	REPAIR KIT, BRAKE CALÍPER	VOLVO	
	II 179320062	REPAIR KIT, BRAKE CALÍPER	VOLVO	
	II 197330062	REPAIR KIT, BRAKE CALÍPER	VOLVO	
	II 39769F0063	REPAIR KIT, BRAKE CALÍPER	VOLVO	
	K 001301	REPAIR KIT, BRAKE CALÍPER	VOLVO	
	K 000945	REPAIR KIT, BRAKE CALÍPER	VOLVO	
	K 000029	REPAIR KIT, BRAKE CALÍPER	VOLVO	

	OEM NO	DESCRIPTION	NOTES	
	1069888	DISC SPRING	VT / 1708 B-2009 B VT-VTO/2214 B -2514B VT-VTO /2814 B	
	1521886	DISC SPRING	VT / 1708 B-2009 B VT-VTO/2214 B -2514B VT-VTO /2814 B	
	20476025	SEALING RING	VT-VTO	
	3192111	PUSHER PLATE AUTOMATIC	VT – VTO/2214 B	
	1521890	PUSHER PLATE	VT / 1708 B-2009 B - 2214 B – VT/2014- 2514-2514(OD) VT-VTO /2814 B	
	1652176	THRUST WASHER	R-SR-VT-VTO ALL SERIALS	
	1652688 (20944716)	LOCK WASHER	R-SR-VT-VTO	
	1652948	LOCK RING	R-SR-VT-VTO ALL SERIALS	
	20366756 1652538	REVERSE SHAFT	R-SR-VT-VTO ALL SERIALS	
	1069363	AXEL	EV72	

	OEM NO	DESCRIPTION	NOTES	
	20366608	SPACER RING	VT / 2412 B	
	20366611	AXLE SHAFT	VT / 2412 B	
	1656264	GEARBOX TYPE	R-SR-VT-VTO SERIALS	ALL
	1655569	BEARING RACE	VT / 1708 B	
	20773853	COMPANION FLANGE	VT-VTO / 2814 B ATO / 2512C-3112C AT / 2412C-2512C-2812 C	
	20483351 20365566	GEARBOX TYPE	VT / 2412 B	
	85107014	PLANET GEAR KIT	VT / 1708 B-2009 B - VT/2014-2214-2514- VT-VTO / 2814 B	
	1069957	GEARBOX TYPE	VT / 2412 B	
	20588777 8171735	DISC SPRING	VT / 1708 B-2009 B - VT-VTO/-2214B- 2514B-VT-VTO / 2814 B	
	20366588	COUNTER SHAFT	VT / 2412 B	

	OEM NO	DESCRIPTION	NOTES	
	20537204 20366959	GEARBOX TYPE	VT / 2412 B	
	20366733	GEARBOX TYPE	R / 1500 VT/1708 B	
	20366307	MAIN SHAFT	VT / 2009 B	
	20769606 20366123	INPUT SHAFT	VT / 2412 B	
	20366313	INPUT SHAFT	VT/1708 B	
	1668459	SPRING RING	R-SR-VT-VTO SERIALS ALL	
	3192541	ENGAGING SLEEVE	VT / 2412 B	
	20539768	GEARBOX TYPE	VT-VTO /2814 B	
	20366330	GEAR 3 rd	VT/1708 B	
	20366957	GEAR 3 rd	VTO / 2814 B	

	OEM NO	DESCRIPTION	NOTES	
	20366990	GEAR	VT / 2412 B AT/ 2412 C ATO / 2512 C	
	1069839 8172832	GEAR	VT / 2412 B	
	20366956	GEAR SPLITTER	VTO / 2814 B	
	3152798	ENGAGING SLEEVE	VT / 2412 B	
	1672243	REVERSE GEAR	VT /1708B- R/1500	
	8172752	GEAR 3 rd (WITH BEARING	VT / 2412 B	
	20537776 20366958	GEAR 3 rd (WITH BEARING)	VTO / 2814 B	
	8171942	GEARBOX TYPE	VT /1708B	
	20539766	GEAR 2 nd	VT – VTO /2814 B	
	20499806 20365514	GEAR 2 nd	VT / 2412 B	

	OEM NO	DESCRIPTION	NOTES	
	20366323	GEAR 2 nd	VT /1708B	
	20366329 1069194	GEAR	R / 1500 VT / 1708 B	
	20483445 20365512	GEAR 1 st	VT / 2214 B	
	1069316	GEAR 1 st	R / 1500 VT / 1708 B	
	20776788 20366955	GEAR SPLITTER	VTO /2814 B	
	20366306	COUNTER SHAFT	VT / 2009 B	
	21273152 20366317	GEARBOX TYPE	VT / 2009 B	
	20366316	GEARBOX TYPE	VT / 2009 B	
	20366311	GEAR 1 st	VT / 2009 B	
	20366310	GEAR	VT / 2009 B	

	OEM NO	DESCRIPTION	NOTES	
	20483783 20366321	INPUT SHAFT	VT / 2009 B	
	20589917 20366328	GUIDE SLEEVE	VT / 1708 B	
	20366314	GUIDE SLEEVE	VT / 1708 B-2009 B	
	1521449	NUT	VT / 2014 – 2214 VT / 2412 – 2514 VT – VTO / 2814 B	
	1521910	SUN GEAR (24 T)	VT / 2009 B – 2014 B VT / 2214 B -2514 VT – VTO / 2814 B	
	3152722 1521908	REVERSE GEAR	VT / 2009 B – 2014 B VT / 2014B-2214 B VT– VTO /2514-2814 B	
	20539764	COUNTER SHAFT	VT – VTO / 2814 B	
	1521930	COUNTER SHAFT	VT / 2014 – 2214 VTO / 2214 B	
	20883244 1521411	COUNTER SHAFT	VT / 2514 VT / 2514 (OD)	
	20806212 3191967	BEARING	VT / 2014 – 2214 VT / 2412 – 2514 VT – VTO / 2814 B	

	OEM NO	DESCRIPTION	NOTES	
	1069254	SYNCHRONIZING CONE	VT / 1708 B-2009 B-2014B VT / 2214 B - 2514 VT-VTO / 2814 B	
	3192951 1069253	SYNCHRONIZING CONE INNER	VT / 1708 B-2009 B-2014B VT / 2214 B - 2514 VT-VTO / 2814 B	
	1069255	SYNCHRONIZING CONE	VT / 1708 B-2009 B-2014B VT / 2214 B - 2514 VT-VTO / 2814 B	
	8171737 1521438	SYNCHRONIZING CONE	VT / 2014 B – 2214 B VT / 2412 B- 2514 VT – VTO/ 2814 B	
	1521879	ENGAGING RING	VT / 2014 B – 2214 B VT / 2412 B- 2514 VT – VTO/ 2814 B	
	1521878	ENGAGING RING	VT / 2014 B – 2214 B VT / 2412 B- 2514 VT – VTO/ 2814 B	
	20366735 3192251	HUB	VT / 2009 B – 2014 B VTO / 2214 – 2514 VT – VTO / 2814 B	
	20366826	ENGAGING SLEEVE	VT / 1708 B – 2009 B VT/2014B-2214B-2514B VT – VTO / 2814 B	
	20588775 20478726 8172414 1069256	ENGAGING SLEEVE	VT / 1708 B – 2009 B VT/2014-2214-2514 VT – VTO / 2814 B	
	20478729 8172416 1069257	ENGAGING SLEEVE	VT/2014-2214-2514 VT – VTO / 2814 B	

	OEM NO	DESCRIPTION	NOTES	
	20760515 1673541	ENGAGING RING	VT / 2014 B – 2214 B VT / 2412 B – 2514 VT – VTO / 2814 B	
	20760512 1673540	ENGAGING RING	VT / 2014 B – 2214 B VT / 2412 B – 2514 VT – VTO / 2814 B	
	1521406	MAIN SHAFT	VT/2014-2214-2514 VT – VTO / 2814 B	
	3192293 1521530	AXLE SHAFT	VT / 2009 B – 2014 B VT / 2214 B – 2514 VT – VTO / 2814 B	
	1521979	GUIDE SLEEVE	VT / 2014 B – 2214 B VT / 2514 B VT- VTO / 2814 B	
	20858492 20588772 1521920 8171944 8172497	GUIDE SLEEVE	VT / 2009–2014-2214 VT / 2514 VT – VTO /2814 B	
	20904803 20769602 1069239	INPUT SHAFT	VT-VTO/2214 B-2814 B VT / 2514 B	
	20781951 8171556 1673542	INPUT SHAFT	VT / 2014 B -25 14 VT / 2514 (OD)	
	1521909	GEAR CRAWLING GEAR	VT / 2009-2014-2214B	
	1521907	GEAR CRAWLING GEAR	VT / 2514 (OD)	

	OEM NO	DESCRIPTION	NOTES	
	20776783	CONSTANT GEAR	VT / 2412 B – 2514 B	
	20854441 20761840 1521912	CONSTANT GEAR	VT 2014 – 2214 B	
	1521421	GEAR	VT / 2514 (OD) VT / 2814 B VT – VTO /2514 B	
	8172640 1521915 1521589	GEAR 3 rd WITH BEARING	VT / 2014 B – 2214 B VTO/2214B-2514 (OD) VT / 2814 B	
	1521422	GEAR SPLITTER	VT / 2412B – 2514 B	
	20776785 3152728 1521483	GEAR SPLITTER	VT/2014(OD)- 2514(OD) VTO / 2214B-2514B	
	3152730 1521484	GEAR SPLITTER	VT/2014(OD)- 2514(OD) VTO / 2214B-2514B	
	20854437 1521913	GEAR SPLITTER	VT 2014 – 2214 B	
	20854435 1521914	GEAR 3 rd	VT 2014 – 2214 B VTO / 2214 B	
	1521414	GEAR 2 nd	VT /2514- 2514(OD)	

	OEM NO	DESCRIPTION	NOTES	
	1521917	GEAR 2 nd	VT / 2009 B VT /2014-2214B	
	1521413 1521916	GEAR 1st	VT / 2014-2214 B VT / 2514-2514 (OD) VT- VTO / 2814 B	
	21141850	REPAIR KIT	VT/2014B-2214B-2514B- VT -VTO/ 2412B -2814 B	
	20847116	REPAIR KIT	VT / 1708-2009-2014 VT /2214- 2514 VT-VTO /2814 B	
	1004057	REPAIR KIT	VT / 1708 – 2009-2014 VT/ 2214 – 2514 VT- VTO /2814 B	
	3092270	CALIPER , REP.KIT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	85102093	CALIPER ,MECHANISM FRONT LEFT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	85102095	CALIPER ,MECHANISM REAR LEFT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	85102096	CALIPER ,MECHANISM REAR RIGHT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	3092262	CALIPER ,MECHANISM LEFT	FM 9 / FM 10 FH 12 / FH 16 B 12	

	OEM NO	DESCRIPTION	NOTES	
	3092263	CALIPER ,MECHANISM RIGHT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	3092264	CALIPER , REP.KIT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	85102092	CALIPER , REP.KIT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	85102093	CALIPER , REP.KIT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	3095626	CALIPER , REP.KIT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	3092261	CALIPER , BEARING KIT FRONT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	3092329	CALIPER , BEARING KIT REAR	FM 9 / FM 10 FH 12 / FH 16 B 12	
	3095669	CALIPER REP.KIT	FM 9 / FM 10 FH 12 / FH 16 B 12	
	3092269	CALIPER REP.KIT	FM 9 / FM 10 FH 12 / FH 16 B 12	